

# INDUSTRIAL AUTOMATION

## USER MANUAL

Manuale d'uso

Manuel d'emploi

Bedienungsanleitung

Manual de uso

Manual do usuário

Руководство по эксплуатации

## VARIABLE FREQUENCY DRIVE **SINUS VEGA**

Basic User Manual-Manuale d'uso Basic

---

# Contents

|                                                           |           |
|-----------------------------------------------------------|-----------|
| <b>1. Preface</b>                                         | <b>5</b>  |
| <b>2. Inspection</b>                                      | <b>6</b>  |
| <b>3. Safety precautions</b>                              | <b>7</b>  |
| 3.1 Safety definition                                     | 7         |
| 3.2 Safety items                                          | 7         |
| 3.3 Notice Items                                          | 10        |
| <b>4. Specifications and Optional Parts</b>               | <b>13</b> |
| 4.1 Specifications                                        | 13        |
| 4.2 Products Series Introduction                          | 16        |
| 4.2.1 SINUS VEGA Models                                   | 16        |
| 4.2.2 Ordering information of SINUS VEGA series           | 17        |
| 4.2.3 Size                                                | 17        |
| 4.2.4 Protective cover                                    | 19        |
| 4.2.5 LED Keypad Display Unit Size                        | 19        |
| 4.2.6 Optional Parts                                      | 20        |
| 4.2.7 Braking Resistor and Recommendation of Braking Unit | 21        |
| <b>5. Installation and wiring</b>                         | <b>23</b> |
| 5.1 Installation                                          | 23        |
| 5.1.1 EMC Compliance Installation                         | 24        |
| 5.1.2 Noise Suppression                                   | 27        |
| 5.1.3 Using Surge Suppressor                              | 28        |
| 5.1.4 Leakage Current                                     | 28        |
| 5.1.5 Applications of Power Filter                        | 29        |
| 5.1.6 AC Line Reactor Applications                        | 30        |
| 5.2 Wiring                                                | 30        |
| 5.2.1 Overview                                            | 31        |
| 5.2.2 Power Terminals                                     | 33        |
| 5.2.3 Control Circuit Wiring                              | 34        |
| 5.2.4 Onsite Wiring Requirements                          | 46        |
| 5.2.5 Earthing                                            | 48        |
| <b>6. Operation Procedures</b>                            | <b>49</b> |
| 6.1 Term Definition                                       | 49        |
| 6.1.1 Inverter Control modes                              | 49        |
| 6.1.2 Frequency Setting Method                            | 49        |

|                                                               |            |
|---------------------------------------------------------------|------------|
| 6.1.3 Inverter Operation Status .....                         | 50         |
| 6.1.4 Operating Mode .....                                    | 50         |
| 6.2 Operation Guide .....                                     | 50         |
| 6.2.1 LED Keypad .....                                        | 50         |
| 6.2.2 Keypad Function Explanation .....                       | 51         |
| 6.2.3 Indicator Description .....                             | 52         |
| 6.2.4 Parameter Setting Method .....                          | 53         |
| 6.2.5 Speed Setting .....                                     | 55         |
| 6.2.6 Locking/Unlocking Keypad .....                          | 55         |
| <b>7. Parameters .....</b>                                    | <b>57</b>  |
| 7.1 Basic Parameters (F0) .....                               | 57         |
| 7.2 Motor Parameter (F1) .....                                | 63         |
| 7.3 Start/Brake Parameter (F2) .....                          | 65         |
| 7.4 Flux vector control parameters (F3) .....                 | 70         |
| 7.5 Current vector control parameter (F4) .....               | 74         |
| 7.6 Multi-function terminal (F5) .....                        | 75         |
| 7.7 Output terminal control parameters (F6) .....             | 86         |
| 7.8 Close-loop control (F7) .....                             | 92         |
| 7.9 MS parameters (F8) .....                                  | 99         |
| 7.10 Enhanced function (F9) .....                             | 100        |
| 7.11 Display Control Parameters (FA) .....                    | 114        |
| 7.12 Communication (FB) .....                                 | 117        |
| 7.13 PLC parameters (FD) .....                                | 117        |
| 7.14 Constant-pressure water supply (FE) .....                | 123        |
| 7.15 Protection (FL) .....                                    | 125        |
| 7.16 Operation Time and Temperature of Cooling Fan (FN) ..... | 131        |
| 7.17 Protection of Parameters (FP) .....                      | 131        |
| 7.18 Factory Default (FU) .....                               | 132        |
| <b>8. Troubleshooting .....</b>                               | <b>133</b> |
| <b>9. Maintenance .....</b>                                   | <b>140</b> |
| 9.1 Routine Maintenance .....                                 | 140        |
| 9.2 Periodic Maintenance .....                                | 140        |
| 9.3 General Inspection: .....                                 | 141        |
| 9.4 Replacing Easily-worn Parts .....                         | 141        |
| 9.5 Storing Inverters .....                                   | 142        |
| 9.6 Warranty .....                                            | 142        |
| <b>Parameter Set .....</b>                                    | <b>144</b> |
| <b>10. Communication Protocol .....</b>                       | <b>192</b> |

---

|                                                           |            |
|-----------------------------------------------------------|------------|
| 10.1 Communication Mode .....                             | 192        |
| 10.2 Protocol Format .....                                | 192        |
| 10.3 Protocol function. ....                              | 193        |
| 10.4 Application .....                                    | 202        |
| 10.5 Scaling .....                                        | 204        |
| <b>Appendix I.....</b>                                    | <b>205</b> |
| Closed-loop tension speed control .....                   | 205        |
| Closed-loop tension speed control with feed-forward ..... | 205        |

## 1. Preface

Thank you for using SINUS VEGA series inverter made by SANTERNO

SINUS VEGA series satisfies high performance requirements by using a unique control method to achieve high torque, high accuracy and wide speed-adjusting range. Its anti-tripping function and capabilities of adapting severe power network, temperature, humidity, and dusty environment exceeds those of similar products made by other companies, which improves the products reliability noticeably.

SINUS VEGA considers customers' needs and combines general purpose function and industrial-oriented function. It features PI control, simple PLC, flexible I/O terminals and pulse frequency setting. You can select whether to save the parameters upon power off or stop, bind frequency setting channel with command channel, zero frequency return difference zero frequency hysteresis, main and auxiliary frequency setting, traverse operation, length control, etc. It is an integral, cost-effective and highly reliable solution for manufacture in the related fields.

SINUS VEGA series can satisfy the customers' requirements on low noise and EMI by using optimized PWM technology and EMC design.

This manual provides information on installation, wiring, parameters setting, trouble-shooting, and routine maintenance. In order to ensure the correct installation and operation of the inverter, please read this manual carefully before using and keep it in a safe place.

## **2. Inspection**

Don't install or use any inverter that is damaged or have fault parts otherwise may cause injury.

Check the following items when unpacking the inverter.

1. Ensure there is operation manual and warranty cards in the packing box.
2. Inspect the entire exterior of inverter to ensure there are no scratches or other damaged caused by transportation.
3. Check the nameplate and ensure it is what you ordered.
4. Ensure the optional parts are what you need if you have ordered any optional parts.

Please contact the local agent if there is any damage in the inverter or the optional parts.

### 3. Safety precautions

#### 3.1 Safety definition

In this manual, the safety precautions are sorted to “Danger” or “Caution”



**Operations without following instructions can cause personal injury or death.**



**Operation without following instructions can cause personal injury or damage to product or other equipment.**

#### 3.2 Safety items

**Before installation:**



1. Please don't use the inverter if being scathed or loss of parts!
2. Please use the insulating motor upwards B class; otherwise it will result in death or serious injury on account of getting an electric shock!

**When installation:**



Please install the inverter on the fireproofing material (such as metal) to prevent fire!



1. When you need to install two or more inverters in one cabinet, cooling fans should be provided to make sure that the ambient temperature is lower than 45°C. Otherwise it could cause fire or damage to the device.
2. No wires head or screws fall into the inverter!

**When wiring:**



1. Only qualified personnel shall wire the inverter!
2. Inverter and power must be comparted by the breaker; otherwise the fire will be caused!

3. Never wire the inverter unless the input AC is totally disconnected!
4. The ground terminal must be properly earthed to reduce electrical accident!

 CAUTION

1. Connect input terminals(R,S,T) and output terminals(U,V,W) correctly. Otherwise it will cause damage the inside part of inverter!
2. Make sure that the wiring according with EMC requirements and safety standards in the region, the wire diameter used reference the manual suggested; otherwise it will cause an accident!
3. Brake resistor cannot be directly connected between  $\pm$ DC bus+ and  $\pm$ DC bus- terminals, or it may cause a fire!

**Before power-on:**

 DANGER

1. Please confirm whether the power and voltage level is consistent with the rated voltage of the inverter, input and output wiring position is correct or not, and pay attention to check whether there are short-circuit in the external circuit phenomenon, ensure the line is fastened. Otherwise the inverter may cause damage!
2. Install the cover before power-on, in order to reduce the danger of electric shock!

 CAUTION

1. Inverters do not need to do pressure test, factory products have made this test, and otherwise it may cause an accident!
2. All the external parts are connected exactly in accordance with this manual, or it may cause an accident!

**After power-on:**

 DANGER

1. Do not open the cover after power-on, otherwise there is a risk of electric shock!
2. Do not wire and operate the inverter with wet hands, otherwise there is a risk of electric shock!



3. Do not touch inverter terminals (including the control terminals), otherwise there is a risk of electric shock!
4. At the beginning of power-on, the inverter can carry out safety testing for external strong electric circuit automatically, at this time, please do not touch U,V,W terminals or motor terminals, otherwise there is a risk of electric shock!



1. If you need parameter identification, please note that the risk of injuries in motor rotation, otherwise it may cause an accident!
2. Please do not arbitrarily change the parameters of inverter manufactures; otherwise it may result in equipment damage!

### **Operating status:**



1. When the user selects the function re-starting, please do not stay close to the mechanical equipment, otherwise it may cause personal injury!
2. Do not touch the radiator, otherwise it may cause burn!
3. Only qualified personnel shall detect the signal, otherwise it may cause personal injury or equipment damage!



1. When the inverter is running, please avoid the sundries fall into the device, otherwise it would cause equipment damage!
2. Please do not use the method of contactor on and off to control the inverter, start-stop, otherwise it would cause equipment damage!

### **When maintaining:**



1. Never service and maintain inverter with electrification, otherwise it may cause injury or electric shock!
2. Ensure the inverter's CHARGE light turns off before the maintenance and repair of the inverter, otherwise the residual charge on the capacitor may cause

personal injury!

3. Only trained personnel shall operate and maintain this equipment, otherwise it will cause personal injury or equipment damage!

### **3.3 Notice Items**

1. Insulation of Motors

Before using the inverter, the insulation of motors must be checked, especially, if it is used for the first time or if it has been stored for a long time. This is to reduce the risk of the inverter from being damaged by the poor insulation of the motor winding. Please use 500V insulation tester to measure the insulation resistance. It should not be less 5MΩ.

2. Thermal protection of the motor

If the selection of motor and rated capacity of the inverter does not match, especially when rated power of the inverter is greater than rated power of the motor, be sure to adjust the motor protection-related parameters in the inverter or pre-installed in the motor thermal relay for motor protection.

3. Working above power frequency

The inverter can provide 0Hz-60Hz output frequency, if the customers need to run at 50Hz or above, please consider the affordability of mechanical devices.

4. The vibration of mechanical devices

When the output frequency to achieve certain values of the inverter, you may encounter a mechanical resonance point of the load devices. It can be avoided by setting the parameters of the frequency jump in inverter.

5. Regarding motor heat and noise

Because the output voltage of the inverter is the PWM wave, it contains some harmonics wave, Therefore, there will be some increase in temperature、noise、libration in motor and Work-frequency.

6. Varistors for Surge Protection or Capacity Used to improve the Power Factor

Don't connect any varistors or capacitors to the output terminals of the inverter. Because the inverter's output voltage waveform is pulse wave, otherwise, it may cause tripping or damage to components.

7. If circuit breaker or contactor needs to be connected between the inverter and the motor, be sure to operate these circuit breakers or contactor when the inverter has no output to avoid damaging of the inverter. Otherwise it may cause damage to the inverter module.

8. Using outside rated voltage

The inverter is not suitable to be used out of the specified range of operating voltage. If needed, please use suitable voltage regulation device.

9. Three-phase input change to Two-phase input

Don't permit of changing three-phase inverter as two-phase to be used, or it will result in failure or damage to inverter.

10. Protection against lightning strike

There are transient surge suppressors inside the inverter that protect it against lightning strike.

11. Derating due to Altitude

Derating must be considered when the inverter is installed at high altitude, greater than 1000m. This is because the cooling effect of the inverter is less effective in the thin air. For details, please contact us.

12. Some special usages

If the customers need to use the wiring diagram that the manual did not mention , such as the common DC bus, please contact us.

13. Disposing Unwanted inverters

1) The capacitors may explode when they are burnt.

2) Poisonous gas may be generated when the plastic parts like front covers are burns.

3) Please dispose the inverter as industrial waste.

14. Adaptive motor

1) Standard adaptive motor for 4 grade Squirrel-cage asynchronous induction motor. If it is not above motor that may select the inverter according to rated current of motor. If you need to inverter permanent magnet synchronous motor, please ask for support.

2) The cooling fan of non-inverter motor and the rotor axis is a coaxial connection, the effect of fan cooling is poor when the speed decreases, therefore, should be retrofitted with exhaust fan or replace for the inverter motor in the motor overheat occasion.

3) The inverter has built-in standard parameters of adaptive motor, according to the actual situation, Motor parameter identification needs to be done or personality default value in order to be compatible with the actual value, otherwise it will affect the running results and protection performance.

4) If the short-circuit occurred in the cable or the internal motor will cause the inverter alarm, and even deep-fried machine. When the motor and cable just installed, please first conduct insulation short-circuit tests, routine maintenance is also required to conduct this test regularly.

**Before using, please read this manual thoroughly to ensure proper usage. Keep this manual at an easily accessible place so that can refer anytime as necessary.**

## 4. Specifications and Optional Parts

### 4.1 Specifications

Table2-1 SINUS VEGA Specifications

| Item                 |                                         | Description                                                                                                                                                                |
|----------------------|-----------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Input                | Rated voltage;<br>Frequency             | SINUS VEGA 4T: 380V~440V; 50Hz/60Hz three phase                                                                                                                            |
|                      | Permissible<br>fluctuation<br>range     | Continuous fluctuation range $\leq\pm 10\%$ , Short time fluctuation range $\leq -15\% \sim +10\%$ ;<br>Voltage unbalance range $\leq 3\%$ ; Frequency $\leq 5\%$          |
| Output               | Rated voltage                           | SINUS VEGA 4T: 0~380V/440V                                                                                                                                                 |
|                      | Frequency                               | 0Hz~650Hz                                                                                                                                                                  |
|                      | Over load<br>ability                    | Heavy Duty: 150% rated current for 1 minute, 180% rated current for 3s/1s (380V/220V series), 200% rated current for 0.5s;<br>Normal Duty: 120% rated current for 1 minute |
| Control<br>functions | Modulation<br>mode                      | Flux vector PWM modulation                                                                                                                                                 |
|                      | Speed range                             | 1: 100                                                                                                                                                                     |
|                      | Starting torque                         | 180% rated torque at 0.5Hz                                                                                                                                                 |
|                      | Accuracy of<br>speed at steady<br>state | $\leq \pm 0.5\%$ rated synchronous speed                                                                                                                                   |
|                      | Torque boost                            | Auto torque boost, Manual torque boost                                                                                                                                     |
|                      | Acc/Dec curve                           | Linear、S curve; 4 Acc/Dec time;<br>Unit(minute/second), 60hours at most                                                                                                    |
|                      | Jog                                     | Jog frequency: 0.10-60.00Hz; Acc/Dec time: 0.1-60.0s.<br>Jog interval adjustable                                                                                           |
|                      | Multi-speed<br>operation                | Seven sections of frequency. Able to achieve through the built-in PLC or terminals.                                                                                        |
|                      | Closed-loop<br>control                  | Analog closed-loop, speed closed-loop control                                                                                                                              |
|                      | Auto energy<br>saving<br>operation      | Voltage output is optimized automatically according to the load condition to perform energy-saving operation.                                                              |
|                      | Auto voltage<br>regulation              | Constant output voltage even if electric network voltage fluctuates                                                                                                        |

| Item                               |                                                  |                                                                                                                                                   |
|------------------------------------|--------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
|                                    | Auto carrier-wave regulation                     | Adjust the carrier frequency automatically according to the load characteristics;                                                                 |
| Customized and operating functions | Traverse for textile motor                       | Traverse control, central traverse adjustable                                                                                                     |
|                                    | Set length control                               | When reaching set length, the inverter will stop                                                                                                  |
|                                    | Constant-pressure water supply                   | Constant-pressure water supply with PID control                                                                                                   |
|                                    | Tone selection                                   | Set the tone of the motor when it is running                                                                                                      |
|                                    | Immunity to transient power failure              | The inverter gives output even if power failure occurs                                                                                            |
|                                    | Channel binding                                  | Command channel can bind with frequency. Setting channel and switched synchronizingly                                                             |
|                                    | Methods of inputting commands                    | Via keypad panel、terminals and serial port                                                                                                        |
|                                    | Methods of setting up frequency                  | Digital setting、VCI、CCI、pulse setting、serial port                                                                                                 |
|                                    | Auxiliary frequency                              | Flexible auxiliary frequency tuning、frequency synthesis                                                                                           |
|                                    | Pulse output terminal                            | 0~50kHz pulse signal output . Signals can be reference frequency and output frequency                                                             |
|                                    | Analog output terminals                          | 2 analog outputs of 0/4~20mA and 0~10V(selectable). Be able to output signals like reference frequency and output frequency.                      |
| Water Supply Special Functions     | Constant-pressure water supply special functions | Smart constant-pressure water supply control system, including sleep, wake-up, pressure feedback off-line detection, multi-pressure setting, etc. |
|                                    | Work Mode Selection                              | Multi water supply mode selection                                                                                                                 |
|                                    | Closed-loop setting                              | Setting by digital voltage / analog voltage / analog current / communication                                                                      |
|                                    | Multi-pressure setting                           | Up to 6 steps of pressure commands setting per day                                                                                                |
|                                    | Sleep/wake-up control                            | Complete sleep/wake-up of pump automatically                                                                                                      |

| Item                |                       |                                                                                                                          |
|---------------------|-----------------------|--------------------------------------------------------------------------------------------------------------------------|
| Control panel       | LED keypad            | Able to show many parameters, such as: frequency setting, output frequency, output voltage, etc.                         |
|                     | Keypad lock           | Total lock or partially lock, in order to avoid misoperation                                                             |
| Protection function |                       | Phase loss failure, Over/Under current, Over/Under voltage protection, Overheat and overload protection                  |
| Environment         | Operating environment | In-door,                                                                                                                 |
|                     | Altitude              | Less than 1000m                                                                                                          |
|                     | Ambient temperature   | -10℃ ~ +40℃, derating is required from 40~50℃; Increase every 1 above 40℃, derating 2%, highest temperature allowed: 50℃ |
|                     | Humidity              | Less than 95% RH, no condensing                                                                                          |
|                     | Vibration             | Less than 5.9m/s <sup>2</sup> (0.6g)                                                                                     |
|                     | Storage temperature   | -40℃ ~ +70℃                                                                                                              |
| Enclosure           | Protection level      | IP20                                                                                                                     |
|                     | Cooling               | Fan cooling                                                                                                              |
| Mounting mode       |                       | Mounted in a cabinet                                                                                                     |

## 4.2 Products Series Introduction

### 4.2.1 SINUS VEGA Models

#### SINUS VEGA 4T

Applicable motor power with power supply 380 ÷ 440Vac

Table2-2 Inverter series

| Model              | Inom | Imax | Applicable motorpower |     |     | Applicable motorpower |     |     |
|--------------------|------|------|-----------------------|-----|-----|-----------------------|-----|-----|
|                    |      |      | NORMAL DUTY           |     |     | HEAVY DUTY            |     |     |
|                    |      |      | kW                    | H   | A   | kW                    | H   | A   |
| SINUS VEGA 0002 4T | 2.3  | 3.5  | 0.75                  | 1   | 2.3 | 0.75                  | 1   | 2.3 |
| SINUS VEGA 0003 4T | 3.7  | 5.5  | 1.5                   | 2   | 3.7 | 1.5                   | 2   | 3.7 |
| SINUS VEGA 0004 4T | 5    | 7.5  | 2.2                   | 3   | 5   | 2.2                   | 3   | 5   |
| SINUS VEGA 0005 4T | 9    | 14   | 4                     | 5.5 | 9   | 4                     | 5.5 | 9   |
| SINUS VEGA 0007 4T | 17   | 20   | 7.5                   | 10  | 17  | 5.5                   | 7.5 | 13  |
| SINUS VEGA 0011 4T | 25   | 26   | 11                    | 15  | 25  | 7.5                   | 10  | 17  |
| SINUS VEGA 0015 4T | 32   | 38   | 15                    | 20  | 32  | 11                    | 15  | 25  |
| SINUS VEGA 0018 4T | 37   | 48   | 18.5                  | 25  | 37  | 15                    | 20  | 32  |
| SINUS VEGA 0022 4T | 45   | 56   | 22                    | 30  | 45  | 18.5                  | 25  | 37  |
| SINUS VEGA 0030 4T | 60   | 68   | 30                    | 40  | 60  | 22                    | 30  | 45  |
| SINUS VEGA 0037 4T | 75   | 90   | 37                    | 50  | 75  | 30                    | 40  | 60  |
| SINUS VEGA 0045 4T | 90   | 113  | 45                    | 60  | 90  | 37                    | 50  | 75  |
| SINUS VEGA 0055 4T | 110  | 135  | 55                    | 75  | 110 | 45                    | 60  | 90  |
| SINUS VEGA 0075 4T | 152  | 165  | 75                    | 100 | 152 | 55                    | 75  | 110 |
| SINUS VEGA 0090 4T | 176  | 228  | 90                    | 125 | 176 | 75                    | 100 | 152 |
| SINUS VEGA 0110 4T | 210  | 264  | 110                   | 150 | 210 | 90                    | 125 | 176 |
| SINUS VEGA 0132 4T | 260  | 315  | 132                   | 180 | 260 | 110                   | 150 | 210 |
| SINUS VEGA 0160 4T | 305  | 390  | 160                   | 220 | 305 | 132                   | 180 | 260 |

**NORMAL DUTY:** Overload 120% rated current for 1 minute- for applications which use self-ventilated induction motors and require a low overload capability (e.g. fans, pumps)

**HEAVY DUTY:** Overload 150% rated current for 1 minute- Overload 180% rated current for 3 Sec Overload 200% rated current for 0.5 Sec, for constant torque applications which require a high overload capability (e.g. cranes, hoists)



## 4.2.2 Ordering information of SINUS VEGA series

Please refer to Figure2-1a and Figure 2-1 b.





Table2-1a Explanations of inverter models


| SINUS VEGA 0011 4T                                                                                                                                                     |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| INPUT: AC3PH 380~440V +10/-15% 50/60Hz                                                                                                                                 |
| OUTPUT: AC3PH 0~440V 0~600Hz                                                                                                                                           |
| Normal Duty: 11kW/15HP/25A                                                                                                                                             |
| Heavy Duty: 7.5kW/10HP/17A                                                                                                                                             |
| K10/IP20Imax: 26A/Inom: 25A                                                                                                                                            |
|  <b>SANTERNO</b><br>40026 Imola (Bologna) – Italy<br>www.santerno.com                 |
| <br> |
| S/N:                                                                                                                                                                   |

Table2-1b SINUS VEGA series nameplate


## 4.2.3 Size

Please refer to Figure 2-2 and Table 2-3.






K10-15



K20-25



K30-35

Figure2-2 SINUS VEGA series inverter size

Table 2-3 Dimensions of SINUS VEGA series (mm)

| Size | W (mm) | H (mm) | Mounting hole | D (mm) | Weight (kg) |
|------|--------|--------|---------------|--------|-------------|
| K00  | 105    | 180    | 5             | 135    | 1.8         |
| K05  | 140    | 215    | 5.5           | 175    | 2.5         |
| K10  | 157    | 262    | 5.5           | 181    | 5           |
| K15  | 198    | 305    | 5.5           | 181    | 8           |
| K20  | 276    | 438    | 7             | 220    | 18          |
| K25  | 395    | 589    | 10            | 231    | 45          |
| K30  | 489    | 759    | 12            | 298    | 75          |
| K35  | 539    | 889    | 12            | 370    | 125         |


#### 4.2.4 Protective cover




Notice: For ventilation, try not to use protective cover, unless there is a need, so that you can extend the inverter's life.

#### 4.2.5 LED Keypad Display Unit Size

Through it, operation and configuration of the inverter can be done. Please refer to its size and configuration in Figure 2-3.



Keypad dimensions of SINUS VEGA 0002 4T ~ 0004 4T



Keypad dimensions of SINUS VEGA 0005 4T~ 0160 4T

Figure2-3 Keypad display unit

#### 4.2.6 Optional Parts

You may order the optional parts below from our company.

| Part name            | Applicable range      | Specification          | Remarks                             |
|----------------------|-----------------------|------------------------|-------------------------------------|
| Braking resistor     | Pls refer to tale 2-4 | Pls refer to table 2-4 |                                     |
| Keypad connect board | 0.4KW~4.0KW optional  | -                      | Ethernet connection will be enabled |

| Part name              | Applicable range     | Specification | Remarks                                                                                                                     |
|------------------------|----------------------|---------------|-----------------------------------------------------------------------------------------------------------------------------|
| Keypad tray            | Above 5.5KW optional | 74.7.141      | dimension                                                                                                                   |
| Keypad extension cable | 0.4KW~4.0KW optional | 1.5m          | Flat cable                                                                                                                  |
|                        | 0.4KW~160KW optional | 2m、3m         | Internet cable ; 0.4KW~4.0KW keypad connection board is required if you want to use internet cable to extend the connection |
| Basement               | 132KW~160KW optional | 539*370*485   | 132KW~160KW basement is applicable for both cabinet and wall type interers                                                  |
| Direct current reactor | 132KW~160KW optional | -             | -                                                                                                                           |

#### 4.2.7 Braking Resistor and Recommendation of Braking Unit

SINUS VEGA series inverter is equipped with braking unit. If there is a need for energy-consuming braking, please select a braking resistor in Table2-4; please refer the wiring of braking resistor and the inverter to Figure2-4. The wire specifications are listed in Table2-4.

Table2-4 Braking Resistor and Recommendation of Braking Unit

| Model              | Suggested value of resistance | Suggested power | Suggested model of braking unit | Remark                                              |
|--------------------|-------------------------------|-----------------|---------------------------------|-----------------------------------------------------|
| SINUS VEGA 0002 4T | 250-350 $\Omega$              | 100W            | Built-in standard parts         | Nospecial instructions                              |
| SINUS VEGA 0003 4T | 200-300 $\Omega$              | 200W            | Built-in standard parts         | Match Proper Motor                                  |
| SINUS VEGA 0004 4T | 100-250 $\Omega$              | 250W            |                                 |                                                     |
| SINUS VEGA 0005 4T | 100-150 $\Omega$              | 300W            |                                 |                                                     |
| SINUS VEGA 0007 4T | 80-100 $\Omega$               | 500W            |                                 |                                                     |
| SINUS VEGA 0011 4T | 60-80 $\Omega$                | 700W            |                                 |                                                     |
| SINUS VEGA 0015 4T | 40-50 $\Omega$                | 1KW             |                                 |                                                     |
| SINUS VEGA 0018 4T | 30-40 $\Omega$                | 1.5KW           |                                 |                                                     |
| SINUS VEGA 0022 4T | 25-30 $\Omega$                | 2KW             | Built-in optional parts         | Add $\downarrow$ B $\downarrow$ at the end of model |
| SINUS VEGA 0030 4T | 20-25 $\Omega$                | 2.5KW           |                                 |                                                     |
| SINUS VEGA 0037 4T | 15-20 $\Omega$                | 3KW             |                                 |                                                     |
| SINUS VEGA 0045 4T | 15-20 $\Omega$                | 3.5KW           | Built-in optional parts         | Add $\downarrow$ B $\downarrow$ at the end of model |
| SINUS VEGA 0055 4T | 10-15 $\Omega$                | 4.5KW           |                                 |                                                     |

| Model              | Suggested value of resistance | Suggested power | Suggested model of braking unit | Remark         |
|--------------------|-------------------------------|-----------------|---------------------------------|----------------|
| SINUS VEGA 0075 4T | 10-15 $\Omega$                | 5.5KW           |                                 |                |
| SINUS VEGA 0090 4T | 8~10 $\Omega$                 | 7.5 KW          | BU4R150                         | optional parts |
| SINUS VEGA 0110 4T | 8~10 $\Omega$                 | 9.0KW           |                                 |                |
| SINUS VEGA 0132 4T | 6~8 $\Omega$                  | 11.0KW          |                                 |                |
| SINUS VEGA 0160 4T | 6~8 $\Omega$                  | 13.5KW          | BU4R250                         | optional parts |

P.S: the calculation method of braking resistance:

When braking is enabled, almost all renewable energy have been consumed by the braking resistor, please follow the following formula:

$$U \cdot U / R = P_b$$

In this formula: U means the braking voltage of the system( The value of U may differ from each system, I.e, 380Vac system, U is 700V generally.

$P_b$  is the braking power

Power selection for braking resistor

Theoretically, the braking resistor's power is the same as the braking power, however by taking the 70% derate into consideration, you can use the following formula to calculate the braking resistor's power:

$$0.7 \cdot P_r = P_b \cdot D$$

$P_r$ --power of the braking resistor

D--braking frequency

Braking frequency values for standard elevator and winder applications:

| Applications         | Elevator | Winding and unwinding | Centrifuge machine | Occasionally braking load | General applications |
|----------------------|----------|-----------------------|--------------------|---------------------------|----------------------|
| Braking frequency(D) | 20%~30%  | 20 ~30%               | 50%~60%            | 5%                        | 10%                  |

The above Table 2-4 is a guide reference only, users can choose different braking resistance and power according to each application. However, please be remembered that the braking resistance shouldn't be less than the above recommended value, but the power is allowed to be exceed than the recommend numbers. Users need to select the right braking resistors according to each application case, there are quite a few aspects which will determine your choice of the resistors, such as the power of the motor, system inertia, deceleration time, the energy of the load etc. The greater the system inertia is, the shorter the required deceleration time is required, then the braking frequency will be increased, which means you need to choose a bigger power braking resistor with a lower braking resistance.

## 5. Installation and wiring

### 5.1 Installation

Please mount the inverter vertically indoors, with good ventilative conditions. When selecting mounting environment, the followings should be taken into account:

Ambient temperature should be within the range of  $-10^{\circ}\text{C} \sim 40^{\circ}\text{C}$ . If the temperature is higher than  $40^{\circ}\text{C}$ , the inverter should be derated and forced heat dissipation is required.

Humidity should be lower than 95%, non-condensing;

Mount in the location where vibration is less than  $5.9\text{m/s}^2$  ( $0.6g$ ) ;

Mount in the location free of direct sunlight, dust, metal powder, corrosive gas or combustible gas;

If there are any special requirements for installation, please contact us for clarifications.

The requirements on mounting space and clearance are shown in figure 3-1 and 3-2; When two inverters are mounted one on top the other, an air flow diverting plate should be fixed in between as shown in figure 3-3.




Figure 3-1 Installation clearance




Figure3-2 Installation of several inverters      Figure3-3 Installation of one on top theother

### 5.1.1 EMC Compliance Installation

In a traction system composed of a inverter and a motor, if the inverter, controllers and transducer are installed in one cabinet, the disturbance they generate should be depressed at the connection points, therefore, a noise filter and inrush reactor should be installed in the cabinet, so that EMC requirement is met inside it.

The inverter is usually installed in a metal cabinet, the instruments outside the metal cabinet is shielded and may be disturbed lightly. The cables are the main EMI source, if you connect the cables in according to the manual, the EMI can be suppressed effectively.

In system design phase, to reduce EMI, insulating the noise source and use the noise subber are the best choice, but the choice is considerable. If there are a few sensitive devices on site, just install the power line filter beside them is enough note that the inverter and the contactor are noise source, and the automatic devices encoder and conductor are sensible to them.。

Divide the system into several EMC parts; refer to figure 3-4.

#### **Note:**

1. After installing EMI filter and AC reactor, the inverter can satisfy IEC 61800—3 standard.
2. The input/output filter should be installed close to the inverter as possible.






Figure3-4 Recommended System Layout:

Area I : Should be used to install transformers for control power supply, control system and sensor.

Area II : should be used for interface of signal and control cables with good immunity level.

Area III: Should be used to install noise generating devices such as input reactor, inverter, brake unit and contactor.

Area IV: should be used to install output noise filter.

Area V : should be used to install power source and cables connecting the RFI filter.

Area VI: should be used to install the motor and motor cables.

Areas should be isolated in space, so that electro-magnetic decoupling effect can be achieved. The shortest distance between areas should be 20cm.

Earthing bars should be used for decoupling among areas; the cables from different area should be placed in different tubes.

The filter should be installed at the interfaces between different areas if necessary. Bus cable (such as RS485) and signal cable must be shielded.




Figure 3-5 Installation of the inverter

## 5.1.2 Noise Suppression

The noise generated by the inverter may disturb the equipment nearby; the degree of disturbance is depend on the inverter system, immunity of the equipment, wire connections, installation clearance and earthing methods.

| Noise emission paths                                                                                                                                                                                                 | Actions to reduce the noise                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| If the external equipment shares the same AC supply with the inverter, the inverter's noise may be transmitted along its input power supply cables, which may cause nuisance tripping to other external equipment. . | Install noise filter at the input side of the inverter, and use an isolation transformer or line filter to prevent the noise from disturbing the external equipment                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| If the signal cables of measuring meters, radio equipment and sensors are installed in a cabinet together with the inverter, these equipment cables will be easily disturbed.                                        | <p>1) The equipment and the signal cables should be as far away as possible from the inverter. The signal cables should be shielded and the shielding layer should be grounded. The signal cables should be placed inside a metal tube and should be located as far away as possible from the input/output cables of the inverter. If the signal cables must cross over the power cables, they should be placed at right angle to one another.</p> <p>2) Install radio noise filter and linear noise filter (ferrite common-mode choke) at the input and output sides of the inverter to suppress the emission noise of power lines.</p> <p>3) Motor cables should be placed in a tube thicker than 2mm or buried in a cement conduit. Power cables should be placed inside a metal tube and be grounded by shielding layer (Motor cable should be a 4-core cable, where one core should be connected to the PE of the inverter and another should be connected to the motor's enclosure)</p> |
| If the signal cables are routed in parallel with the power cables or bundle these cables together, the induced electro-magnetic noise and induced ESD noise may disturb the signal cables.                           | Avoid this kind of routing. Other equipment sensible to EMI should also be located as far away as possible from the inverter. The signal cables should be placed inside a metal tube and should be placed as far away as possible from the input/output cables of the inverter. The signal cables and power cables should be shielded cables. EMC interference will be further reduced if they could be placed inside metal tubes. The clearance between the metal tubes should be at least 20cm.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

Table3-1 Actions to reduce the noise

### 5.1.3 Using Surge Suppressor

The device such as relay, contactor and electro-magnetic braking kit, which may generate great noises, should be installed with surge suppressor even if installed outside of the device cabinet.




Figure3-6 Installation of Relay, contactor and electro-magnetic braking kit

### 5.1.4 Leakage Current

Leakage current may flow through the inverter's input and output capacitors and the motor's capacitor. The leakage current value is dependent on the distributed capacitance and carrier wave frequency. The leakage current includes ground leakage current and the leakage current between lines .

#### Ground leakage current

The ground leakage current not only flows into the inverter's system, but also into other equipment via earthing cables. It may cause leakage current circuit breaker and relays to be falsely activated. The higher the inverter's carrier wave frequency, the higher the leakage current, and also, the longer the motor's cable, the greater is the leakage current.

#### Suppressing methods:

Reduce the carrier wave frequency, but the motor noise may be higher;

Motor cables should be as short as possible;

The inverter and other equipment should use leakage current circuit breaker designed for protecting the products against high-order harmonic/surge leakage current .

#### Leakage current between lines

The line leakage current flowing outside though the distributed capacitor of the inverter may false trigger the thermal relay, especially for the inverter of which power rating is less than 7.5KW. If the cable is longer than 50m, the ratio of leakage current to motor rated current may increase to a level that can cause external thermal relay to trigger unexpectedly.

Suppression methods:

Reduce the carrier wave frequency, but the motor audible noise is higher;

Install reactor at the output side of the inverter.

In order to protect the motor reliably, it is recommended to use a temperature sensor to detect the motor's temperature, and use the inverter's over-load protection device (electronic thermal relay) instead of an external thermal relay.

### **5.1.5 Applications of Power Filter**

Power source filter should be used in the equipment that may generate strong EMI or the equipment that is sensitive to EMI. The power source filter should be a low pass filter through which only 50Hz current can flow and high frequency current is rejected.

The power filter ensures the equipment can satisfy the conducting emission and conducting sensitivity in EMC standard. It can also suppress the radiated emission of the equipment

It can prevent the EMI generated by the equipment from entering power cable, and also prevent the EMI generated by the power cable from entering the equipment.

Common mistakes in using power line filter

Power cable is too long

The filter inside the cabinet should be located near to the input power source. The length of the cables should be as short as possible.

The input and output cables of the AC supply filter are too close

The distance between input and output cables of the filter should be as far apart as possible, otherwise the high frequency noise may be coupled between the cables and bypass the filter. Thus, the filtering effect becomes ineffective.

Bad earthing of filter.

The filter enclosure must be connected properly to the metal casing of the inverter. In order to be earthed well, a special earthing terminal on the filter's enclosure should be used. If you use one cable to connect the filter to the case, the earthing is useless due to high frequency interference. When the frequency is high, so too is the impedance of cable, hence there is little bypass effect.

The filter should be mounted in the enclosure of equipment. Ensure to clear away the insulation paint between the filter case and the enclosure for good earth contact.

### 5.1.6 AC Line Reactor Applications

#### Input AC Line Reactor:

A line reactor should be used if the distortion of power network is severe or the input current harmonic level is high even after a DC reactor has been connected to the inverter. It can also be used to improve the AC input power factor of the inverter.

#### Output AC Line Reactor:

When the cables from the inverter to motor are longer than 80m, multi-strand cables and an AC line reactor should be used to suppress the high frequency harmonics. Thus, the motor insulation is protected. At the same time, leakage current and unexpected trigger are reduced.

## 5.2 Wiring

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div data-bbox="509 697 599 723" data-label="Image"></div> <ul style="list-style-type: none"> <li>·Wiring can only be done after the Variable Speed Inverter's AC power is disconnected; all the LEDs on the operation panel are off and after waiting for at least 10 minutes. Then, you can remove the panel.</li> <li>·Wiring job can only be done after confirming the Charge indicator inside the inverter has extinguished and the voltage between main circuit power terminals + and - is below DC36V.</li> <li>·Wire connections can only be done by trained and authorize personnel.</li> <li>·For the sake of safety, the inverter and motor must be earthedbecause there is leakage current inside the inverter; Check the wiring carefully before connecting emergency stopping or safety circuits.</li> <li>·Check the Variable Speed Inverter's voltage level before supplying power to it; otherwise human injuring or equipment damage may happen.</li> </ul> |
| <div data-bbox="524 1076 588 1099" data-label="Image"></div> <ul style="list-style-type: none"> <li>·Check whether the inverter's rated input voltage is in compliant with the AC supply voltage before using.</li> <li>·Dielectric strength test of the inverter has been done in factory and the user needs not do it again</li> <li>·Refer to chapter 2 on how to connect braking resistor or braking.</li> <li>·It is prohibited to connect the AC supply cables to the inverter's terminals U, V and W.</li> <li>·Grounding cables should be copper cables with cross-sectional area bigger than <math>2.5 \text{ mm}^2</math>, and the grounding resistance should be less than <math>10\Omega</math>.</li> <li>·For the sake of safety, the inverter and motor must be earthed because there is</li> </ul>                                                                                                                                                             |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p style="text-align: center;"> CAUTION</p> <ul style="list-style-type: none"> <li>• The control circuits of SINUS VEGA are isolated from the power circuits in the inverter by basic insulation (single insulation) only. If the control cables are to connect to external control circuit exposing to human contact, an extra insulating layer, rated for use at the AC supply voltage of the load, must be applied.</li> <li>• If the control circuits are to connect to other circuits classified as Safety Extra Low Voltage (SELV), e.g. connecting the RS485 port of the inverter to a personal computer through an adapter, an additional isolating barrier must be included in order to maintain the SELV classification.</li> </ul> |
| <p style="text-align: center;"> CAUTION</p> <ul style="list-style-type: none"> <li>• The control terminals of the inverter are of ELV (Extra Low Voltage) circuit. Do not touch them once energized;</li> <li>• If the external device has touchable terminals of SELV (Safety Extra Low Voltage) circuit. Remember to connect isolating protections in between. Otherwise, the SELV circuit will be degraded to ELV circuit;;</li> <li>• When connecting the inverter with PC, do choose RS485/232 adapters with isolating protections that measure up to safety requirements.。</li> </ul>                                                                                                                                                   |

## 5.2.1 Overview

You should finish the power circuit and control circuit wiring。

First, open the front door, and then you will see the power terminals and control terminals

For different models of the inverter, the power terminals layout is different, which is described in details as below.

(Jumpers: CN is for inverters 4.0KW and below, SW(or J) is for inverters 5.5kw~160kw)

Beneath the keypad display unit, there are control terminal strip and jumpers CN4(J2 OR SW2), CN5(J3 OR SW3), CN7(J1 OR SW1), CN14(J4 OR SW4)。

Terminal strip is relay output, analog, digital I/O and communication interfaces. CN4(J2 OR SW2), CN5(J3 OR SW3) and CN7(J1 OR SW1) are jumpers through which the output of voltage or current signal is set, the terminals will be described in details later.

The figure below is the systematic wiring of the inverter




Figure 3-7 Systematic Wiring Diagram

Note:

1. In the above figure,  $\odot$  P is the terminal in power circuit, and  $\odot$  P is the control terminal;
2. Terminal CCI can input voltage or current signal by switching the jumper CN10 on control board;
3. Built-in braking kit is installed and a braking resistor is required to be connected between P (+) and PB;
4. Refer to section 3.2.3 for the using of control terminals;
5. MCCB must be installed at the input side of each inverter in the cabinet;
6. Refer the cable section area and MCCB capacity to Table 3-2.

Table 3-2 Recommended MCCB Capacity and Copper Cable Section Area

| Model              | MCCB<br>Circuit<br>breaker<br>(A) | Power circuit (mm <sup>2</sup> ) |                     |                  |                | Control<br>cable<br>(mm <sup>2</sup> ) |
|--------------------|-----------------------------------|----------------------------------|---------------------|------------------|----------------|----------------------------------------|
|                    |                                   | Input<br>cable                   | Braki<br>ng<br>line | Outpu<br>t cable | Earth<br>cable |                                        |
| SINUS VEGA 0002 4T | 10                                | 1.0                              | 1.0                 | 1.0              | 2.5            | 1.0                                    |
| SINUS VEGA 0003 4T | 16                                | 1.5                              | 1.0                 | 1.5              | 2.5            | 1.0                                    |
| SINUS VEGA 0004 4T | 16                                | 1.5                              | 1.5                 | 1.5              | 2.5            | 1.0                                    |
| SINUS VEGA 0005 4T | 25                                | 2.5                              | 1.5                 | 2.5              | 2.5            | 1.0                                    |
| SINUS VEGA 0007 4T | 32                                | 4.0                              | 2.5                 | 4.0              | 4.0            | 1.0                                    |



| Model              | MCCB<br>Circuit<br>breaker<br>(A) | Power circuit (mm <sup>2</sup> ) |                                                           |                  |                | Control<br>cable<br>(mm <sup>2</sup> ) |
|--------------------|-----------------------------------|----------------------------------|-----------------------------------------------------------|------------------|----------------|----------------------------------------|
|                    |                                   | Input<br>cable                   | Braki<br>ng<br>line                                       | Outpu<br>t cable | Earth<br>cable |                                        |
| SINUS VEGA 0011 4T | 32                                | 4.0                              | 2.5                                                       | 4.0              | 4.0            | 1.0                                    |
| SINUS VEGA 0015 4T | 40                                | 6.0                              | 4.0                                                       | 6.0              | 6.0            | 1.0                                    |
| SINUS VEGA 0018 4T | 63                                | 6.0                              | 4.0                                                       | 6.0              | 6.0            | 1.0                                    |
| SINUS VEGA 0022 4T | 63                                | 10                               | 10                                                        | 10               | 10             | 1.0                                    |
| SINUS VEGA 0030 4T | 80                                | 16                               | 16                                                        | 16               | 16             | 1.0                                    |
| SINUS VEGA 0037 4T | 100                               | 25                               | 25                                                        | 25               | 16             | 1.0                                    |
| SINUS VEGA 0045 4T | 160                               | 25                               | 10                                                        | 25               | 16             | 1.0                                    |
| SINUS VEGA 0055 4T | 200                               | 35                               | 16                                                        | 35               | 16             | 1.0                                    |
| SINUS VEGA 0075 4T | 200                               | 35                               | 25                                                        | 35               | 25             | 1.0                                    |
| SINUS VEGA 0090 4T | 250                               | 70                               | Pls<br>refer<br>to<br>brake<br>resisto<br>r<br>manua<br>l | 70               | 35             | 1.0                                    |
| SINUS VEGA 0110 4T | 310                               | 70                               |                                                           | 70               | 35             | 1.0                                    |
| SINUS VEGA 0132 4T | 400                               | 95                               |                                                           | 95               | 50             | 1.0                                    |
| SINUS VEGA 0160 4T | 400                               | 150                              |                                                           | 150              | 75             | 1.0                                    |

Note:

If the control circuit uses multi-strand cable, the single-core cable section area can be 0.5mm<sup>2</sup>.

## 5.2.2 Power Terminals

1. SINUS VEGA 0002 4T ~ 0005 4T

|   |   |   |   |     |     |    |   |   |   |
|---|---|---|---|-----|-----|----|---|---|---|
| ⊕ | R | S | T | (+) | (-) | PB | U | V | W |
|---|---|---|---|-----|-----|----|---|---|---|

Table 3-4 Definitions of power terminals

| Mark  | Definition                      |
|-------|---------------------------------|
| R、S、T | 3-phase AC input                |
| +、PB  | External braking resistor       |
| +、-   | DC positive, negative bus input |
| U、V、W | 3-phase AC outputs              |
| PE/   | Protective earth                |

2. SINUS VEGA 0007 4T~0018 4T

|   |   |   |    |     |    |     |   |   |   |
|---|---|---|----|-----|----|-----|---|---|---|
| R | S | T | P1 | (+) | PB | (-) | U | V | W |
|---|---|---|----|-----|----|-----|---|---|---|



3. SINUS VEGA 0022 4T ~ 0075 4T

|   |   |   |    |     |    |     |   |   |   |    |
|---|---|---|----|-----|----|-----|---|---|---|----|
| R | S | T | P1 | (+) | PB | (-) | U | V | W | PE |
|---|---|---|----|-----|----|-----|---|---|---|----|

4. SINUS VEGA 0090 4T and above:

Into the terminal  
(at the top of the machine)

|    |   |   |   |
|----|---|---|---|
| PE | R | S | T |
|----|---|---|---|

At the bottom of the  
outlet terminals  
(machine)

|    |   |   |   |    |     |     |
|----|---|---|---|----|-----|-----|
| PE | U | V | W | P1 | (+) | (-) |
|----|---|---|---|----|-----|-----|


Table 3-5 Definitions of power terminals

| Mark     | Definition                                                             |
|----------|------------------------------------------------------------------------|
| R、S、T    | 3-phase AC input                                                       |
| P1、 (+)  | External DC reactor reserved terminals (connect with steel before use) |
| (+) 、 PB | External braking resistor                                              |
| (-)      | DC negative bus input                                                  |
| U、 V、 W  | 3-phase AC outputs                                                     |
| PE       | Protective earth                                                       |

## 5.2.3 Control Circuit Wiring

### Control Terminals and Jumpers

Refer the layout to Figure 3-8. Control terminals functions are listed in Table 3-6, Jumper's functions in 3-7. Be sure to set the jumper and wire the terminals properly. It is recommended to use cable of section area bigger than 1mm<sup>2</sup>.



Up to SINUS VEGA 0055 4T SINUS VEGA 0075 4T and above

Figure 3-8 Layouts of control terminals and jumpers

Table 3-6 Function of control terminals

| Mark      | Function                               |
|-----------|----------------------------------------|
| CN6- CN11 | Analog I/O, digital I/O, relay outputs |

Table 3-7 Jumpers' function

| Mark                | Function&Setting                                                                                   | Default             |
|---------------------|----------------------------------------------------------------------------------------------------|---------------------|
| CN7<br>(J1 OR SW1)  | CCI current/voltage input selection<br>I: 0~20mA current signal<br>V: 0~10V voltage signal         | 0~10V               |
| CN14<br>(J4 OR SW4) | 485 terminal resistor selection: ON: 120Ω terminal resistor, OFF: No terminal resistor.            | No resistor         |
| CN4<br>(J2 OR SW2)  | AO1 current/voltage input selection<br>0/4~20mA: AO1 current signal 0/2~10V:<br>AO1 voltage signal | 0~10V               |
| CN5<br>(J3 OR SW3)  | AO2 current/voltage input selection<br>0/4~20mA: AO2 current signal 0/2~10V: AO2 voltage signal    | 0~10V               |
| J5                  | Y2 selection of pull-up resistor<br>PU: With pull-up resistor<br>OC: Without pull-up resistor      | No Pull-up resistor |

## Jumper usage

CN4(J2 OR SW2)、CN7(J1 OR SW1) or CN5(J3 OR SW3) jumper usage:




Figure a means that 0~10V analog voltage input is selected; Figure b means that 0/4~20mA analog current input is selected.

CN14(J4 OR SW4) jumper usage:




Figure a means that there is a resistor (OFF) ; Figure b means that there is no resistor (ON) .




Figure a means that there is no pull-up resistor (OFF) ; Figure b means that there is a 10K  $\Omega$  resistor (ON)

## Terminal strip layout

The layout is shown below

SINUS VEGAup to 0005 4T terminal strip layout:

|     |     |     |    |    |     |     |     |      |     |      |      |
|-----|-----|-----|----|----|-----|-----|-----|------|-----|------|------|
| TC  | TB  | TA  | Y1 | Y2 | FWD | REV | AO1 | AO2  | VCI | CCI  | GND  |
| COM | PLC | P24 | X1 | X2 | X3  | X4  | X5  | +10V | GND | 485+ | 458- |

SINUS VEGA 0007 4T (and above) terminal strip layout:

|      |      |     |     |     |     |     |     |     |    |     |     |     |     |
|------|------|-----|-----|-----|-----|-----|-----|-----|----|-----|-----|-----|-----|
| 485+ | 485- | GND | AO1 | AO2 | X1  | X2  | X3  | X4  | X5 | COM | 1TA | 1TB | 1TC |
| +10V | VCI  | CCI | GND | P24 | PLC | COM | FWD | REV | Y1 | Y2  | 2TA | 2TB | 2TC |

TA-TB: Normally closed; TA-TC: Normally open

Contact capacity: 250Vac/2A (COS $\phi$ =1) , 250Vac/1A (COS $\phi$ =0.4) , 30Vdc /1A

TA, TB and TC can be defined as multi-functional digital output signals.  
Please refer to Section 5.7

Relay output TA、TB、TC Wiring:

If there are inductive loads, such as: electro-magnetic relay and contactor, surge snubber circuit, e.g. RC circuit, varistor, fly-wheel diode (pay attention to the polarity when used in a DC circuit), should be installed. Note that the leakage current should be less than the current in the contactor or relay. The components in the snubber circuit should be installed near to the relay or contactor coil.

Note :

The “+RS485-” in the above figure means RS485+ and RS485-.

Table 3-8 Terminal function table

| Category      | Terminals | Name                    | Function                                                                                                                                                                                                                         | Specification                                                                                                           |
|---------------|-----------|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| Communication | 485+      | RS485communication port | RS485+                                                                                                                                                                                                                           | Standard RS-485 communication port, please use twisted-pair cable or shielded cable                                     |
|               | 485-      |                         | RS485-                                                                                                                                                                                                                           |                                                                                                                         |
| Analog input  | VCI       | Analog input VCI        | Analog voltage input (reference ground: GND)                                                                                                                                                                                     | Input voltage range:0~10V (input resistance:100kΩ) resolution:1/2000                                                    |
|               | CCI       | Analog input CCI        | Accepting analog voltage/current input.CN7(J1 OR SW1) can select voltage or current input mode, Voltage input mode is the default (Reference ground: GND)                                                                        | Input voltage range:0~10V (input resistance:100kΩ) Input current range:0~20mA (input resistance:500Ω) resolution:1/2000 |
| Analog output | AO1       | Analog output 1         | Be able to output analog voltage/current, (total 12 kinds of signal). Jumper CN4(J2 OR SW2) can select voltage or current input mode. Voltage input mode is the default mode. Refer to F6.03 for details (reference ground: GND) | Output current range: 0/4~20mA Output voltage range: 0/2~10V                                                            |

| Category      | Terminals | Name                                | Function                                                                                                                                                                                                                         | Specification                                                                                                                                                                                                         |
|---------------|-----------|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               | AO2       | Analog output 2                     | Be able to output analog voltage/current (total 12 kinds of signals). Jumper CN5(J3 OR SW3) can select voltage or current input mode, Voltage input mode is the default mode. Refer to F6.04 for details.(reference ground: GND) |                                                                                                                                                                                                                       |
| Digital input | X1~X3     | Multi-functional digital inputs 1~3 | Can be defined as multi-functional digital inputs, see Section 5.7<br>Reference ground: COM                                                                                                                                      | Optical-isolator<br>2-way input<br>input resistance: 2k $\Omega$<br>maximum input frequency: 200Hz<br>Input voltage range: 9~30V                                                                                      |
|               | X4~X5     | Multi-functional digital inputs 4~5 | Having the same function as X1~X3, besides, it can be defined as high-speed pulse inputs. See Section 5.7.<br>Reference ground: COM                                                                                              | Optical-isolator<br>2-way input<br>Single way max. input frequency: 100kHz,<br>2-way max. input frequency: 50kHz<br>Max. reference pulse frequency: 50Hz<br>Input voltage range: 9~30V<br>Input impedance: 2 $\Omega$ |
|               | FWD       | Run forward command                 | Optical-isolator two-way input programmable terminal, max. input frequency: 200Hz                                                                                                                                                |                                                                                                                                                                                                                       |
|               | REV       | Reverse run command                 | Optical-isolator two-way input programmable terminal, max. input frequency: 200Hz                                                                                                                                                |                                                                                                                                                                                                                       |
|               | PLC       | Common terminal                     | Common terminal for multi-functional inputs                                                                                                                                                                                      |                                                                                                                                                                                                                       |

| Category       | Terminals                                                                          | Name                     | Function                                                                                              | Specification                                                                                                                          |
|----------------|------------------------------------------------------------------------------------|--------------------------|-------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
|                | P24                                                                                | +24V supply              | Providing +24V power supply                                                                           | Output: +24V, set point accuracy: $\pm 10\%$<br>Max output current: 200mA (150mA for 2S0007G and 2S0004G)                              |
|                | COM                                                                                | +24V common terminal     | Isolated internally with GND                                                                          | Isolated internally with GND                                                                                                           |
| Digital input  | Y1                                                                                 | Open collector output 1  | Programmable terminals, defined as multi-function digital outputs, see Section 5.7.                   | Optical-isolator output: 24V <sub>DC</sub> /50mA                                                                                       |
| Digital output | Y2                                                                                 | Open collector output 2  | Programmable terminals, defined as multi-function digital outputs, see Section 5.7.                   | Optical-isolator output: 24V <sub>DC</sub> /50mA, Y2 can be used as digital output, Max output frequency :50kHz                        |
| Power supply   | +10V                                                                               | +10V power supply        | Provide +10V power supply                                                                             | Output: +10V, Setpoint accuracy: $\pm 10\%$<br>Max. output current: 100mA                                                              |
|                | GND                                                                                | GND of +10V power supply | reference ground of analog signal and 10V power supply                                                | Isolated internally with COM                                                                                                           |
| Others         | 1TA/1TB/<br>1TC/2TA/<br>2TB/2TC<br>( Only one group relay below SINUS VEGA 0005 4T | Relay output             | TA, TB and TC can be defined as multi-functional digital output signals. Please refer to Section 5.87 | TA-TB: normally closed; TA-TC: normally open<br>Contact capacity: 250Vac/2A (COS $\phi$ =1) , 250Vac/1A (COS $\phi$ =0.4) , 30 Vdc /1A |

## 1) Analog Input Terminal Wiring

① Terminal VCI receives analog voltage input, the wiring is as follows:




Figure 3-9 VCI Wiring Diagram

② Terminal CCI receives analog signal. Select current or voltage signal by setting jumper. Refer to the figure below:




Figure 3-10 CCI Wiring Diagram

## 2) Analog Output Terminal Wiring

If the analog output terminal AO1 and AO2 are connected with analog meter, it can measure many parameters. The jumpers for AO1 and AO2 are CN4 (J2 OR SW2) and CN5 (J3 OR SW3).




Figure3-11 Analog Output Terminal Wiring



#### Note:

1. When using analog input, you should install capacitor-filter or common-mode inductor between VCI and GND, or between CCI and GND.
2. Analog I/O signals are sensible to interference, ensure to use shielded cable and ground it properly. The cable length should be as short as possible.

### 3) Serial Communication Port Connection

The inverter can be connected to the host with RS485 port directly.

Figure 3-12 shows the connection of the inverter with the host with RS232 port.

Using above wiring method, you can built a “single-master single-slave” system or a “single-master multi-slaves” system. The inverter in the network can be monitored, can be controlled remotely automatically in real time by using a PC or PLC controller. Thus more complicated operation control can be realized.




Figure3-12 RS485- (RS485/RS232) -RS232 communication cable

Precautions for communication port connection:

The PE terminal of each inverter should be earthed at a nearby grounding point;

The GND terminal of each inverter should be connected together;

RS485 communication uses shielded cables, which is earthed at one side. The earth wire of the shielded cable is connected to RS485 communication module (PE).

If the above standard wiring methods cannot meet the requirements, you can take the actions below:

Use isolated RS485 communication module;

If the noise is transmitted through the GND line to the inverter or other devices, which results in malfunction of them, you may disconnect the GND lines.

#### 4) Multi-function Input Terminal and FWD, REV Wiring

The multi-function input terminals use full-bridge rectifying circuit, as the below figure shows. PLC is the common terminal for X1~X5, FWD and REV. The PLC terminal can sink or source current. Wire connections X1~X5, FWD and REV is flexible and the typical wiring is shown below:

##### ① Connection method 1

It is default to use the inverter's internal power source 24V, i.e. PLC connected with P24.

If you want to use external power supply, make sure to remove the wire between PLC and P24.




Figure 3-13 External power supply wiring diagram

##### ② Connection Method 2

Inverter's internal +24V power supply is used and the external controller uses PNP transistors whose common emitters are connected, as shown in Figure 3-14.




Figure 3-14 Internal +24V wiring diagram (source)

Inverter's internal +24V power supply is used and the external controller uses PNP transistors whose common emitters are connected. (Remote the wire between PLC and P24) .




Figure 3-15 Internal +24V wiring diagram (drain)

When using External power supply, remember to disconnect PLC and P24




Figure 3-16 External power supply wiring (source)

External power supply wiring (drain) (Remember to disconnect PLC and P24)




Figure 3-17 External power supply wiring (drain)

##### 5) Multi-function Output Terminal Wiring

- ① Terminal Y1 can use the internal 24V power supply, see the figure below:




Figure 3-18 Multi-function output terminal wiring1

- ② Terminal Y1 can also use external power (9~30V) supply:




Figure 3-19 Multi-function output terminal wiring2

- ③ When Terminal Y2 is used as digital pulse frequency output, it can also use the internal 24V power supply:




Figure 3-20 Terminal Y2 wiring 1

- ④ When Terminal Y2 is used as digital pulse frequency output, it can also use the external power supply (9~30V):




Figure 3-21 Terminal Y2 wiring 2

**Note:**

1. Don't short terminals P24 and COM, otherwise the control board may be damaged.
2. Use multi-core shielded cable or multi-strand cable (above 1mm) to connect the control terminals.
3. When using a shielded cable, the shielded layer send that is nearer to the inverter should be connected to PE.
4. The control cables should be as far away (at least 20cm) as possible from the main circuits and high voltage cables (including power supply cables, motor cables, relay cables and cables of contactor). The cables should be vertical to each other to reduce the disturbance to minimum.

### 5.2.4 Onsite Wiring Requirements

To avoid mutual EMI disturbance, the control cables, power cable and motor cable should be installed as apart as possible, especially when they are routed in parallel for rather long distance. If the signal cable must cross the power cable or motor cable, keep them at right angle to each other.




Figure 3-22 Cable routing schematic diagram

If the section area of the motor cable is too big, the motor should derate. Refer the inverter's cable specs in Table 3-2. Since the larger the section area of cables, the greater their capacitance to the ground, therefore, the output current should derate 5% with increasing every category of cable section area. Shielded/armored cable: high-frequency low-impedance shielded cable should be used, such as woven copper mesh, aluminum mesh or metal mesh.

The control cable should be shielded, and the clamps at both ends of the metal mesh should be connected to the earth terminal of the inverter enclosure.

Use conductive plate and dentate pad to clear away the paint between the screws and metal casing, to ensure good conductivity.




Figure 3-23 Correct shield layer earthing




Figure3-24 Incorrect shield layer earthing

## 5.2.5 Earthing

Independent earthing pole(recommended) Shared earthing pole(acceptable)




Figure 3-25 Earthing Diagram 1

Figure 3-26 Earthing Diagram 2

Shared earthing lines (not allowed)




Figure 3-27 Earthing Diagram 3

Besides, pay attention to the following points:

In order to reduce the earthing resistance, flat cable should be used because the high frequency impedance of flat cable is smaller than that of round cable with the same CSA.

For 4-core motor cable, the end of one cable should be connected to the PE of the inverter, and the other end should be connected to the motor enclosure. If the motor and the inverter each have its own earthing pole, then the earthing effect is better.

If the earthing poles of different equipment in one system are connected together, then the leakage current will be a noise source that may disturb the whole system. Therefore, the inverter earthing pole should be separated with the earthing pole of other equipment such as audio equipment, sensors and PC, etc.

In order to reduce the high frequency impedance, the bolts used for fixing the equipment can be used as the high frequency terminal. The paints on the bolt should be cleaned.

The earthing cable should be as short as possible, that is, the earthing point should be as close as possible to the inverter.

Earthing cables should be located as far away as possible from the I/O cables of the equipment that is sensitive to noise, and lead should also be as short as possible.



## 6. Operation Procedures

### 6.1 Term Definition

#### 6.1.1 Inverter Control modes

There are three control modes:

- (1) Keypad control: The inverter is controlled by RUN、STOP key.
- (2) Terminal control: The inverter is controlled by FWD、REV and COM (two-wire mode), Xi (3-wire mode).
- (3) Communication: The operations such as START and STOP are controlled by RS485.

The control modes can be selected by parameters, switched by multi-function input terminals (function code 27、28、29 of F5.00).

#### 6.1.2 Frequency Setting Method

Methods to set frequency:

- (1) ▲ and ▼ on the keypad;
- (2) Terminal UP/DN;
- (3) Serial communication port;
- (4) Analog VCI;
- (5) Analog CCI;
- (6) Terminal (PULSE);
- (7) Potentiometer (for power rate lower than 4.G)

How to set frequency:

Main reference frequency: Set by F0.02, multi-speed (MS) or close loop control.

The main reference frequency is decided by the priority of running mode. The priority level is Jog>close loop>PLC>MS (multi-speed) >common running, e.g. if the inverter is running in MS mode, the primary reference frequency is MS frequency.

Auxiliary reference frequency: set by F0.03、F9.17、F0.05、F9.18.

Preset frequency: the sum of main and auxiliary frequency multiply a factor, which is set in F9.19 and F9.20. Please refer to F9.19, F9.20 and Figure 5-1 in chapter 5.

### 6.1.3 Inverter Operation Status

(1) Stop: After the inverter is switched on and initialized, if no operating command is received or the stop command is executed, then the inverter enters stop status.

(2) Operating: After receiving run command, the inverter begins to operate.

(3) Motor parameter tuning: If F1.10 is set at 1 or 2, after giving RUN command, the inverter will enter motor parameter tuning status, and then it will stay in stop status.

### 6.1.4 Operating Mode

There are 5 kinds of operating modes of SINUS VEGA, which can be arranged in the sequence of: Jog>Close loop operation>PLC>MS>Simple operation according to the priority.

(1) Jog: When the inverter is in stop status, it will operate according to Jog frequency after it receives the Jog operation command. (See F9.05~F9.08)

(2) Close-loop operation: If the close-loop operating function is enabled (F7.00=1), the inverter will select the close-loop operation mode, meaning that it will perform PI regulation according to the reference and feedback values (See explanations of Parameter F7). Close-loop operating function can be disabled by multi-function terminal (function No. 20), and the inverter will then select other operating mode of lower priority level.

(3) PLC running: PLC function is enabled if the one's place of FD.00 setting is a non-zero value. The inverter will run according to the preset mode, see FD function group. It can be disabled by multi-function terminal (function No.21).

(4) MS running: Select multi-frequency 1~7 (F8.00~F8.06) by the combination of multi-function terminal (function No. 1, 2, 3), which is not zero.


(5) Simple running: Simple open-loop operation.

The above 5 operating modes determine 5 frequency setting sources. Except Jog, the other four frequency settings can be adjusted or combined with auxiliary frequency. The frequency of PLC, MS and simple running can also be adjusted by traverse.


## 6.2 Operation Guide

### 6.2.1 LED Keypad

LED keypad display unit is to receive command and display parameters.



Keypad diagram of SINUS VEGA 0002 4T~0004 4T



Keypad diagram of SINUS VEGA 0005 4T and above

Figure 4-1 LED Keypad Display Unit

## 6.2.2 Keypad Function Explanation

Keys on the LED keypad display unit refer to the function of each key in Table 4-1.

Table 4-1 Key's function of SINUS VEGA 0002 4T~0005 4T

| Key        | Name              | Function                                                                                                                        |
|------------|-------------------|---------------------------------------------------------------------------------------------------------------------------------|
| PRG        | Program/Esc key   | To shift between program state and Esc state                                                                                    |
| FUNC/DATA  | Function/Data key | To shift between function code menus, confirm modification                                                                      |
| ▲          | Increase key      | To increase data or function code number                                                                                        |
| ▼          | Decrease key      | To decrease data or function code number                                                                                        |
| ▶▶         | Shift key         | To scroll over the displayed parameters, such as voltage、 frequency. To select the digit to be modified                         |
| RUN        | Run key           | In the keypad operating mode, press the key to start running                                                                    |
| STOP/RESET | Stop/Reset key    | In keypad mode, stop the inverter or reset in case of alarm or fault;<br>Terminal control mode: reset in case of alarm or fault |
| /          | Potentiometer     | Set frequency                                                                                                                   |

Key's function SINUS VEGA 0007 4T~SINUS VEGA 0160 4T

| Key        | Name              | Function                                                                                                                  |
|------------|-------------------|---------------------------------------------------------------------------------------------------------------------------|
| MENU/ESC   | Program/Esc key   | To shift between program state and Esc                                                                                    |
| ENTER/DATA | Function/Data key | To enter sub-menu, confirm modification                                                                                   |
| ▲          | Increase key      | To increase data or function code number                                                                                  |
| ▼          | Decrease key      | To decrease data or function code number                                                                                  |
| ▶▶         | Shift key         | In the edit state, you can select the modified bit of set digit; In other state, to scroll over the displayed parameters. |
| LOCAL      | Control mode      | Control mode selection, press ENTER/DATA to confirm                                                                       |
| JOG        | Jog key           | In panel control mode, press Jog to start running                                                                         |
| RUN        | Run key           | In panel control mode, press the key to start running.                                                                    |
| STOP/RESET | Stop/Reset key    | Reset in case of alarm or fault                                                                                           |

### 6.2.3 Indicator Description

Functions of the indicators on the keypad:

| Indicator              | Meaning                                                                                        | Color | Mark  |
|------------------------|------------------------------------------------------------------------------------------------|-------|-------|
| Status indicator       | ON: the inverter is running                                                                    | Green | RUN   |
| Frequency indicator    | ON: current LED display is frequency                                                           | Green | Hz    |
| Current indicator      | ON: current LED display is current                                                             | Green | A     |
| Voltage indicator      | ON: current LED display is voltage                                                             | Green | V     |
| Control mode indicator | ON, keypad control mode;<br>OFF: terminal control mode;<br>Flicker: communication control mode | Green | LOCAL |
| Potentiometer          | Set frequency by the potentiometer                                                             | Green | None  |

Implication of the combination of indicators:

| Indicator combination | Meaning              |
|-----------------------|----------------------|
| Hz+A                  | Set speed (r/min)    |
| A+V                   | Set line speed (m/s) |
| Hz+V                  | Set percentage (%)   |

If all the above indicators (A, V, Hz) go out, it means the displayed parameter has no unit.

## 6.2.4 Parameter Setting Method

### Parameter system

The SINUS VEGA series inverter has 19 function groups: F0~F9, FA, FB, FC, FD, FE, FL, FN, FP and FU. Each function group includes many parameters, which is presented as function group number + parameter number, e.g. F7.08.

### Menu structure and parameter

When setting parameter through LED keypad display unit, function group is listed in menu level 1, parameter in menu level 2, and settings of parameters in menu level 3.

### Examples of Parameter Setting

The setting of parameter is presented in decimal (DEC) and hexadecimal (HEX) format. If it is set in hexadecimal format, each digit of the setting is independent to one another, which can be 0~F. There are at most 4 digits, they are: one's place, ten's place, hundred's place and thousand's place. You may



corresponding bit at Zero. Therefore, it turns out to be “0100”, after converting to HEX value, it is 4. So, you should set the one’s place at 4.

## 2. Set Ten’s place:

Similarly, set the corresponding bit at “1” for those parameters you want to display, you will get “1111”, i.e. “F”.

## 3. Set Hundred’s and Thousand’s place:

Since no parameters related to hundred’s and thousand’s place are required to display, so they are set at zero, from the above, FA.00 is set at 00F4.

| Thou | Hun | Ten | One                                                                                                                                                     |
|------|-----|-----|---------------------------------------------------------------------------------------------------------------------------------------------------------|
|      |     |     | BIT0 : output freq. Hz <i>before compensation</i><br>BIT1 : output freq. Hz <i>after compensation</i><br>BIT2 : set freq. Hz<br>BIT3 : output current A |
|      |     |     | BIT0 : actual speed rpm<br>BIT1 : set speed rpm<br>BIT2 : actual line speed m/s<br>BIT3 : set line speed m/s                                            |
|      |     |     | BIT0 : output power<br>BIT1 : output torque %<br>BIT2 : reserved<br>BIT3 : reserved                                                                     |
|      |     |     | BIT0 : reserved<br>BIT1 : reserved<br>BIT2 : reserved<br>BIT3 : reserved                                                                                |

Under menu level 3, if no digit of a parameter is blinking, it means it is unchangeable. The possible reasons are:

The parameter is unchangeable, such as measured parameters, operation log, etc;

The parameter can be changed at stop state only;

The parameter is protected. When FP.01=1 or 2, the parameter is protected. You should set FP.01=0 to allow the modification.

## 6.2.5 Speed Setting

If the initial state is actual speed, set speed, actual line speed or set line speed, you may press ▲ or ▼ key to change the set speed and set line speed real-time. If you want to change the reference setting, press ►► key to shift the LED display to frequency then change it.

## 6.2.6 Locking/Unlocking Keypad

**Lock Keypad:** Set the hundred’s place of F9.21 at non-zero value. Press **FUNC/DATA** key and **PRG** key at the same time, thus the keypad is locked.




Figure 4-2 Lock LED keypad display unit

Unlock: at stop or operating state, press **FUNC/DATA** key, and then press **▼** three times. Note that the operation will not change the value of F9.21.

Note:

Even though the hundred's place of F9.21 is not zero (allow to lock the keypad), every time the inverter is powered up, the keypad is not locked.



## 7. Parameters

**Note:**

The contents in the “【】” are factory default.

### 7.1 Basic Parameters (F0)

|       |                 |                |
|-------|-----------------|----------------|
| F0.00 | Command channel | Range: 0~2 【0】 |
|-------|-----------------|----------------|

SINUS VEGA has 3 kinds of command channels:

0: LED keypad display unit, use **RUN** and **STOP** key on the keypad to control the inverter.

1: Terminal control: Input operating commands via terminals. Use terminals FWD, REV, to start and stop the inverter

2: Serial communication port control.

|       |              |                |
|-------|--------------|----------------|
| F0.01 | Control mode | Range: 0~1 【0】 |
|-------|--------------|----------------|

0: V/F control

1: Vector control

|       |                          |                |
|-------|--------------------------|----------------|
| F0.02 | Frequency source setting | Range: 0~6 【0】 |
|-------|--------------------------|----------------|

0: Digital setting 1, set by ▲ or ▼ key.

Initial frequency is the value of F0.04 and it can be adjusted via ▲ and ▼ keys on the keypad.

1: Digital setting 2 set by terminal UP/DN.

Initial frequency is the value of F0.02 and it can be adjusted via terminal UP/DN.

2: Digital setting 3, set through serial communication port

Initial frequency is the value of F0.04 and it can be adjusted via serial communication port.

3: VCI

The reference frequency is set by voltage input via terminal VCI and the input voltage range is DC 0~10VDC.

4: CCI

The reference frequency is set by voltage or current input via terminal CCI and the input range is DC 0~10 VDC (if jumper CN7 (J1 OR SW1) is placed at V side) or DC0~20mA (if jumper CN7 (J1 OR SW1) is placed at I side).

5: Terminal Pulse Setting

The reference frequency is set by terminals X4 or X5, see F5.03~F5.04. The input pulse range: 15~30V, 0~50.0 kHz.

6: Keypad Potentiometer Setting (for power rate lower than SINUS VEGA 0005 4T)

The reference frequency is set by potentiometer, the adjusting range is 0~Max (F0.09).

Note :

For method 3, 4 and 5, the frequency calculation curve is given in F5.10~F5.21, please refer to 5.5.

|                                     |                  |
|-------------------------------------|------------------|
| F0.03 Auxiliary reference frequency | Range: 00~13 【0】 |
|-------------------------------------|------------------|

The setting frequency of SINUS VEGA is composed of main reference frequency and auxiliary reference frequency. F0.03、F0.05、F9.17、F9.18 are used to define auxiliary reference frequency. Figure 5-1 shows the formation process of setting frequency.




Figure 5-1 Preset Freq. Calculation Method





Figure 5-2 Auxiliary Frequency Processing

Table 5-1 Auxiliary reference frequency method selection

| Method | Name                                                         | Description                               |
|--------|--------------------------------------------------------------|-------------------------------------------|
| 0      | Invalid                                                      | Auxiliary freq.=0                         |
| 1      | Adjust by ▲ and ▼                                            | Set by F0.05                              |
| 2      | Adjust UP/DN                                                 |                                           |
| 3      | Set by serial port                                           |                                           |
| 4      | VCI                                                          | Depending on actual input. Refer to F5.10 |
| 5      | CCI                                                          |                                           |
| 6      | PULSE                                                        |                                           |
| 7      | - VCI                                                        |                                           |
| 8      | - CCI                                                        |                                           |
| 9      | - PULSE                                                      |                                           |
| 10     | VCI-5                                                        |                                           |
| 11     | CCI-5                                                        |                                           |
| 12     | PULSE-0.5×Max pulse input freq.                              |                                           |
| 13     | Potentiometer (for power rate lower than SINUS VEGA 0005 4T) |                                           |

Select digital setting 3, you may set F0.03 via serial port to change auxiliary frequency.


If VCI-5 or CCI-5 is selected, take 5V input as the point corresponding to zero frequency, 0~5V input corresponds to negative output, 5~10V input corresponds to positive output. See Figure5-3.



$f_{\max}$ —frequency corresponding to Max analog value(F5.17 or F5.21)

Figure 5-3 Frequency Setting Via VCI-5 or CCI-5

If PULSE-0.5 × F5.13 is taken as auxiliary frequency setting method, one half of F5.13 (max. pulse freq.) as the point corresponding to zero frequency, 0~0.5 times of F1.03 input corresponds to negative output, 0.5~1 times of F5.13 input corresponds to positive output. See Figure5-4.



$$P_{mid} = 1/2 \times F5.13$$

$f_{max}$ —frequency corresponding to Max analog value (F5.17 or F5.21)

Figure 5-4 PULSE-0.5 × F5.13 As Freq. input

F9.17: Analog auxiliary reference factor

It is valid when F0.03=4~12. The auxiliary reference undergoes F9.17 gain calculation first, and then output according to F5.10.

F9.18: digital auxiliary reference control

It is valid when F0.03=1~3. See Figure 5-5.




Figure 5-5 Digital Auxiliary Freq. Setting

One's place of F9.18

0: save the auxiliary freq. at power off

The auxiliary frequency will be saved in F9.03, and the sign of the freq. saved in F9.18.

1: not save the auxiliary freq. at power off

Ten's place of F9. 18

0: maintain the auxiliary freq. if the inverter stops

1: preset frequency is cleared if the inverter stops

Hundred's place of F9.18: sign of auxiliary freq.

0: (+) positive sign.

Preset freq. is the sum of main freq. and auxiliary freq.

1: (−) negative sign

Preset freq. is the result of main freq. minus auxiliary freq.

Note:

When the inputting mode of auxiliary reference frequency is the same with that of main reference frequency, the auxiliary reference frequency setting is invalid.

|                              |                                                            |
|------------------------------|------------------------------------------------------------|
| F0.04 Keypad digital setting | Range: Lower limit of freq.~Upper limit of freq. 【50.00Hz】 |
|------------------------------|------------------------------------------------------------|

When the frequency source setting method is defined as keypad digital setting(F0.02=0、1、2), F0.04 is the initial value of frequency.

|                                   |                               |
|-----------------------------------|-------------------------------|
| F0.05 Digital auxiliary frequency | Range: 0.00~650.00Hz 【0.00Hz】 |
|-----------------------------------|-------------------------------|

F0.05: The initial value of digital auxiliary frequency.

It is valid only and it is the initial value of auxiliary frequency when

F0.03=1~3.

|                            |                                               |
|----------------------------|-----------------------------------------------|
| F0.06 Base frequency       | Range: 0.00~650.00Hz 【50.00Hz】                |
| F0.07 Upper limit of freq. | Range: Upper limit~Max output freq. 【50.00Hz】 |
| F0.08 Lower limit of freq. | Range: 0~Upper limit of freq. 【0.00Hz】        |

Please refer  $f_H$  and  $f_L$  in Figure 5-6

|                            |                                                                      |
|----------------------------|----------------------------------------------------------------------|
| F0.09 Max output frequency | Range: Max {50.00, F0.12 upper limit of frequency}~650.00H 【50.00Hz】 |
| F0.10 Max output voltage   | Range: 1~480V 【Inverter rated】                                       |

The max frequency refers to the allowed max output frequency of the inverter. Refer to the  $f_{max}$  in Figure 5-6;

Base frequency normally corresponds with the rated frequency of the motor. It is the Min frequency when the inverter outputs the highest voltage, as shown in Figure 5-6 as  $f_b$

Max output voltage is the inverter output voltage when the inverter outputs base frequency, as shown in Figure 5-6 as  $V_{max}$ . This corresponds to the rated voltage of the inverter




Figure 5-6 Characteristic parameters definition

The  $f_H$  and  $f_L$  are defined by F0.07 and F0.08 as upper limit and lower limit of frequency respectively.

|       |                    |            |     |
|-------|--------------------|------------|-----|
| F0.11 | Running directions | Range: 0、1 | 【0】 |
|-------|--------------------|------------|-----|

The function applies only to keypad control, but not serial port control, not terminal control mode.

0: Forward

1: Reverse

|       |            |                        |              |
|-------|------------|------------------------|--------------|
| F0.12 | Acc time 1 | Range: 0.1~3600s (min) | 【6.0s/20.0S】 |
| F0.13 | Dec time 1 | Range: 0.1~3600s (min) | 【6.0s/20.0S】 |




Figure 5-7 Acc/Dec time definition

Acc time is the time taken for the motor to accelerate from 0 Hz to the maximum frequency (as set in F0.09), see  $t_1$  in Figure 5-7. Dec time is the time taken for the motor to decelerate from maximum frequency (F0.09) to 0 Hz, see  $t_2$  in Figure 5-7.

SINUS VEGA has four pairs of acc/dec time. Here we only introduce acc/dec 1. Please find acc/dec time 2~4 in section 5.9: F8.14~F8.19

|       |                      |            |     |
|-------|----------------------|------------|-----|
| F0.14 | Anti-reverse setting | range: 0、1 | 【0】 |
|-------|----------------------|------------|-----|

0: Reverse allowed

1: Reverse not allowed

## 7.2 Motor Parameter (F1)

|       |  |
|-------|--|
| F1.00 |  |
|-------|--|

|       |               |                                                |
|-------|---------------|------------------------------------------------|
| F1.01 | Motor's poles | Range: 2~14 <b>【4】</b>                         |
| F1.02 | Rated power   | Range: 0.4~999.9kW <b>【depending on model】</b> |
| F1.03 | Rated current | Range: 0.1~999.9A <b>【depending on model】</b>  |

F1.01~F1.03 are to set motor's parameters. Be sure to input the values according to motor's nameplate.

|       |                      |                                                |
|-------|----------------------|------------------------------------------------|
| F1.04 | Current without load | Range: 0.1~999.9A <b>【depending on model】</b>  |
| F1.05 | Stator resistance    | Range: 0.0~50.00% <b>【depending on model】</b>  |
| F1.06 | Leakage inductance   | Range: 0.0~50.00% <b>【depending on model】</b>  |
| F1.07 | Rotor resistance     | Range: 0.0~50.00% <b>【depending on model】</b>  |
| F1.08 | Mutual inductance    | Range: 0.0~2000.0% <b>【depending on model】</b> |

Please refer the above parameters to Figure 5-8.




Figure 5-8 Motor's Equivalent Circuit

In Figure 5-8,  $R_1$ ,  $X_{1l}$ ,  $R_2$ ,  $X_{2l}$ ,  $X_m$  and  $I_0$  represent stator's resistance, stator's leakage inductance, rotor's resistance, rotor's leakage inductance, mutual inductance and current without load respectively. The setting of F1.06 is the sum of stator's leakage inductance and rotor's inductance.

The settings of F1.05 ~F1.08 are all percentage. Formula used for calculating stator's resistance or rotor's resistance::

$$\%R = \frac{R}{V / (\sqrt{3} \cdot I)} \times 100\%$$

R: Stator's resistance or rotor's resistance that is converted to the stator's side;

V: Rated voltage;

I: Motor's rated current;

Formula for calculating (leakage inductance or mutual inductance);

$$\%X = \frac{X}{V/(\sqrt{3} \cdot I)} \times 100\%$$

X: The sum of leakage inductance of stator and rotor, or mutual inductance.  
The rotor's inductance has been converted to the stator's side;

V: Rated voltage;

I: Motor's rated current

If motor's parameters are available, please set F1.05 ~F1.08 to the values calculated according to the above formula.

If the inverter performs auto-tuning of motor's parameters, then the settings of F1.04~F1.08 after the auto-tuning process will be updated.

After motor power (setting of F1.02) is changed, the inverter will set F1.03~F1.08 to corresponding parameters.

|       |                      |                                     |
|-------|----------------------|-------------------------------------|
| F1.09 | Rated slip frequency | Range: 0.00~20.00Hz <b>【2.00Hz】</b> |
|-------|----------------------|-------------------------------------|

Motor's rated slip frequency can be calculated by the motor's rated speed (on the nameplate):

Rated slip frequency = motor's rated frequency (i.e. basic operating frequency F0.06) × (motor's synchronous speed-motor's rated speed) ÷ motor's synchronous speed. Where: motor's synchronous speed = motor's rated frequency × 120 ÷ number of motor's poles (F1.01)

After setting the slip compensation, the slip compensation will be enabled by F3.09~F3.11.

|       |             |                       |
|-------|-------------|-----------------------|
| F1.10 | Auto tuning | Range: 0~2 <b>【0】</b> |
|-------|-------------|-----------------------|

FH09 can be used to measure and write-in the motor's parameters automatically.

0: Auto-tuning is disabled

1: Stationary auto-tuning (Start auto-tuning to a standstill motor)

Before starting auto-tuning, values on the motor's nameplate must be input correctly (F1.01~F1.03). When starting auto-tuning to a standstill motor, the stator's resistance, rotor's resistance and the leakage inductance will be measured and the measured values will be written into F1.05, F1.06 and F1.07 automatically.

2: Rotating auto-tuning

When starting a rotating auto-tuning, at first, the motor is in standstill status, and the stator's resistance, rotor's resistance and the leakage inductance will be measured, and then the motor begins to rotate, mutual inductance,



parameters will be measured and written into F1.05, F1.06, F1.07, F1.08 and F1.04 automatically.

After auto-tuning, F1.10 will be set to 0 automatically.

Auto-tuning procedures:

- 1) Set the F0.06 basic operating frequency and F0.07 Max output voltage correctly according to the motor's feature;
- 2) Set the F1.01, F1.02 and F1.03 correctly;
- 3) If F1.10 is set to 2, Acc time (F0.12) and Dec time (F0.13) should be set correctly and remove the load from the motor and check the safety;
- 4) Set F1.10 to 1 or 2, press **FUNC/DATA**, and then press **RUN** to start auto-tuning;
- 5) When the operating LED turns off, that means the auto-tuning is over.

Note :

1. When setting F1.10 to 2, you may increase Acc/Dec time if over-current or over-voltage fault occurs in the auto-tuning process;
2. When setting F1.10 to 2, the motor's load must be removed before starting rotating auto-tuning;
3. The motor must be in standstill status before starting the auto-tuning, otherwise the auto-tuning cannot be executed normally;
4. If it is inconvenient to start auto-tuning (e.g. the motor cannot break away from the load), or you don't require much on motor's control performance, you can use stationary auto-tuning or even disable the function. You may input the values on the motor's nameplate correctly (F1.01~F1.03);
5. If the auto-tuning function is unavailable and there is motor's parameters on the nameplate, you should input the values correctly (F1.01~F1.03), and then input the calculated values (F1.04~F1.08). Please set the parameters correctly;
6. If auto-tuning is not successful, the inverter alarms and displays fault F.tU.

### 7.3 Start/Brake Parameter (F2)

|                  |                         |
|------------------|-------------------------|
| F2.00 Start mode | Range: 0、1、2 <b>【0】</b> |
|------------------|-------------------------|

F2.00=0: Start at start frequency

The inverter is started at start frequency (F2.01) and in preset time (F2.02) .

F2.00=1: Brake first and then start at start frequency.

DC brake first, refer to F2.03、F2.04, and then start in the manner of F2.00=0

F2.00=2: Rotate speed tracking and then start at start frequency (For power rate lower than SINUS VEGA 0005 4T, F2.00 is reserved)

Tracking motor's rotate speed and directions automatically. Start the motor during rotating smoothly and without any impact. Please refer to Figure 5-a.




Figure 5— a

Note :

1. Start mode 1 applies to small-inertia motor when the inverter stops, the motor is still rotating. For large-inertia load, do not restart until the motor stops.
2. Start mode 2 applies to large-inertia motor when the inverter stops, the motor is still running.
3. The performance of start mode 2 is related to motor parameters. Please set the parameters of FH correctly.
4. When driving synchronized motor, it is recommended to use start mode 0.

|       |                           |                              |
|-------|---------------------------|------------------------------|
| F2.01 | Start frequency           | Range: 0.20~60.00Hz 【0.20Hz】 |
| F2.02 | Start frequency hold time | Range: 0.0~10.0s 【0.0s】      |

Start frequency refers the frequency at which the inverter starts, as shown in Figure 5-9 as  $f_s$ , Start frequency hold time refers the time within which the inverter runs at start frequency during start up, as shown in Figure 5-9  $t_1$ .




Figure 5-9 Relation of Start Freq. and Start Time

Note:

The start frequency is not limited by lower limit of the frequency.

|                                   |                                     |
|-----------------------------------|-------------------------------------|
| F2.03 DC brake current at startup | Range: Depending on model<br>【0.0%】 |
| F2.04 DC brake time at startup    | Range: Depending on model<br>【0.0s】 |

F2.03 and F2.04 are valid only when you set F2.00=1, that is, braking before starting. See Figure 5-10.

DC brake current at startup is determined by inverter model,

4.0KW and below Heavy duty: 0~150%; Normal duty: 0~130%。

5.5KW and above Heavy duty: 0~100%; Normal duty: 0~80%。

DC braking current start up is relative to the percentage of the rated current of the inverter.

If the brake time at startup is set to 0.0s, no brake process.




Figure 5-10 Start mode 1

|               |                |
|---------------|----------------|
| F2.05 Acc/Dec | Range: 0、1 【0】 |
|---------------|----------------|

F2.05=0: Linear Acc/Dec

The output frequency increase or decrease according to a fixed slope, see Figure 5-11.

F2.05=1: S curve Acc/Dec

The output frequency increase or decrease according to S curve, see Figure 5-12.





Figure 5-11 Linear Acc/Dec curve Figure 5-12 Acc/Dec S curve

|                           |                       |
|---------------------------|-----------------------|
| F2.06 S curve start time  | Range: 10~50% 【20.0%】 |
| F2.07 S curve rising time | Range: 10~80% 【60.0%】 |

F2.06、F2.07 are only valid when F2.05=1 (S curve mode) and F2.06+F2.07 ≤ 90%.

S curve start time is illustrated in Figure 5-12 as ①, the change rate of output frequency is increasing from 0.

S curve rising time is illustrated in Figure 5-12 as ②, the change rate remains the same.

S curve end time is illustrated in Figure 5-12 as ③. The change rate decreases to 0.

S curve Acc/Dec is suitable to the start and stop of elevator, conveyor, etc.

|                 |                         |
|-----------------|-------------------------|
| F2.08 Stop mode | Range: 0、1、2 <b>【0】</b> |
|-----------------|-------------------------|

0: Decelerate to stop

When the inverter receives Stop command, it will reduce output frequency to zero and stop within preset deceleration time.

1: Coast to stop

When the inverter receives Stop command, it will stop outputting frequency and stop gradually relying on load inertia.

2: Deceleration + DC braking

When the inverter receives Stop command, it will reduce output frequency within preset Dec time. When it arrives at the frequency threshold of DC braking, the DC braking begins. Please refer to F2.09~F2.12.

|                                         |                                                     |
|-----------------------------------------|-----------------------------------------------------|
| F2.09 Frequency threshold of DC braking | Range: 0.00~60.00Hz<br><b>【1.00Hz】</b>              |
| F2.10 DC brake delay time               | Range: 0.00~10.00s <b>【0.00s】</b>                   |
| F2.11 DC brake current                  | Range: Depending on model<br><b>【120.0%/100.0%】</b> |
| F2.12 DC brake time at stop             | Range: Depending on model<br><b>【0.5s】</b>          |

DC braking delay time is the period from arriving at frequency threshold (F2.09) to starting braking.

During the period, there is no output from the inverter. This function can prevent current overshoot of high power motor at startup.

For power rate lower than SINUS VEGA 0005 4T:

The braking current is different depending on inverter's model,

Heavy duty: 0~150% of inverter's rated current (max. current among the 3 phases),

Normal duty: 0~130% of inverter's rated current (max. current among the 3 phases).

For power rate higher than SINUS VEGA 0075 4T:

The braking current is different depending on inverter's model,

Heavy duty: 0~150% of inverter's rated current (max. current among the 3 phases), Normal duty: 0~130% of inverter's rated current (max. current among the 3 phases).

If the brake time at stop is set at 0.0s, there is no braking process.




Figure 5-13 Deceleration +DC braking Process

|                       |                 |
|-----------------------|-----------------|
| F2.13 Dynamic braking | Range: 0, 1 【0】 |
|-----------------------|-----------------|

0: Disabled

1: Enabled

Note :

Please set this parameter properly according to your needs, otherwise, the control performance will be suffered.

|                                                      |                            |
|------------------------------------------------------|----------------------------|
| F2.14 Ration of braking time to total operating time | Range: 0.0~100.0% 【100.0%】 |
|------------------------------------------------------|----------------------------|

The max. Continuous dynamic braking time is calculated with 100s as a cycle.

Note :

The resistance and power of the braking resistor should be considered.

## 7.4 Flux vector control parameters (F3)

|                         |                             |
|-------------------------|-----------------------------|
| F3.00 V/F curve setting | Range: 0~3 【0】              |
| F3.01 V/F freq. F3      | Range: F3.03~F0.06 【0.00Hz】 |
| F3.02 V/F voltage V3    | Range: F3.04~100.0% 【0.0%】  |
| F3.03 V/F freq. F2      | Range: F3.05~F3.01 【0.00Hz】 |
| F3.04 V/F voltage V2    | Range: F3.06~F3.02 【0.0%】   |
| F3.05 V/F freq. F1      | Range: 0~F3.03 【0.00Hz】     |
| F3.06 V/F voltage V1    | Range: 0~F3.04 【0.0%】       |

This group of parameters defines the V/F setting modes so as to satisfy the requirements of different loads. Three fixed curves and one user-defined curve can be selected according to the setting of F3.00.

If F3.00 is set to 1, a 2-order curve is selected, as shown in Figure 5-14 as curve 1;

If F3.00 is set to 2, a 1.7-order curve is selected, as shown in Figure 5-14 as curve 2;

If F3.00 is set to 3, a 1.2-order curve is selected, as shown in Figure 5-14 as curve 3.

The above V/F curves are suitable for the variable-torque loads such as fan & pumps. The user can select the curves according to the actual load so as to achieve the best energy-saving effects.




Figure 5-14 Torque-reducing curve

If F3.00 is set to 0, you can define a curve by F3.01~F3.06, i.e. a polygonal line defined by 3 points (V1, F1), (V2, F2), (V3, F3), to satisfy the needs of special loads, as shown in Figure 5-15.

The default is a straight line, shown in Figure 5-14 as curve 0.




Figure 5-15 User Defined V/F curve

|                    |                       |
|--------------------|-----------------------|
| F3.07 Torque boost | Range: 0~30.0% 【0.0%】 |
|--------------------|-----------------------|

In order to compensate the torque drop at low frequency, the inverter can boost the voltage so as to increase the torque. If F0.09 is set to 0, auto torque boost is enabled and if set to non-zero, manual torque boost is enabled, as shown in Figure 5-16.




Figure 5-16 Torque boost (shadow area: boost value)

#### Note:

1. Wrong parameter setting can cause overheating of the motor or triggers the over-current protection of the inverter.
2. Refer to F3.08 for definition of  $f_z$ .
3. When using synchron motor, you should select manual torque boost, and adjust V/F curve according to the motor parameters and application.

|                                        |                      |
|----------------------------------------|----------------------|
| F3.08 Manual torque boost cutoff point | Range: 0~50% 【10.0%】 |
|----------------------------------------|----------------------|

F3.08 defines the ratio of the cut-off frequency used for manual torque boost to the base frequency (defined by F0.06) , as shown in Figure 5-16 as  $f_z$ . This cut-off frequency adapts to any V/F curve defined by F3.00.

|                               |                            |
|-------------------------------|----------------------------|
| F3.09 Slip compensation gain  | Range: 0.0~300.0% 【100.0%】 |
| F3.10 Slip compensation limit | Range: 0.0~250.0% 【200.0%】 |
| F3.11 Compensation time       | Range: 0.1~25.0s 【2.0s】    |

The change in motor torque will affect motor slip and result in speed change. Through slip compensation, the output frequency can be adjusted according to motor load torque, so as to reduce speed change caused by load change. See Figure 5-17.






Figure 5-17 Auto slip compensation

Electromotion state: Increase the gain of slip compensation gradually when the actual speed is lower than the reference speed (F3.09)

Power generation state: Increase the gain of slip compensation gradually when the actual speed is higher than the reference speed (F3.09).

Slip compensation range: limit of slip compensation (F3.10) × rated slip (F1.09).

**Note :**

The value of automatically compensated slip is dependent on the motor's rated slip; therefore the motor's rated slip must be set correctly (F1.09).

|                    |                         |
|--------------------|-------------------------|
| F3.12 AVR function | Range: 0、1、2 <b>【2】</b> |
|--------------------|-------------------------|

0: Disabled

1: Always enabled

2: Disabled during decelerating

AVR: auto voltage adjustment. This function can keep constant output voltage when the input voltage deviates from rated value. Therefore, the function should be enabled all the time especially when the input voltage is higher than the rated value.

If AVR is disabled during deceleration, the Dec time is shorter but the current is higher, otherwise, the motor decelerates smoothly with lower current, but the Dec time is longer.

|                          |                       |
|--------------------------|-----------------------|
| F3.13 Auto energy saving | Range: 0、1 <b>【0】</b> |
|--------------------------|-----------------------|

0: Disabled

1: Enabled

The inverter can detect load current and adjust voltage accordingly to save energy.

**Note :**

This function is preferable to the load such as fan and pump.。

|       |                            |                                   |
|-------|----------------------------|-----------------------------------|
| F3.14 | Motor stabilization factor | Range: 0~255 【Depending on model】 |
|-------|----------------------------|-----------------------------------|

F3.14 is used to suppress the oscillation caused by the inverter and the motor. If the inverter's output current changes constantly at fixed load, the oscillation can be reduced by adjusting F3.14.

For power rate lower than 55kW, the default value is 10;

For power rate higher 55kW, the default value is 20.

## 7.5 Current vector control parameter (F4)

|       |          |   |
|-------|----------|---|
| F4.00 | Reserved | - |
|-------|----------|---|

|       |                |                |
|-------|----------------|----------------|
| F4.01 | Pre-excitation | Range: 0~1 【1】 |
|-------|----------------|----------------|

0: Valid

1: Invalid

|       |                                |                      |
|-------|--------------------------------|----------------------|
| F4.02 | Speed loop proportional gain 1 | Range: 0~65535 【120】 |
|-------|--------------------------------|----------------------|

|       |                            |                    |
|-------|----------------------------|--------------------|
| F4.03 | Speed loop integral gain 1 | Range: 0~65535 【3】 |
|-------|----------------------------|--------------------|

|       |                                |                      |
|-------|--------------------------------|----------------------|
| F4.04 | Speed loop proportional gain 2 | Range: 0~65535 【120】 |
|-------|--------------------------------|----------------------|

|       |                            |                    |
|-------|----------------------------|--------------------|
| F4.05 | Speed loop integral gain 2 | Range: 0~65535 【3】 |
|-------|----------------------------|--------------------|

|       |                                |                        |
|-------|--------------------------------|------------------------|
| F4.06 | Speed loop switching frequency | Range: 0.0%~100.0% 【3】 |
|-------|--------------------------------|------------------------|

|       |                                       |                        |
|-------|---------------------------------------|------------------------|
| F4.07 | D axis current loop proportional gain | Range: 0~65535 【10000】 |
|-------|---------------------------------------|------------------------|

|       |                                   |                       |
|-------|-----------------------------------|-----------------------|
| F4.08 | D axis current loop integral gain | Range: 0~65535 【2000】 |
|-------|-----------------------------------|-----------------------|

|       |                                       |                        |
|-------|---------------------------------------|------------------------|
| F4.09 | Q axis current loop proportional gain | Range: 0~65535 【10000】 |
|-------|---------------------------------------|------------------------|

|       |                     |                       |
|-------|---------------------|-----------------------|
| F4.10 | Q axis current loop | Range: 0~65535 【2000】 |
|-------|---------------------|-----------------------|

|               |  |
|---------------|--|
| integral gain |  |
|---------------|--|

## 7.6 Multi-function terminal (F5)

|       |                                        |                        |
|-------|----------------------------------------|------------------------|
| F5.00 | Function of multi-function terminal X1 | Range: 0~43 <b>【0】</b> |
| F5.01 | Function of multi-function terminal X2 | Range: 0~43 <b>【0】</b> |
| F5.02 | Function of multi-function terminal X3 | Range: 0~43 <b>【0】</b> |
| F5.03 | Function of multi-function terminal X4 | Range: 0~47 <b>【0】</b> |
| F5.04 | Function of multi-function terminal X5 | Range: 0~48 <b>【0】</b> |
| F5.05 | (Reserved)                             |                        |
| F5.06 | (Reserved)                             |                        |
| F5.07 | (Reserved)                             |                        |

The multi-function terminals can realize various functions. You may assign functions to them by setting parameters F5.00~F5.04. Please refer to Table 5-3. Take X1~X3 for example in the following description.

Table 5-2 Functions of multi-function terminals

| Setting | Functions                                      | Setting | Functions                                     |
|---------|------------------------------------------------|---------|-----------------------------------------------|
| 0       | No function                                    | 1       | MS frequency 1                                |
| 2       | MS frequency 2                                 | 3       | MS frequency 3                                |
| 4       | Acc/Dec time 1                                 | 5       | Acc/Dec time 2                                |
| 6       | External fault normally-open input             | 7       | External fault normally-closed input          |
| 8       | Reset signal                                   | 9       | Forward jog                                   |
| 10      | Reverse jog                                    | 11      | Coast-to-stop input                           |
| 12      | Frequency increase(UP)                         | 13      | Frequency decrease(DN)                        |
| 14      | PLC operation pause                            | 15      | Acc/Dec prohibit                              |
| 16      | 3-wire operation control                       | 17      | External interrupt signal normally-open input |
| 18      | External interrupt signal normally-close input | 19      | DC injection braking command                  |
| 20      | Disable close-loop                             | 21      | Disable PLC                                   |
| 22      | Frequency setting method 1                     | 23      | Frequency setting method 2                    |
| 24      | Frequency setting method 3                     | 25      | Reference freq. is input via CCI              |
| 26      | Reserved                                       | 27      | Terminal control mode is forcibly enabled     |

| Setting | Functions                               | Setting | Functions                               |
|---------|-----------------------------------------|---------|-----------------------------------------|
| 28      | Control mode 1                          | 29      | Control mode 2                          |
| 30      | MS close-loop 1                         | 31      | MS close-loop 2                         |
| 32      | MS close-loop 3                         | 33      | Start traverse operation                |
| 34      | Reset the travers operation status      | 35      | External stop command                   |
| 36      | Reserved                                | 37      | Inverter operation prohibiting          |
| 38      | Reserved                                | 39      | Clear length                            |
| 40      | Clear auxiliary reference frequency     | 41      | Reset PLC stop status                   |
| 42      | Clear counter record                    | 43      | Signal of triggering counter            |
| 44      | Input the signal of length              | 45      | Pulse input                             |
| 46      | Single phase speed measuring            | 47      | Speed measuring input SM1 (only for X4) |
| 48      | Speed measuring input SM2 (only for X5) |         |                                         |

The functions are explained as follows:

### 1~3: MS terminals

If any three of F5.00~F5.02 are set at 1, 2, 3 respectively, Up to 8 segments of speed can be defined through the combination of the ON and OFF state of the 3 terminals.

Table 5-3 MS Speed

| X <sub>3</sub> | X <sub>2</sub> | X <sub>1</sub> | Freq.        |
|----------------|----------------|----------------|--------------|
| OFF            | OFF            | OFF            | Common freq. |
| OFF            | OFF            | ON             | MS freq. 1   |
| OFF            | ON             | OFF            | MS freq. 2   |
| OFF            | ON             | ON             | MS freq.3    |
| ON             | OFF            | OFF            | MS freq.4    |
| ON             | OFF            | ON             | MS freq. 5   |
| ON             | ON             | OFF            | MS freq. 6   |
| ON             | ON             | ON             | MS freq. 7   |

The MS frequency will be used in MS running and simple PLC operation. e.g.: Set the parameters corresponding to X1, X2 and X3: F5.00=1, F5.01=2,

F5.02=3, then X1, X2 and X3 are used to perform MS running. See Figure 5-18.




Figure 5-18 MS Running

Figure 5-19 illustrated the wiring of terminal control of MS running. K4 and K5 control the running direction. The combination of K1, K2 and K3 can enable common running or MS running with 1~7 speeds.




Figure 5-19 Wiring of MS running

#### 4~5: Acc/Dec time terminal

Table 5-4 Acc/Dec Time Selection

| X2  | X1  | Acc/Dec time selection |
|-----|-----|------------------------|
| OFF | OFF | Acc time 1/ Dec time1  |
| OFF | ON  | Acc time 2/ Dec time 2 |
| ON  | OFF | Acc time 3/ Dec time 3 |
| ON  | ON  | Acc time 4/ Dec time 4 |

By combination of the ON/OFF state of Terminal 1 and 2, you can get 4 groups of Acc/Dec time.

#### 6~7: External fault signal (normally-open/close input)

If the setting is 6~7, fault signal of external equipment can be input via the terminal, which is convenient for the inverter to monitor the fault of external

equipment. Once the inverter receives the fault signal, it will display “F.ED”. The fault signal has two input modes, i.e. normally-open and normally-close.




Figure 5-20 Normally-open/close input

In Figure 5-20, X4 is normally open input and X5 normally close input. KM is external fault relay.

### 8: Reset

If any of F5.00~F5.04 is set at 8, the inverter can be reset via the terminal when the inverter has a fault. The function of this terminal is the same with the **RESET** key on the keypad.

### 9~10: External jog command (JOGF/JOGR)

If any of F5.00~F5.04 is set at 9~10, the terminal can enable the jog operation. JOGF is terminal for forward jog operation command and JOGR is terminal for reverse jog operation command. Jog frequency, jog interval and jog Acc/Dec time are defined in F9.05~F9.08.

### 11: Coast to stop

This function is the same with F2.08, however, it is realized by terminal and convenient for remote control.

### 12~13: Frequency increase (UP) /decrease (DN)

If the setting is 12~13, the terminal can be used to increase or decrease frequency instead of ▲ and ▼ keys on the panel for remote control. This terminal is valid when F0.00=1 or F0.03=2. Increasing or decreasing rate is determined by F5.09.

### 14: Pause command for simple PLC:

If the setting is 14, the terminal is used to pause the PLC operation and the inverter operates at zero frequency when the terminal is enabled, but the running time is not counted. If the terminal is disabled, the inverter will start at start frequency and continue the PLC operation. Refer to FD.00~FD.14 for the use of this terminal.

### 15: Acc/Dec prohibit

---

The motor is immune to any external command except Stop command and maintain the present speed.

---

Note:

**This function is disabled during normal decelerating to stop.**

**16: 3-wire operation control**

Refer to F5.08.

**17~18: External interrupt signal normally-open input**

When the inverter receives an interrupt signal during running, it will stop outputs and run at zero frequency. Once the signal removed, the inverter will resume previous running at start frequency.

As Figure 5-20 shows, there are X4, normally open contacts and X5, normally closed contact.

---

Note:

Different from function 6~7, the external interrupt signal will not cause alarm, and the inverter will resume previous running once the signal removed.

---

**19: DC Braking (DB)**

If the setting is 19, the terminal can be used to perform DC injection braking to the motor that is running for emergency stop and accurate location. Initial braking frequency, braking delay time and braking current are defined by F2.09~F2.11. Braking time is decided by the bigger value between F2.12 and the period that the terminal is effective.

**20: Disable close-loop**

If the setting is 20, the terminal can be used to realize the flexible switching between close-loop operation and low level operating mode.

When the inverter is switched to low level operating mode, its start/stop, operating direction, ACC/Dec time are shifted to the corresponding operating modes accordingly.

**21: Disable PLC**

If the setting is 21, the terminal is used to realize the flexible switching between PLC operation and low level operating mode.

When the inverter is switched to low level operating mode, its start/stop, operating direction, ACC/Dec time are shifted to the corresponding operating modes accordingly.

**22~24: Reference frequency setting method**

Through the combination of the ON/OFF state of X1, X2 and X3, you can select different frequency setting method, which will come into effect regardless of F0.02.

Table 5-5 Frequency Setting Mode Selection

| X3  | X2  | X1  | Mode               |
|-----|-----|-----|--------------------|
| OFF | OFF | OFF | None               |
| OFF | OFF | ON  | Digital setting 1  |
| OFF | ON  | OFF | Digital setting 2  |
| OFF | ON  | ON  | Digital setting 3  |
| ON  | OFF | OFF | VCI analog setting |
| ON  | OFF | ON  | CCI analog setting |
| ON  | ON  | OFF | Pulse              |
| ON  | ON  | ON  | LED keypad         |

## 25: Frequency reference is input via terminal CCI

If the setting is 25, the frequency reference will be input via terminal CCI forcibly. The frequency input will be changed to the previous one if this terminal function is disabled.

## 26: Reserved

## 27: Terminal control mode is enabled

When this terminal function is enabled, the operating command is input through this terminal forcibly. The inverter will be controlled in the previous mode if FWD/REV terminal function is disabled.

## 28~29: Control mode selection X1~X2

Table 5-6 Control Mode Selection

| X2  | X1  | Control mode |
|-----|-----|--------------|
| OFF | OFF | None         |
| OFF | ON  | LED keypad   |
| ON  | OFF | Terminal     |
| ON  | ON  | Serial port  |

The selection of control mode is realized by the combination of ON/OFF state of any two of X1~X5. In the above table, you should set F5.00=28, F5.01=29.

## 30~32: MS close-loop terminal (3 terminals of X1~X5)

Table 5-7 MS Close-loop Setting Selection

| X3  | X2  | X1  | MS close-loop reference |
|-----|-----|-----|-------------------------|
| OFF | OFF | OFF | By F5.01                |
| OFF | OFF | ON  | MS close-loop setting 1 |
| OFF | ON  | OFF | MS close-loop setting 2 |
| OFF | ON  | ON  | MS close-loop setting 3 |
| ON  | OFF | OFF | MS close-loop setting 4 |
| ON  | OFF | ON  | MS close-loop setting 5 |
| ON  | ON  | OFF | MS close-loop setting 6 |



|    |    |    |                         |
|----|----|----|-------------------------|
| ON | ON | ON | MS close-loop setting 7 |
|----|----|----|-------------------------|

The various MS close-loop setting is realized by the combination of ON/OFF state of terminal X1~X3. In the above table, you should set F5.00=30, F5.01=31, F5.02=32

### **33: Start traverse operation**

### **34: Reset the travers operation status**

### **35: External Stop command**

This Stop command is valid to all control modes. When this function is enabled, the inverter will stop as specified F2.08.

### **36: Reserved**

### **37: Prohibit inverter from operating**

If this function is enabled, the inverter that is operating will coast to stop and the inverter ready to run will be prohibited to start. This function is mainly used as safety protection.

### **38: Reserved**

### **39: Clear length**

### **40: Clear the setting of auxiliary reference frequency**

This function is valid for auxiliary reference frequency (F0.03=1, 2 and 3) to clear it to zero, so that the reference frequency is determined solely by main reference.

### **41: Reset PLC state**

When the inverter stops in PLC mode, the memorized PLC operating information (operating stage, operating time, operating frequency, etc.) will be cleared.

### **42: Clear the counter to zero**

This function is to clear the counter to zero and is used in conjunction with function 43.

### **43: Input signal to trigger the counter**

When the setting is 43, this terminal is used to input counting pulse signal to the internal counter of the inverter. The max.pulse frequency is 200Hz. The present counting value can be saved at power off. See F6.10 and F6.11 for details.

### **44:Input the signal of length**

### **45: Pulse frequency input**

This function is effective only to multi-function input terminals X4 and X5. The terminal is used to input pulse signal that is used as frequency reference.

Refer to F5 parameters for the relationship between input pulse frequency and the reference frequency.

#### 46: Single-phase speed measuring input

This function is effective only to multi-function input terminals X4 and X5. See section 3.2.3 for input characteristics. The speed control accuracy is .0.1%. Single-phase speed feedback control can be realized by using this terminal and PG.

#### 47: Speed measuring input SM1

#### 48: Speed measuring input SM2

This function is effective only to multi-function input terminals X4 and X5. See section 3.2.3 for input characteristics. The speed control accuracy is .0.1%. 2-phase speed feedback control can be realized by using this terminal and PG.

#### Note:

When the inverter is in motor auto-tuning status, No. 44~47 functions of X4 are disabled automatically.

|                             |                       |
|-----------------------------|-----------------------|
| F5.08 Terminal control mode | Range: 0~3 <b>【0】</b> |
|-----------------------------|-----------------------|

This parameter defines four operating modes controlled by external terminals.

0: 2-wire operating mode 1




Figure 5-21 2-wire Operation Mode 1

1: 2-wire operating mode 2

## SINUS VEGA




Figure 5-22 2-wire Operation Mode 2

### 2: 3-wire operating mode 1




Figure 5-23 3-wire Operation Mode 1

SB1: Stop button; SB2: Run forward button; SB3: Run reverse button  
Terminal Xi is the multi-function input terminal of X1~X5. For this case, the corresponding parameter should be set at 16 (3-wire operation).

### 3: 3-wire operating mode 2




Figure 5-24 3-wire Operation Mode 2

SB1: Stop button; SB2: Run button

Terminal Xi is the multi-function input terminal of X1~X5. For this case, the corresponding parameter should be set at 16 (3-wire operation).

**Note:**

In terminal control mode, for 2-wire operating mode 1 and 2, although the terminal is effective, the inverter will not run if there is external stop command. If you want to start the inverter, you should activate FWD/REV terminal again, e.g. set any of F5.00~F5.04 at 11 or 35, PLC stop after single cycle, stop after preset length arrival, Stop key pressed (see F9.21). When the inverter stops due to a fault, it will start immediately if the terminal FWD/REV is enabled and the fault is cleared.

|                  |                                         |
|------------------|-----------------------------------------|
| F5.09 UP/DN rate | Range: 0.01~99.99Hz/s <b>【1.00Hz/s】</b> |
|------------------|-----------------------------------------|

To define the increase/decrease rate when using UP/DN terminal to change reference frequency.

|                                                      |                                     |
|------------------------------------------------------|-------------------------------------|
| F5.10 Freq. Curve selection                          | Range: 000~111 <b>【000】</b>         |
| F5.11 Gain of reference frequency selector           | Range: 0.00~9.99 <b>【1.00】</b>      |
| F5.12 Filter constant                                | Range: 0.01~50.00s <b>【0.50s】</b>   |
| F5.13 Max. input pulse freq.                         | Range: 0.1~50.0kHz <b>【10.0kHz】</b> |
| F5.14 Ratio of Min. input of curve 1                 | Range: 0.0%~F5.16 <b>【2.0%】</b>     |
| F5.15 Frequency corresponds to min. input if curve   | Range: 0.0~F0.09 <b>【0.00Hz】</b>    |
| F5.16 Ratio of Max. input of curve1                  | Range: F5.14~100.0% <b>【100.0%】</b> |
| F5.17 Frequency corresponds to max. input of curve 1 | Range: 0.0~F0.09 <b>【50.00Hz】</b>   |
| F5.18 Ratio of Min. input of curve2                  | Range: 0.0%~F5.20 <b>【0.0%】</b>     |
| F5.19 Frequency corresponds to min. input            | Range: 0.0~F0.09 <b>【0.00Hz】</b>    |
| F5.20 Ratio of Max. input of curve 2                 | Range: F5.18~100.0% <b>【100.0%】</b> |
| F5.21 Frequency corresponds to max. input            | Range: 0.0~F0.09 <b>【50.00Hz】</b>   |

When selecting VCI and CCI or PULSE input as open loop setting method, the process is shown in Figure 5-25.




Figure 5-25 The process of setting reference freq.

After the input passes through the filter and gain processor, the relationship of its value and reference frequency is determined by curve 1 or curve 2, which are decided by F5.14~F5.17 and F5.18~F5.21 respectively. Both of them can work as positive or negative logic, as shown in Figure 5-26.




Figure 5-26 Reference freq. curve

When the analog input A is 100%, it is a 10V or 20mA signal and the reference frequency is the maximum; when the pulse input is 100%, it corresponds to F5.13 (max. input pulse frequency).

F5.12 defines the filter time. The longer the time, the stronger the immunity to disturbance, the slower the response, and vice versa.

F5.10 is to select the reference frequency curve of VCI, CCI and PULSE setting method, see Figure 5-27.




Figure 5-27 Frequency curve selection

Suppose you want to:

- ① set reference frequency by terminal pulse signal;
- ③ input signal range: 1kHz~20kHz;
- ④ 1kHz input for reference frequency 50Hz, 20kHz input for reference frequency 5Hz;

To meet the above requirement, you should set:

- ① F0.02=5, set terminal pulse mode;
- ② F5.03=45, input pulse signal from X4;
- ③ F5.10=100, select curve 2;
- ④ F5.13=20.0 kHz, set max. pulse frequency at 20kHz;
- ⑤  $F5.18 = 1 \div 20 \times 100\% = 5.0\%$ , to set the ratio of min input of curve 2 (1kHz) to F1.03 (20kHz) ;
- ⑥ F5.19=50.00Hz; reference frequency corresponds to min. input.
- ⑦  $F5.20 = 20 \div 20 \times 100\% = 100.0\%$ , to set the ratio of max. input of curve 2 (1kHz) to F.04 (20kHz);
- ⑧ F5.21=5.00Hz, to set the reference frequency corresponding to max. input.




Figure 5-28 Frequency Set By Pulse Signal

## 7.7 Output terminal control parameters (F6)

|       |                                   |                         |
|-------|-----------------------------------|-------------------------|
| F6.00 | Open collector output terminal Y1 | Range: 0~19 <b>【0】</b>  |
| F6.01 | Open collector output terminal Y2 | Range: 0~32 <b>【1】</b>  |
| F6.02 | Relay 1 output function           | Range: 0~19 <b>【16】</b> |
| F6.03 | Relay 2 output function           | Range: 0~19 <b>【16】</b> |

Refer to section 3.3.2 for the output characteristics of Y1, Y2 and the relay's output terminal. Table 5-8 shows the functions of the above 3 terminals. Note that one function can be selected repeatedly.

F6.01=20~32, Y2 is the output pulse frequency, range: 0~max. pulse frequency (F6.10). The relation between the output pulse frequency and the parameters it presents are shown in 20~32 in the table below. The extended function 2 of host is to control Y2 by serial port directly. The max setting of F6.10 is 65535.

Table 5-8 Parameter Setting and Function of Output Terminals

| Setting | Function                                     | Setting | Function                             |
|---------|----------------------------------------------|---------|--------------------------------------|
| 0       | Inverter running signal (RUN)                | 1       | Frequency arrival signal (FAR)       |
| 2       | Frequency detection threshold (FDT1)         | 3       | Frequency detection threshold (FDT2) |
| 4       | Overload signal (OL)                         | 5       | Low voltage lock-up signal (LU)      |
| 6       | External stop command (EXT)                  | 7       | Higher limit of frequency (FHL)      |
| 8       | Lower limit of frequency (FLL)               | 9       | Zero-speed running                   |
| 10      | Completion of simple PLC operation           | 11      | PLC cycle completion indication      |
| 12      | Preset counting value arrival                | 13      | Specified counting value arrival     |
| 14      | Preset length arrival                        | 15      | Inverter is ready (RDY)              |
| 16      | Inverter fails                               | 17      | Extended function 1 of host          |
| 18      | Upper and lower limits of traverse frequency | 19      | Preset operation time out            |

| Setting | Function                       | Range                                 |
|---------|--------------------------------|---------------------------------------|
| 20      | Freq. before slip compensation | 0~Max. output freq.                   |
| 21      | Freq. after slip compensation  | 0~Max. output freq.                   |
| 22      | Preset freq.                   | 0~Max. output freq.                   |
| 23      | Output current                 | 0~2 times of inverter rated current   |
| 24      | Output current                 | 0~2 times of inverter rated current   |
| 25      | Output torque                  | 0~2 times of inverter rated torque    |
| 26      | Output voltage                 | 0~1.2 times of inverter rated voltage |
| 27      | Bus voltage                    | 0~800V                                |

| Setting | Function                                                           | Range              |
|---------|--------------------------------------------------------------------|--------------------|
| 28      | VCI                                                                | 0~10V              |
| 29      | CCI                                                                | 0~10V/0~20mA       |
| 30      | Output power                                                       | 0~2 of rated power |
| 31      | Extended function 2 of host                                        | 0~65535            |
| 32      | Potentiometer setting(for power rate lower thanSINUS VEGA 0005 4T) | 0~10V              |

The explanation of output signal is shown in Table 5-8.

0: Inverter running signal (RUN)

This signal will be given if the inverter is running.

1: Frequency arrival signal (FAR)

See F6.13.

2: Frequency detection threshold (FDT1)

See F6.14~F6.15.

3: Frequency detection threshold (FDT2)

See F6.16~F6.17.

4: Overload signal (OL)

The signal will be given if the inverter's output current is bigger than the value defined by FL.05 and the overload time is longer than the time defined by FL.06. This function is usually used for overload pre-alarm. See Figure5-78.

5: Low voltage lock-up signal (LU)

The signal will be given when the DC bus voltage is lower than the low voltage limit, and the LED displays “-LU-”.

6: External stopping command (EXT)

The terminal outputs the indicating signal if the inverter outputs tripping signal caused by external fault (F.Ed).

7: Higher limit of frequency (FHL)

The signal is given if the preset frequency is higher than upper limit of frequency and the operating frequency reaches the upper limit of frequency.

8: Lower limit of frequency (FLL)

The signal is given if the preset frequency is higher than lower limit of frequency and the operating frequency reaches the lower limit of frequency.

9: Zero-speed running

The signal is given if the inverter's output frequency is 0 and the inverter is in operating status.

10: Completion of simple PLC operation stages



The signal is given (pulse, 500ms) if the present stage of PLC operation is finished.

11: PLC cycle completion indication

The signal (pulse, 500ms) is given if one cycle of PLC operation is finished.

12: preset counting value arrival

13: reference length arrival

Refer to F6.11~F6.12.

14: preset length arrival

The signal is given if the setting of FC.09 (actual length) is bigger than FC.08 (preset length). The length counting terminal is the one whose parameter (F5.03 or F5.04) is set at 44.

15: Inverter is ready (RDY)

The RDY signal is output when the inverter has no fault, its DC bus voltage is normal; the Start Prohibit function is disabled. It is ready to start.

16: Inverter fails

The signal is given if the inverter has faults.

17: Extended function 1 of host

The output signal of terminal Y1, Y2 or TC is directly controlled by a serial port. Refer to the communication protocol of SINUS VEGA.

18: Upper and lower limits of traverse frequency

19: preset operating time out

The signal is given if the inverter's total operating time (FN.01) reaches preset operating time (FN.00).

|       |                     |                        |
|-------|---------------------|------------------------|
| F6.04 | AO1 output function | Range: 0~12 <b>【0】</b> |
| F6.05 | AO2 output function | Range: 0~12 <b>【3】</b> |
| F6.06 | Reserved            |                        |

AO1 and AO2 are analog output terminals.

Refer to section 3.3.2 for the output characteristics of AO1 and AO2.

Refer to Table 5-9 for the function of F6.04 and F6.05.

Table 5-9 Signals from AO1 and AO2

| Setting | Function                         | Range                                 |
|---------|----------------------------------|---------------------------------------|
| 0       | Output freq. before compensation | 0~Max. output freq.                   |
| 1       | Output freq. after compensation  | 0~Max. output freq.                   |
| 2       | Preset freq.                     | 0~Max. output freq.                   |
| 3       | Output current                   | 0~2 times of inverter's rated current |
| 4       | Output current                   | 0~2 times of motor's rated            |

| Setting | Function                    | Range                                   |
|---------|-----------------------------|-----------------------------------------|
|         |                             | current                                 |
| 5       | Output torque               | 0~2 times of motor's torque             |
| 6       | Output voltage              | 0~1.2 times of inverter's rated voltage |
| 7       | Bus voltage                 | 0~800V                                  |
| 8       | VCI                         | 0~10V                                   |
| 9       | CCI                         | 0~10V/0~20Ma                            |
| 10      | Output power                | 0~2 times of rated power                |
| 11      | Extended function 2 of host | 0~65535                                 |
| 12      | Setting of potentiometer    | 0~10V                                   |

Using extended function 2 of host, AO1 and AO2 output can be controlled by serial port directly, the output of AO1 or AO2 “65535” corresponds to max. analog output 10V (20mA) .

Suppose you want:

AO1 outputs 4~20mA, which means the bus voltage is 0~800V.

You should do the following configuration:

- ② F6.04=7, output signal presenting bus voltage;
- ② F6.07=01, AO1 output: 4~20mA;
- ③ P6.08=100%, output gain 100%;
- ④ Select 0/4-20mA of CN4 (J2 OR SW2) jumper.

**Note:**

When X5 is select as 44~46, Y2 pulse output will be invalid.

|                           |                   |
|---------------------------|-------------------|
| F6.07 Analog output range | Range: 00~11 【00】 |
|---------------------------|-------------------|




Figure 5-30 Analog Output Type Selection

The parameter is to select the output type, i.e. voltage or current, of AO1 and AO2.

CN4(J2 OR SW2) jumper is for AO1, “I” represents current, “V” represents voltage.

CN5(J3 OR SW3) jumper is for AO2, “I” represents current, “V” represents voltage.

|                       |                                   |
|-----------------------|-----------------------------------|
| F6.08 AO1 output gain | Range: 0.0~200.0% <b>【100.0%】</b> |
| F6.09 AO2 output gain | Range: 0.0~200.0% <b>【100.0%】</b> |

You can change the measurement range or calibrate error of AO1 and AO2 outputs by adjusting the output gain.

Note:

The parameter will come into effect immediately while you change it.

|                                       |                                     |
|---------------------------------------|-------------------------------------|
| F6.10 Y2 Max output pulse freq. of Y2 | Range: 0.1~50.0kHz <b>【10.0KHz】</b> |
|---------------------------------------|-------------------------------------|

It defines the max. pulse frequency from terminal Y2. Refer to P6.11.

|                                |                              |
|--------------------------------|------------------------------|
| F6.11 Preset counting value    | Range: F6.11~9999 <b>【0】</b> |
| F6.12 Specified counting value | Range: 0~F6.10 <b>【0】</b>    |

F6.11 and F6.12 are complementary to Function No.12 and No.13 in Table 5-9.

When the number of pulses defined by F6.11 are input from Xi, Yi or relay will output an indicating signal.

Suppose F6.11=8, as Figure 5-31 shows, when 8 consecutive pulses are input from Xi, Y1 will output an indicating signal.

When the number of pulses defined by F6.12 are input from Xi, Yi or relay will output an indicating signal which will last until the number of pulses defined by F6.11 are input.

Suppose F6.12=5, 6.11=8, as Figure 5-31 shows, when 5 consecutive pulses are input from Xi, Y2 will output an indicating signal and it holds the signal until the 8th pulse passes. Note that if F6.12 is bigger than F6.11, then F6.12 is invalid.




Figure 5-31 Preset counting value and specified counting value

|                                           |                                      |
|-------------------------------------------|--------------------------------------|
| F6.13 Freq. arrival detection range (FAR) | Range: 0.00~650.00Hz <b>【2.50Hz】</b> |
|-------------------------------------------|--------------------------------------|

As shown in Figure 5-32, if the inverter's output frequency is within the detecting range of preset frequency, a pulse signal will be output. It is complementary to No.1 function in Table 5-8.




Figure 5-32 Freq. Arrival Signal Output

|       |            |                                |
|-------|------------|--------------------------------|
| F6.14 | FDT1 level | Range: 0.00~650.00Hz 【50.00Hz】 |
| F6.15 | FDT1 lag   | Range: 0.00~650.00Hz 【1.00Hz】  |
| F6.16 | FDT2 level | Range: 0.00~650.00Hz 【25.00Hz】 |
| F6.17 | FDT2 lag   | Range: 0.00~650.00Hz 【1.00Hz】  |

F6.14~F6.15 is a complement to the No.2 function in Table 5-8. F6.16~F6.17 is a complement to the No.3 function in Table 5-8. Their functions are same. Take F6.14~F6.15 for example: when the inverter's output frequency reaches FDT1 level, it outputs an indicating signal until its output frequency drops below FDT1 level (FDT1 level-FDT1 lag). As shown in Figure 5-33.




Figure 5-33 Frequency Detection

## 7.8 Close-loop control (F7)

Usually, the close loop control can be divided into two types: analog close loop and pulse close loop according to feedback. Figure 5-34 and Figure 5-35 are analog and pulse close loop control wiring diagram.




Figure 5-34 Build-in PI Analog Feedback Control




Figure 5-35 PG Speed Close Loop Control System

Analog feedback control system:

An analog feedback control system can be formed by a pressure transducer as the feedback sensor of the internal PI.

As shown in Figure 5-34, pressure reference (voltage signal) is input via terminal VCI, while the feedback pressure value is input to terminal CCI in the form of 0~20mA current signal. The reference signal and feedback signal are detected by the analog channel. The start and stop of the inverter can be controlled by terminal FWD.

The above system can also use a TG (speed measuring generator) as speed close speed-loop control.

PG speed close-loop control:

A speed close-loop control system can be formed by external control terminals X4 and X5, and pulse generator (PG) .

As shown in Figure 5-35, close speed-loop input can come from a potentiometer in the form of voltage signal via terminal VCI, while the

feedback value of the close loop is input by PG in pulse mode via terminal X4 and X5. The start and stop of the inverter can be controlled by terminal FWD.

In Figure 5-35,

A and B are PG's dual phase quadrature output;

P24 is connected to the power source of PG;

Speed reference is the voltage signal of 0~10V. The voltage signal corresponds to synchronous speed  $n_0$  which, in turn, corresponds to 0~Max frequency (F0.09). P is the number of poles of motor (FH.00).

$$n_0 = 120 \times f_{\max} / P$$

Refer to function No. 47~48 of F5.00~F5.04 for the functions of input terminals X4, X5.

#### Note:

1. The reference can also be input via keypad or serial port;
2. Dual-phase input can improve the speed measurement accuracy, while single phase input wiring is simple;
3. Dual-phase pulse can only be input in quadrature mode;
4. If PG is supplied from terminal P24, then the max load current of optical PG must be less than 100mA.

The mechanism of the build-in PI is shown in the figure below:




Figure 5-36 PI Working Mechanism

In Figure 5-36, KP: proportional gain. KI: integral, refer to F7.01~F7.15 for the definitions of close-loop reference, feedback, error limit and proportional and Integral parameters.

There are two features of internal PI:

The relationship between reference and feedback can be defined by F7.08~F7.11.

For example: In Figure 5-34, if the reference is 0~10V analog signal, the expected controlled value is 0~1MP, and the pressure signal is 4~20mA, then the relationship between reference and feedback is shown in Figure 5-37.




Figure 5-37 Reference (Input) and Feedback

The reference value is based on 10V (i.e. 10V means 100% input); and the feedback value is based on 20mA (20mA corresponds to 100% output).

Close-loop characteristic is selected through F7.16 to satisfy different applications.

In order to meet the control requirements, the motor's speed should be increased with reference speed. This kind of control characteristic is called positive response. If the motor speed is required to be decreased when the reference value is increased, this control characteristic is called negative response.

See Figure 5-38. F7.16 defines the two characteristics.




Figure 5-38 Close-loop control Characteristics

After the system type is determined, the following procedures can be used to determine the close loop parameters:

- ① Determine the close-loop reference and feedback channel (F7.01 and F7.02) ;
- ② Define the relationship between close-loop reference and feedback value (F7.08~F7.11);
- ③ Determine the speed reference of speed close-loop control and the number of revolutions of PG (F7.06~F7.07) ;
- ④ Determine the close-loop regulation characteristic, that is, if the motor speed decreases while the input reference increases, then the close-loop control characteristic should be set to negative (F5.16=1) ;
- ⑤ Set integral regulation and close-loop frequency (F7.17~F7.19) ;

⑥ Adjust close-loop filter time, sampling cycle, bias limit and gain factor (F7.12~F7.15).

|                          |                       |
|--------------------------|-----------------------|
| F7.00 Close-loop control | Range: 0、1 <b>【0】</b> |
|--------------------------|-----------------------|

0: Disabled

1: Enabled

|                              |                       |
|------------------------------|-----------------------|
| F7.01 Reference input method | Range: 0~2 <b>【1】</b> |
|------------------------------|-----------------------|

0: digital setting

Take the value of F7.05 (set analog close-loop feedback, F7.02=0~5) ;

Take the value of F7.06 (set pulse close-loop feedback, F7.02=6) .

1: VCI (0~10V)

2: CCI

Pay attention to the setting of jumper CN7(J1 OR SW1).

3: LED keypad (for power rate lower than SINUS VEGA 0005 4T)

4: PULSE (for power rate lower than SINUS VEGA 0005 4T)

Note:

The motor speed is controlled by pulse feedback. Given analog input 10V (20mA) or max. input frequency F1.04, the output pulse will be max. frequency F0.09, which corresponds to the motor synchronous speed  $n_0$  ( $n_0 = 120f_{max}/P$ ).

|                       |                       |
|-----------------------|-----------------------|
| F7.02 Feedback method | Range: 0~6 <b>【1】</b> |
|-----------------------|-----------------------|

0: VCI analog voltage 0~10V

1: CCI analog input

2: VCI+CCI

3: VCI-CCI

4: Min{VCI, CCI}

5: Max{VCI, CCI}

When current input is selected, the signal will be converted to voltage signal, whose value is determined by the formula:  $V_{out} = m A / 2$ ;

F7.02=6: Pulse

It can be single-phase or 2-phase PG close loop feedback. Please refer to multi-function input terminal X4, X5 (F7.03~F7.04).

|                       |                                   |
|-----------------------|-----------------------------------|
| F7.03 Input filter    | Range: 0.01~50.00s <b>【0.50s】</b> |
| F7.04 Feedback filter | Range: 0.01~50.00s <b>【0.50s】</b> |



Both the input signal and feedback signal have some noise signals. These signals can be filtered by setting the time constant of filter (settings of F7.03 and F7.04) . The bigger the time constant, the better the immunity capability, but the response becomes slow. The smaller the time constant, the faster the response, but the immunity capability becomes weak.

|                               |                                  |
|-------------------------------|----------------------------------|
| F7.05 Digital reference input | Range: 0.00~10.00V <b>【0.00】</b> |
|-------------------------------|----------------------------------|

When analog feedback is selected (F7.02=0~5) , this function allows parameter setting from keypad or serial port.

|                                |                                  |
|--------------------------------|----------------------------------|
| F7.06 Speed close-loop setting | Range: 0~39000rpm <b>【0 rpm】</b> |
|--------------------------------|----------------------------------|

When PG pulse feedback is selected (F5.02=6) , speed can be set through keypad or serial port.

|                                              |                             |
|----------------------------------------------|-----------------------------|
| F7.07 Pulse number per revolution of encoder | Range: 1~9999 <b>【1024】</b> |
|----------------------------------------------|-----------------------------|

Please set this parameter according to the characteristics of the pulse encoder.

|                              |                                     |
|------------------------------|-------------------------------------|
| F7.08 Min. input             | Range: 0.0%~F7.10 <b>【0.0%】</b>     |
| F7.09 Feedback of min. input | Range: 0.0~100.0% <b>【20.0%】</b>    |
| F7.10 Max. input             | Range: F7.08~100.0% <b>【100.0%】</b> |
| F7.11 Feedback of max. input | Range: 0.0~100.0% <b>【100.0%】</b>   |

F7.08~F7.11 define the relation of analog close loop input and feedback. The values of the above parameters are percentage of input or feedback value to reference value (10V or 20mA or F5.13) .




Figure 5-39 Relation of Input and Feedback

|                         |                                         |
|-------------------------|-----------------------------------------|
| F7.12 Proportional gain | Range: 0.000~9.999 <b>【2.000/0.050】</b> |
| F7.13 Integral gain     | Range: 0.000~9.999 <b>【0.100/0.050】</b> |

|                      |                                  |
|----------------------|----------------------------------|
| F7.14 Sampling cycle | Range: 0.01~50.00s 【0.10s/0.50s】 |
|----------------------|----------------------------------|

The bigger the proportional gain, the faster the response, but oscillation may occur easily if proportional gain is too big.

If only proportional gain is used in regulation, the error cannot be eliminated completely. Therefore, it is preferred to use the integral gain to form a PI control system. The bigger the integral gain, the faster the response, but oscillation may occur if integral gain is too big.

F7.14 refers to the sampling cycle of feedback value. The PI regulator calculate once in each sampling cycle. The bigger the sampling cycle the slower the response.

|                   |                       |
|-------------------|-----------------------|
| F7.15 Error limit | Range: 0.0~20% 【2.0%】 |
|-------------------|-----------------------|

F7.15 is the max. error between system output and the close-loop reference, as shown in Figure 5-40. PI regulator stops operation when the feedback error is within this range. Setting this parameter correctly is helpful to improve the system output accuracy and stability.




Figure 5-40 Error Limit Schematic Diagram

|                                             |                |
|---------------------------------------------|----------------|
| F7.16 Close-loop regulation characteristics | Range: 0、1 【0】 |
|---------------------------------------------|----------------|

0: Positive logic

Set F7.16 to 0 if the motor speed is required to increase with the reference.

1: Negative logic

SetF7.16 to 1 if the motor speed is required to decrease with the increase of the reference.

|                           |                |
|---------------------------|----------------|
| F7.17 Integral regulation | Range: 0、1 【0】 |
|---------------------------|----------------|

0: Stop integral regulation when the frequency reaches theupper or lower limits

1: Continue the integral regulation when the frequencyreaches the upper or lower limits

It is recommended to set the parameter at 0 for the system that requires fast response.

|                                  |                               |
|----------------------------------|-------------------------------|
| F7.18 Preset frequency           | Range: 0.00~650.00Hz 【0.00Hz】 |
| F7.19 Preset frequency hold time | Range: 0.0~3600s 【0.00s】      |

The above parameters are helpful for the close loop control to enter stable state quickly.

After close-loop running is started, the inverter will accelerate to the preset frequency F7.18 within the accelerate time, and hold the frequency for a period of time (F7.19) , and then run according to close-loop characteristic.




Figure 5-41 Close-loop preset frequency

Note:

If you don't need preset frequency, just set F7.18 and F7.19 at 0.

## 7.9 MS parameters (F8)

|                  |                                          |
|------------------|------------------------------------------|
| F8.00 MS freq. 1 | Range: lower limit~upper limit 【 5.00Hz】 |
| F8.01 MS freq. 2 | Range: lower limit~upper limit 【10.00Hz】 |
| F8.02 MS freq. 3 | Range: lower limit~upper limit 【20.00Hz】 |
| F8.03 MS freq. 4 | Range: lower limit~upper limit 【30.00Hz】 |
| F8.04 MS freq. 5 | Range: lower limit~upper limit 【40.00Hz】 |
| F8.05 MS freq. 6 | Range: lower limit~upper limit 【45.00Hz】 |
| F8.06 MS freq. 7 | Range: lower limit~upper limit 【50.00Hz】 |

These frequencies will be used in simple PLC operation and multi-speed operation, refer to the introductions of F5.00~F5.04 and group PD parameters.

|                               |                           |
|-------------------------------|---------------------------|
| F8.07 MS close-loop setting 1 | Range: 0.0~10.00V 【0.00V】 |
| F8.08 MS close-loop setting2  | Range: 0.0~10.00V 【0.00V】 |
| F8.09 MS close-loop setting 3 | Range: 0.0~10.00V 【0.00V】 |
| F8.10 MS close-loop setting 4 | Range: 0.0~10.00V 【0.00V】 |
| F8.11 MS close-loop setting 5 | Range: 0.0~10.00V 【0.00V】 |
| F8.12 MS close-loop setting 6 | Range: 0.0~10.00V 【0.00V】 |
| F8.13 MS close-loop setting 7 | Range: 0.0~10.00V 【0.00V】 |

Besides the 3 close-loop setting methods, the MS close-loop voltage setting F5.20~F5.26 can also be used.

MS close-loop setting 1~7 can be selected through external terminals, please refer to F5.00~F5.04 (function No. 30~32) . It can also used with simple PLC close-loop, see FD parameters.

The MS close-loop setting has priority over the methods defined in F7.01.

|       |            |                                     |
|-------|------------|-------------------------------------|
| F8.14 | Acc time 2 | Range: 0.1~3600s (min) 【6.0s/20.0s】 |
| F8.15 | Dec time 2 | Range: 0.1~3600s (min) 【6.0s/20.0s】 |
| F8.16 | Acc time 3 | Range: 0.1~3600s (min) 【6.0s/20.0s】 |
| F8.17 | Dec time 3 | Range: 0.1~3600s (min) 【6.0s/20.0s】 |
| F8.18 | Acc time 4 | Range: 0.1~3600s (min) 【6.0s/20.0s】 |
| F8.19 | Dec time 4 | Range: 0.1~3600s (min) 【6.0s/20.0s】 |

Three kinds of Acc/Dec time can be defined, and the inverter's Acc/Dec time 1~4 can be selected by different combinations of control terminals, refer to F5.00~F7.07 for the definitions of terminals used to select Acc/Dec time.

Note:

Acc time 1 and Dec time 1 is defined in F0.12 and F0.13 respectively.

## 7.10 Enhanced function (F9)

|                                  |                   |
|----------------------------------|-------------------|
| F9.00 FDigital frequency control | Range: 00~11 【00】 |
|----------------------------------|-------------------|

Valid only when F0.02=0、1、2.




Figure 5-42 F9.00 setting

One's place of F9.00:

0: when the inverter is powered off or at undervoltage state, update F0.04 by the actual frequency at that time.

1: when the inverter is powered off or at undervoltage state, F0.04 remains unchanged.

Ten's place of F9.00:

0: the reference frequency when the inverter stops will be saved.

1: The reference frequency will restore to F0.04 when the inverter stops.

|                               |                       |
|-------------------------------|-----------------------|
| F9.01 FWD/REV transition time | Range: 0~3600s 【0.0s】 |
|-------------------------------|-----------------------|

It refers to the time period when the inverter's rotation changes from FWD to REV or REV to FWD, see Figure 5-43 as  $t_i$ .




Figure 5-43 Transition time from FWD to REV

|                              |                                         |
|------------------------------|-----------------------------------------|
| F9.02 Carrier wave frequency | Range: 0.7~15.0kHz 【depending on model】 |
|------------------------------|-----------------------------------------|

Table 5-10 Relation of Model and Carrier Freq

| Model \ CWF                                                | Max CWF (kHz) | Min CWF (kHz) | Default (kHz) |
|------------------------------------------------------------|---------------|---------------|---------------|
| Heavy duty: 0.75kW~4.0KW                                   | 15            | 0.7           | 8             |
| Heavy duty: 5.5kW~15kW<br>Normal duty: 7.5kW~18.5kW        | 15            | 0.7           | 8             |
| Heavy duty: 18.5kW~45kW<br>Normal duty: 22kW~55KW          | 10            | 0.7           | 4             |
| Heavy duty: 55kW~75kW<br>Normal duty: 75kW~90kW            | 6             | 0.7           | 3             |
| Heavy duty: 90kW and above<br>Normal duty: 110kW and above | 3             | 0.7           | 2             |

Table 5-11 Carrier Freq. and Performance

| Carrier wave Freq. | Decreasing | Increasing |
|--------------------|------------|------------|
| Motor noise        | ↑          | ↓          |
| Leakage current    | ↓          | ↑          |
| Interference       | ↓          | ↑          |

Note:

1. To get the best control effect, the ratio of carrier wave frequency to the max. operating frequency of the inverter should be lower than 36.
2. The displayed current might have error when the carrier frequency is lower.

|                           |                |
|---------------------------|----------------|
| F9.03 CWF auto adjustment | Range: 0、1 【1】 |
|---------------------------|----------------|

0: Disabled

1: Enabled

When CWF auto adjustment is enabled, the inverter can adjust CWF automatically according to the temperature inside the inverter.

|                  |                 |
|------------------|-----------------|
| F9.04 Motor tone | Range: 0~10 【0】 |
|------------------|-----------------|

If CWF is set under 6 kHz, tuning this parameter can change the tone of operating motor.

If it is set at 0, the function is disabled.

|                     |                               |
|---------------------|-------------------------------|
| F9.05 Jog frequency | Range: 0.10~650.00Hz 【5.00Hz】 |
| F9.06 Jog interval  | Range: 0.0~100.0s 【0.0s】      |
| F9.07 Jog Acc time  | Range: 0.1~60.0s 【6.0s/20.0s】 |
| F9.08 Jog Dec time  | Range: 0.1~60.0s 【6.0s/20.0s】 |

F9.05~F9.08 define parameters related to jog.

As Figure5-44 shows, t1 and t3 are actual jog Acc and Dec time; t2 is jog time; t4 is the interval between jog (F9.06) , F1 is jog frequency (F9.05) .

Actual jog Acc and Dec time are calculated by the formula below:

$$t_1 = \frac{F9.05 \times F9.07}{F0.09} \quad t_3 = \frac{F9.05 \times F9.08}{F0.09}$$




Figure 5-44 Jog Parameters Illustration

interval of Jog operation (F9.06) is the period between two executed jog commands. The jog command sent during the interval is invalid, and the

inverter continues to operate at zero frequency. If this command exists until the end of the interval, it will be executed.

**Note:**

1. In Jog operation process, the inverter starts according to starting mode 0 and stops according to stopping mode 0. The unit of Acc/Dec time is second.
2. Jog operation can be controlled by terminals and serial port.

|       |                    |                               |
|-------|--------------------|-------------------------------|
| F9.09 | Skip freq. 1       | Range: 0.00~650.00Hz 【0.00Hz】 |
| F9.10 | Skip freq. 1 range | Range: 0.00~30.00Hz 【0.00Hz】  |
| F9.11 | Skip freq. 2       | Range: 0.00~650.00Hz 【0.00Hz】 |
| F9.12 | Skip freq. 2 range | Range: 0.00~30.00Hz 【0.00Hz】  |
| F9.13 | Skip freq. 3       | Range: 0.00~650.00Hz 【0.00Hz】 |
| F9.14 | Skip freq.3 range  | Range: 0.00~30.00Hz 【0.00Hz】  |

F9.09~F9.14 are used to skip the mechanical resonant frequency of load.

The inverter's preset frequency can skip some frequency as shown in Figure 5-45. Three skip frequency at most can be set.




Figure 5-45 Skip Frequency and Its Range

|                                              |                        |
|----------------------------------------------|------------------------|
| F9.15 Positive or negative logic of terminal | Range: 000~FFFH 【000H】 |
|----------------------------------------------|------------------------|




Figure 5-46 Positive or Negative Logic of Terminals

The parameter defines the positive or negative logic of terminals, where positive logic refers that the terminal Xi is enabled when it connects with the common terminal and disabled if disconnected; negative logic is the opposite of positive logic.

If the bit is set at “0”, it means positive logic, and “1” for negative logic.

Suppose you require X1~X5 to be positive logic, FWD and REV negative logic, Y1 positive logic and Y2 negative logic, you should set the one’s place at 0, ten’s place at 0, hundred’s place at (1011) 2 , i.e B (Hex) . Therefore, F9.15 should be set at 0B00.

The conversion from binary code to Hex value is shown in Table 5-12.

Table 5-12 Conversion from Binary to Hex

| Binary |      |      |      | Hex<br>(LED display) |
|--------|------|------|------|----------------------|
| BIT3   | BIT2 | BIT1 | BIT0 |                      |
| 0      | 0    | 0    | 0    | 0                    |
| 0      | 0    | 0    | 1    | 1                    |
| 0      | 0    | 1    | 0    | 2                    |
| 0      | 0    | 1    | 1    | 3                    |
| 0      | 1    | 0    | 0    | 4                    |
| 0      | 1    | 0    | 1    | 5                    |
| 0      | 1    | 1    | 0    | 6                    |
| 0      | 1    | 1    | 1    | 7                    |
| 1      | 0    | 0    | 0    | 8                    |
| 1      | 0    | 0    | 1    | 9                    |
| 1      | 0    | 1    | 0    | A                    |
| 1      | 0    | 1    | 1    | B                    |
| 1      | 1    | 0    | 0    | C                    |
| 1      | 1    | 0    | 1    | D                    |
| 1      | 1    | 1    | 0    | E                    |
| 1      | 1    | 1    | 1    | F                    |

Note:

1. Factory setting of all the terminals is positive logic.
2. When Y2 is set to output pulse, i.e. F6.01 is set at 20~32, the logic definition is invalid.

|                                                           |                      |
|-----------------------------------------------------------|----------------------|
| F9.16 operating command bundled with freq. setting method | Range: 000~777 【000】 |
|-----------------------------------------------------------|----------------------|

This function defines the combination of 3 operating command and 7 frequency setting method, so that they can be switched at the same time.






Figure 5-47 Operating command bundled with freq. Setting method

The reference frequency setting method is defined by F0.02, see section 5.1 for details.

Different control modes can bundle to one reference frequency setting method.

You may follow the methods below to change control command and frequency setting method simultaneously.

Method 1: Change F0.00;

Method 2: use terminal X1~X5 function No. 28 and 29.

For example: In order to realize remote and local control, it requires that:

- ① Control modes selection: The control modes can be selected by terminal remotely or by F0.00 locally;
- ② If keypad (panel) control mode is used, press **RUN** to run the inverter and press **STOP** to stop the inverter. The preset frequency can be adjusted by pressing **▲** and **▼**.
- ③ If terminal control mode is used, close **FWD** to run forward and close **REV** to run reverse. The preset frequency is adjusted via VCI.
- ④ Terminal control mode is enabled after the inverter is switched on.




Figure 5-48 Local and remote control

To meet the above requirements:

Set F0.00=1, to select terminal control mode and remotecontrol is enabled after the inverter is switched on;

Set F5.00=28, and F5.01=29 to select multi-function inputterminal X1 and X2 to input operating commands;

Set F5.08=1 to select 2-wire control mode 2. The inverter runforward when FWD is enabled, and run reverse when REV isenabled;

Set F9.16=041, then terminal control mode is bundled to VCIanalog input, and the panel control mode is bundled to digitalsetting 1.




Figure 5-49 Wiring for Remote and Local Control

**Note:**

If factory setting is 000, no bundling of operating command and frequency setting method.

|                                           |                         |
|-------------------------------------------|-------------------------|
| F9.17 Auxiliary reference factor          | Range: 0.00~9.99 【1.00】 |
| F9.18 Digital auxiliary reference control | Range: 000~111 【000】    |

The preset frequency is the final result of the combination of main frequency and auxiliary frequency. F0.03、F0.05、F9.17、F9.18 are for auxiliary frequency. Figure5-50 shows the course of frequency combination.




Figure 5-50 Preset Freq. Calculation Method




Figure 5-51 Auxiliary Frequency Processing

Table 5-13 Auxiliary Freq. Setting Method

| Setting | Description                           | Note                                                                                                 |
|---------|---------------------------------------|------------------------------------------------------------------------------------------------------|
| 0       | No auxiliary freq.                    | Auxiliary freq.=0                                                                                    |
| 1       | Digital setting 1, adjust by ▲ and ▼  | Set by F0.05 whether the frequency before power failure will be saved depending the setting of F9.18 |
| 2       | Digital setting 2, adjust by UP/DN    |                                                                                                      |
| 3       | Digital setting 3, set by serial port |                                                                                                      |
| 4       | VCI analog setting                    | Depending on actual input. Refer to F5.10                                                            |
| 5       | CCI analog setting                    |                                                                                                      |
| 6       | Terminal PULSE setting                |                                                                                                      |
| 7       | - VCI analog setting                  |                                                                                                      |
| 8       | - CCI analog setting                  |                                                                                                      |
| 9       | -Terminal PULSE setting               |                                                                                                      |
| 10      | VCI-5                                 |                                                                                                      |
| 11      | CCI-5                                 |                                                                                                      |
| 12      | PULSE-0.5×F5.13                       |                                                                                                      |

| Setting | Description                         | Note |
|---------|-------------------------------------|------|
| 13      | Potentiometer (For 4.0KW and below) |      |

Select digital setting 3, you may set F0.05 via serial port to change auxiliary frequency.

If VCI-5 or CCI-5 is selected, take 5V input as the point corresponding to zero frequency, 0~5V input corresponds to negative output, 5~10V input corresponds to positive output. See Figure5-52.





Figure 5-52 Frequency Setting via VCI-5 or CCI-5

If PULSE-0.5 × F1.03 is taken as auxiliary frequency setting method, one half of F5.13 (max. pulse freq.) as the point corresponding to zero frequency, 0~0.5 times of F5.13 input corresponds to negative output, 0.5~1 times of F5.13 input corresponds to positive output. See Figure5-33:



P mid—1/2\*max. input pulse frequency(F5.13)

Fmax—frequency corresponds to max. analog value(F5.17 or F5.21)

Figure 5-53 PULSE-0.5×F5.13 as Frequency Input

F9.17: Analog auxiliary reference factor:

It is valid when F9.03=4~12. The auxiliary reference undergoes F9.17 gain calculation first, and then output according to F5.10.

F0.05: initial value of digital auxiliary reference:

It is valid when F0.03=1~3. It is the initial setting of any of the 3 method.

# F9.18: digital auxiliary reference control

It is valid when F0.03=1~3. See Figure 5-54.




Figure 5-54 Digital Auxiliary Freq. Setting

## One's place of F9.18

0: save the auxiliary freq. at power off

The auxiliary frequency will be saved in F0.05, and the sign of the freq. saved in F9.18.

1: not save the auxiliary freq. at power off

## Ten's place of F9.18

0: maintain the auxiliary freq. if the inverter stops

1: preset frequency is cleared if the inverter stops

## Hundred's place of F9.18: sign of auxiliary freq.

0: (+) positive sign.

Preset freq. is the sum of main freq. and auxiliary freq.

1: (+) negative sign

Preset freq. is the result of main freq. minus auxiliary freq.

## Note:

When the inputting mode of auxiliary reference frequency is the same with that of main reference frequency, the auxiliary reference frequency setting is invalid.

|                                           |                             |
|-------------------------------------------|-----------------------------|
| F9.19 Preset freq. adjust mode            | Range: 0~2 【0】              |
| F9.20 Factor for calculating preset freq. | Range: 0.0%~200.0% 【100.0%】 |

F9.19 defines how to calculate the preset frequency. Refer to Figure 5-1.

0: disabled

No additional summing operation to the sum of main freq. and auxiliary freq. See Figure 5-1.

1: regulate based on max. output freq. (F0.09)

Preset freq.  $f_4 = f_3 + F0.09 \times (F9.20 - 100\%)$ .

2: regulate based on current output freq.

Preset freq.  $f_4 = f_3 + f_3 \times (F9.20 - 100\%) = f_3 \times F9.20$ .

**F9.21 Keypad functions**

**Range: 000~402【000】**

This function defines the function of **STOP/RESET** key and keypad lock selection.




Figure 5-55 Stop/Reset Key's Function and Keypad Lockup

One's place: **STOP/RESET** key's function

It is to set the usage and function of **STOP/RESET** key when you want to stop the inverter.

0: effective when keypad control is selected.

1: effective for keypad, terminal and serial port control. Press this key and the inverter will stop in specified manner.

2: effective for keypad, terminal and serial port control. In keypad control mode, press this key and the inverter will stop in specified manner. But in terminal or serial port control mode, pressing this key will trigger "F.ED" alarm and the inverter will coast to stop.

**STOP/RESET** can be used to reset a fault in all control modes.

Ten's place: LOCAL functions (for 4.0KW and below).

0: Disabled

1: Enabled in STOP state.

2: Enabled in STOP & RUN state.

Hundred's place: lock up keypad selection

You can select to lock all or part of the keys.

- 0: not lock the keypad.  
 1: lock all keys on the keypad.  
 2: lock all keys on the keypad except STOP/RESET key.  
 3: lock all keys on the keypad except ►►key.  
 4: lock all keys on the keypad except RUN and STOP key. Keypad locking method: press FUNC/DATA key and PRG key at the same time for 3 seconds.  
 Unlocking method: press FUNC/DATA key and hold it, press ▼ key three times (within 3 seconds)

|                   |                |
|-------------------|----------------|
| F9.22 Cooling fan | Range: 0、1 【0】 |
|-------------------|----------------|

0: Auto-stop mode

The cooling fan keeps running during operation. After the inverter stops for 3minutes, the cooling fan will continue to run or stop according to the module temperature.

1: cooling fan keeps running upon power on.

|                         |                |
|-------------------------|----------------|
| F9.23 Acc/Dec time unit | Range: 0、1 【0】 |
|-------------------------|----------------|

0: second

1: minute

It is valid for all acceleration or deceleration except jog and traversing operation.

The Acc/Dec time can be as long as 60 hours.

Note:

It is recommended to select Second as time unit.

|                |  |
|----------------|--|
| F9.24 Reserved |  |
|----------------|--|

|                                 |                |
|---------------------------------|----------------|
| F9.25 High usage of bus voltage | Range: 0、1 【1】 |
|---------------------------------|----------------|

When the electric network voltage is much lower (under 15% of rated voltage) or the inverter works with a heavy load for long time, it will boost its bus voltage usage rate to increase output voltage.

0: disabled

1: enabled

Note:

If F9.25 is enabled, the output harmonic components will increase slightly.

|                             |                               |
|-----------------------------|-------------------------------|
| F9.26 Zero freq. threshold  | Range: 0.00~650.00Hz 【0.00Hz】 |
| F9.27 Zero freq. hysteresis | Range: 0.00~650.00Hz 【0.00Hz】 |

The above two parameters are to set zero frequency hysteresis control.

Take analog CCI for example, see Figure5-58:

Startup process:

When the Run command is given out, only after CCI current arrives at  $I_b$  and the corresponding frequency reaches  $f_b$ , does the inverter start and accelerate to the preset frequency.

Stop:

During operation, if CCI current reduces to  $I_b$ , the inverter will not stop until it reaches  $I_a$  and the corresponding frequency becomes  $f_a$ , where  $f_a$  is the threshold of zero frequency defined by F9.12. The difference between  $f_b$  and  $f_a$  is zero frequency hysteresis, defined by F9.27.

This function can realize dormancy to save energy. In addition, the frequent start and stop at threshold frequency can be avoided.




Figure 5-58 Zero Freq. Hysteresis

|                                                       |                                   |
|-------------------------------------------------------|-----------------------------------|
| F9.28 Low voltage compensation (trip free)            | Range: 0、1 【0】                    |
| F9.29 Freq. decrease rate during voltage compensation | Range: 0.00~99.99Hz/s 【10.00Hz/s】 |

F9.28 is to select whether to enable low voltage compensation in case of voltage drop or undervoltage by reducing output frequency to get energy feedbacked from the load, so that the inverter will not trip.

F9.28=0, disabled

F9.28=1, enabled

If the setting of F9.29 is set too big, the feedback energy of motor will be more than expected and may cause over-voltage protection; if the setting of



F9.29 is set to small, the feedback energy of motor is not enough, hence trip might occur. It is recommended to set F9.29 according to load and its inertia.

|       |                                           |                         |
|-------|-------------------------------------------|-------------------------|
| F9.30 | Conditions of restart after power failure | Range: 0、1 【0】          |
| F9.31 | Restart delay after power failure         | Range: 0.0~10.0s 【0.5s】 |
| F9.32 | Reserved                                  |                         |

F9.22 and F9.23 are to set how the inverter restarts after power failure given different control mode.

F9.30=0, not auto restart.

F9.30=1, the inverter will auto restart if the Start condition can be satisfied after a period of time specified by F9.31.

In fact, whether to auto restart depends on F9.30, inverter's state at power failure and control mode. Refer to Table 5-14.

Table 5-14 Conditions of Restart after Power-on

| F9.30 | State before power off | Control mode at power-on |             |                     |                     |     |
|-------|------------------------|--------------------------|-------------|---------------------|---------------------|-----|
|       |                        | Keypad                   | Serial port | 3-wire terminal 1、2 | 2-wire terminal 1、2 |     |
|       |                        | None                     | None        | None                | None                | Yes |
| 0     | Stop                   | 0                        | 0           | 0                   | 0                   | 0   |
|       | Run                    | 0                        | 0           | 0                   | 0                   | 0   |
| 1     | Stop                   | 0                        | 0           | 0                   | 0                   | 1   |
|       | Run                    | 1                        | 1           | 1                   | 0                   | 1   |

Note:

1. Table 5-14 shows the inverter's action under different conditions. 0 means the inverter is ready to start, and 1 means auto start.
2. When the control mode is keypad or serial port or 3-wire terminal 1 and 2, there is no RUN command at power on.
3. If there is a Stop command, the inverter will not start.
4. When restart is allowed, the inverter will start according to F2.00.

|       |                                |                             |
|-------|--------------------------------|-----------------------------|
| F9.33 | Braking unit operating voltage | Range: 650~780V 【710V/750V】 |
| F9.34 | Terminal filter time           | Range: 0.5~100.0ms          |
| F9.35 | Reserved                       | Range:                      |
| F9.36 | Undervoltage setting           | 75.0%~135.0% 【90.0%】        |

Reserved

|       |                      |            |            |
|-------|----------------------|------------|------------|
| F9.37 | Load loss protection | Range: 0~1 | Default: 0 |
|-------|----------------------|------------|------------|

0: Load loss protection valid;

1: Load loss protection invalid;

|                             |                   |                 |
|-----------------------------|-------------------|-----------------|
| F9.38 Load loss fault level | Range: 0.0~100.0% | Default: 30.0%  |
| F9.39 Load loss fault time  | Range: 0~600.0s   | Default: 120.0s |

Load loss fault level is protection current threshold for action, the set value is percentage of inverter rated current. When the inverter output current is less than F9.38 (load loss fault level), and beyond the time of F9.39 (Load loss fault time), "F.oLL" load loss protection fault will be shown.

|                                   |            |            |
|-----------------------------------|------------|------------|
| F9.40 Torque enable in zero speed | Range: 0~1 | Default: 0 |
|-----------------------------------|------------|------------|

0: Torque enable in zero speed valid;

1: Torque enable in zero speed invalid;

|                                       |                 |               |
|---------------------------------------|-----------------|---------------|
| F9.41 Torque percentage in zero speed | Range: 0.0~100% | Default: 0.0% |
|---------------------------------------|-----------------|---------------|

When F2.01 is set as 0.00Hz, and F9.40 is valid, The output torque is bigger if F9.41 setting is higher when inverter runs in 0.00Hz,

## 7.11 Display Control Parameters (FA)

|                                           |                        |
|-------------------------------------------|------------------------|
| FA.00 LED displayed parameter selection 1 | Range: 000~3FFH 【00DH】 |
|-------------------------------------------|------------------------|




Figure 5-59 LED Displayed Parameter 1 Setting

FA.00 and FA.01 define the parameters that can be displayed by LED when the inverter is operating.

If Bit is set at 0, the parameter will not be displayed;

If Bit is set at 1, the parameter will be displayed.

As to the conversion of binary format to Hex format, please refer to Table 5-12. You may press ►►key to scroll through the parameters.

|                                           |                        |
|-------------------------------------------|------------------------|
| FA.01 LED displayed parameter selection 2 | Range: 000~3FFH 【000H】 |
|-------------------------------------------|------------------------|




Figure 5-60 LED

#### Displayed Parameter 2 Setting

The displayed terminal information includes status of terminal X1~X5, bi-direction open-collector output terminals Y1 and Y2, and relay output terminal TC. The status of terminals are indicated by the “On” or “Off” of LED. If the LED turns on, that means the terminal is enabled, and the terminal is disabled if the LED turns off, as shown in Figure5-61:




Figure 5-61 Terminal Status Indication

In Figure5-61, X1, X2, X4, X5, Y1 and TC are enabled, X3 and Y2 disabled. There are four LEDs are always illuminate for the convenience of observation.

#### Note:

1. When the rotating speed and line speed are displayed, these values can be modified by pressing ▲ and ▼ in real time (no need to shift to frequency display status) .
2. When FA.00 and FA.01 are all set to 0, the frequency before compensation will be displayed.

3. You may press ►►key to scroll through the parameters that has been set to display in FA.00 and FA.01 when the inverter is operating.

|                                         |                           |
|-----------------------------------------|---------------------------|
| FA.02 Displayed parameter at stop state | Range: 0000~3FFFH 【2001H】 |
|-----------------------------------------|---------------------------|




Figure 5-62 Parameter Displayed at Stop State

FA.02 defines the parameter that can be displayed by LED when the inverter is operating.

If BIT is set at 0: the parameter will not be displayed.

If BIT is set at 1: the parameter will not be displayed.

#### Note :

When the rotating speed and line speed are displayed, these values can be changed by pressing ▲ and ▼ in real time (no need to change to frequency displaying status) .

When the setting of FA.02 is 0, the preset frequency will be displayed.

You may press ►► key to scroll through the parameters that have been set to displayed in FA.02 when the inverter is in stop state.

|                                     |                            |
|-------------------------------------|----------------------------|
| FA.03 Rotating speed display factor | Range: 0.1~999.9% 【100.0%】 |
|-------------------------------------|----------------------------|

It is used to calibrate the error of rotating speed display. It has no effect on the actual speed.

|                         |                          |
|-------------------------|--------------------------|
| FA.04 Line speed factor | Range: 0.1~999.9% 【1.0%】 |
|-------------------------|--------------------------|

It is used to calibrate the error of line speed display. It has no effect on the actual speed.

|                                           |                            |
|-------------------------------------------|----------------------------|
| FA.05 Close-loop parameter display factor | Range: 0.1~999.9% 【100.0%】 |
|-------------------------------------------|----------------------------|

It is used to calibrate the error between preset or feedback parameters and the actual ones. It has no effect on close-loop PI regulation.

|       |          |
|-------|----------|
| FA.06 | Reversed |
|-------|----------|

## 7.12 Communication (FB)




Figure 5-63 Communication Configuration

This parameter sets the communication mode.

Virtual terminal is set by host command to simulate the actual terminal. Each bit of the command represents the state of corresponding terminal.

|                            |                         |
|----------------------------|-------------------------|
| <b>FB.01 Local address</b> | <b>Range: 0~247 【1】</b> |
|----------------------------|-------------------------|

In serial communication, FB.01 is used to identify the inverter's address.

Note: "127" is the broadcast address. When the address is set to broadcast address, the inverter can receive and execute the command sent by control PC, but will not answer it.

|                                         |                                |
|-----------------------------------------|--------------------------------|
| <b>FB.02 Communicate timeout detect</b> | <b>Range: 0~1000.0s 【0.0s】</b> |
|-----------------------------------------|--------------------------------|

When the communication signal is lost for a period longer than the setting of this parameter, the inverter deems that communication fault occurs.

When it is set at 0, the inverter will not detect the signals at the serial port, i.e., this function is invalid.

|                             |                              |
|-----------------------------|------------------------------|
| <b>FB.03 Response delay</b> | <b>Range: 0~1000ms 【5ms】</b> |
|-----------------------------|------------------------------|

Response delay refers to the time from the inverter receiving and executing the command of the host to returning reply frame to the host. For RTU mode, the actual response delay should be no less than 3.5 bytes' transmitting time.

## 7.13 PLC parameters (FD)

Simple PLC is a multi-speed generator, through which, the inverter can change frequency and direction according to the running time. This function is

realized through PLC (programmable logic controller) before, now the inverter can do it by itself. See Figure 5-67.




Figure 5-67 Simple PLC Operation

In Figure 5-67, a1~a7, d1~d7 are the Acc and Dec time of the respective stage; f1~f7 and T1~T7 will be defined in later parameters.

The PLC stage and PLC cycle are indicated by the 500mS signals from output terminals Y1 and Y2 of open collector output or relay output. See F6.00~F6.02.

|                       |                         |
|-----------------------|-------------------------|
| FD.00 Simple PLC mode | Range: 0000~1123 【0000】 |
|-----------------------|-------------------------|

Thous Hund Ten One

PLC running mode selection  
0: disabled  
1: stop after single cycle  
2: retain value after 1 cycle  
3: continuous

PLC running after interrupt  
0: start from first stage  
1: start from the stage frequency where the drive stop  
2: start from the frequency when it stops

Save PLC status after poweroff  
0: not save  
1: save the stage and frequency at poweroff

time unit  
0: second  
1: minute

Figure 5-68 Stop After a Single PLC Cycle

One's place of FD.00, PLC running mode selection

0: Disabled

The PLC function is disabled.

1: stop after a single cycle

As Figure5-69 shows, the inverter stops after a single cycle automatically. It will start given another Run command.




Figure 5-69 PLC Continuous Cycle

2: Maintain value of the last stage after 1 cycle

As Figure 5-70 shows, the inverter holds the frequency and direction of the last stage after single cycle.




Figure 5-70 Maintain Last Stage After Single Cycle

3: (Continuous cycle) : The inverter continue running cycle after cycle until Stop command is received.




Figure 5-71 PLC Continuous Cycle

Ten's place of FD.00: Restart mode after PLC interruption:

0: start from the first stage

The inverter restarts from the first stage of PLC after interrupts, such as Stop command, fault or poweroff.

1: continue from the stage frequency where the inverter stops. When the inverter stops caused by Stop command or fault, it can record the time that it has undergone in the current stage. After receiving Run command, it will run at the preset frequency of the stage for the remaining time of the stage, as Figure 5-72 shows.




Figure 5-72 PLC Restart Mode 1

2: Start from the frequency where it stops:

When the inverter stops caused by Stop command or fault, it can record both the time it has undergone in the current stage and the very frequency when the inverter stops. It will pick up the recorded frequency and run for the remaining time of the stage. See Figure 5-73.






Figure 5-73 PLC Start Mode 2

**Note:**

The difference between PLC start mode 1 and mode 2 is that in mode 2, the inverter can record the operating frequency when the inverter stops and continue to operate at the recorded frequency after restart.

Hundred's place of FD.00: Save PLC state after poweroff:

0: not save

The PLC state will not be saved when poweroff, and the inverter will start from the first stage after powerup.

1: save

The PLC state, including the stage, frequency, run time will be saved when poweroff, and the inverter will start according to the setting of ten's place of FD.00 after powerup.

Thousand's place: Selection of time unit:

0: Second

1: Minute

This unit is only valid for defining the PLC operating time. The unit of Acc/Dec time in PLC operation is determined by F9.23.

**Note:**

1. A stage is ineffective if its run time is set to 0.
2. You can use terminals to pause and disable PLC operation, and clear the memorized parameters. See F5、F6 parameters.

|       |                  |                              |
|-------|------------------|------------------------------|
| FD.01 | Stage 1 setting  | Range: 000~323 【000】         |
| FD.02 | Stage 1 run time | Range: 0~6500s (min) 【20.0s】 |
| FD.03 | Stage 2 setting  | Range: 000~323 【000】         |
| FD.04 | Stage 2 run time | Range: 0~6500s (min) 【20.0s】 |
| FD.05 | Stage 3 setting  | Range: 000~323 【000】         |

|       |                  |                              |
|-------|------------------|------------------------------|
| FD.06 | Stage 3 run time | Range: 0~6500s (min) 【20.0s】 |
| FD.07 | Stage 4 setting  | Range: 000~323 【000】         |
| FD.08 | Stage 4 run time | Range: 0~6500s (min) 【20.0s】 |
| FD.09 | Stage 5 setting  | Range: 000~323 【000】         |
| FD.10 | Stage 5 run time | Range: 0~6500s (min) 【20.0s】 |
| FD.11 | Stage 6 setting  | Range: 000~323 【000】         |
| FD.12 | Stage 6 run time | Range: 0~6500s (min) 【20.0s】 |
| FD.13 | Stage 7 setting  | Range: 000~323 【000】         |
| FD.14 | Stage 7 runtime  | Range: 0~6500s (min) 【20.0s】 |

FD.01、FD.03、FD.05、FD.07、FD.09、FD.11、FD.13 are to set frequency, direction, Acc/Dec time of PLC stages. See Figure 5-74:




Figure 5-74 PLC Stage i setting (i=1~7)

One's place:

0: select MS frequency i, e.g. i=3, means the frequency for stage 3 is MS frequency 3, see F8.00~F8.06.

1: the frequency is determined by F0.02

2: MS close loop setting I, e.g. i=2, the frequency of stage 2 is MS close loop setting 2. See F8.07~F8.13.

3: Determined by F7.01.

PLC can realize close-loop operation in a certain stage. Close-loop reference selectors can be preset close-loop reference I or determined by parameter F7.01; and the feedback is determined by F7.02. When the setting method is

determined by F7.01, the terminals can be selected via close-loop input. See F7.00~F7.04 and F8.07~F8.13 for details.

**Note:**

When the PLC operating direction is determined by operating commands, the motor's operating direction can be changed by external command. For example, Running forward can be ordered by terminal FWD-COM. The direction is decided by running command and if it cannot be determined, the inverter will run in the direction of last operating stage.

## 7.14 Constant-pressure water supply (FE)

|                         |            |            |
|-------------------------|------------|------------|
| FE.00 Water supply Mode | Range: 0~3 | Default: 0 |
|-------------------------|------------|------------|

0: General Function

No constant-pressure water supply function.

1: Single pump constant-pressure water supply function

One frequency inverter drives one pump for water supply control

2: Simple one inverter with two motors constant-pressure water supply function

Frequency inverter drives one variable-speed pump and a grid-frequency pump by relay output control. When this function required, the original relay function will be invalid. 7.5KW and above inverters only have one relay output to keep the original relay functions in this mode.

3: Simple one inverter with three motors constant-pressure water supply function (5.5KW and below inverters are reserved)

One frequency inverter drives a variable-speed pump drive and two grid-frequency pumps by relay output control. When this function required, the original relay function will be invalid. When pump added, relay 1 acts at first, 2 relay acts then. When reducing pump, relay 2 acts at first, relay 1 acts then.

Note: When you turn on the constant-pressure water supply functions, please set F7.00 to 1 to enter into closed-loop mode. And then set the PID function parameters in F7 group according to real situation to achieve constant-pressure water supply PID control.

|                        |                             |                  |
|------------------------|-----------------------------|------------------|
| FE.01 Sleep Frequency  | Range: 0.00~upper frequency | Default: 25.00HZ |
| FE.02 Sleep delay time | Range: 0~3600s              | Default: 0s      |

When the output frequency is not higher than FE.01, after a time of FE.02, inverter will enter the sleep state. It will follow the stop mode selected by

FE.09. When the set pressure is higher than the feedback pressure, inverter will accelerate to FE.01 (generally slightly higher than this value) according to the acceleration time at first, then the closed-loop regulation.

|                                   |                   |                |
|-----------------------------------|-------------------|----------------|
| FE.03 Wake-up pressure percentage | Range: 0.0~100.0% | Default: 50.0% |
| FE.04 Wake-up delay time          | Range: 0~3600s    | Default: 0s    |

Wake-up pressure percentage = wake-up pressure / target pressure \* 100%

When the feedback pressure is less than wake-up pressure, inverter will enter into the awake state after the setting time of FE.04.

|                                                      |                  |               |
|------------------------------------------------------|------------------|---------------|
| FE.05 PID feedback disconnection detection threshold | Range: 0.0~80.0% | Default: 0.0% |
| FE.06 PID feedback disconnection detection time      | Range: 0~9999s   | Default: 0s   |

FE.05= 0.0%, without feedback disconnection detection.

PID feedback disconnection detection threshold represent by a percentage of full scale feedback.

When the inverter detects a PID feedback signal is less than FE.05, and the inverter frequency has reached the upper frequency limit, feedback disconnection fault will be shown after the setting time of FE.06.

Note: Please set FE.05 reasonable, and if the value is unreasonable, it will cause unnecessary downtime.

|                                  |                |              |
|----------------------------------|----------------|--------------|
| FE.07 increasing pump delay time | Range: 0~3600s | Default: 10s |
| FE.08 decreasing pump delay time | Range: 0~3600s | Default: 10s |

FE.07 and FE.08 work only when FE.00 is 2 or 3.

FE.07 is used to define the delay time when the frequency reaches the upper frequency and need to increase a pump;

FE.08 is used to define the delay time when the frequency reaches the sleep frequency and need to decrease a pump;

Note: FE.07 and FE.08 are reserved in 5.5KW and below models.

|                  |            |            |
|------------------|------------|------------|
| FE.09 Sleep mode | Range: 0~1 | Default: 0 |
|------------------|------------|------------|

To select the stop mode in to sleep of the inverter

0: Deceleration stop sleep

Decelerate to 0 Hz and sleep according to F0.13 deceleration time

1: Free stop sleep

Free stop to 0 Hz and sleep

|                                                           |            |            |
|-----------------------------------------------------------|------------|------------|
| FE.10 Relay selection for one inverter to drive two pumps | Range: 0~1 | Default: 0 |
|-----------------------------------------------------------|------------|------------|

0: Relay 1 to control grid-frequency pump

1: Relay 2 to control grid-frequency pump

One replay keeps original functions.

Note: This parameter is reserved for 5.5KW and below models.

|               |  |  |
|---------------|--|--|
| FE.11Reserved |  |  |
| FE.12Reserved |  |  |
| FE.13Reserved |  |  |
| FE.14Reserved |  |  |
| FE.15Reserved |  |  |
| FE.16Reserved |  |  |
| FE.17Reserved |  |  |

## 7.15 Protection (FL)

|                                      |                  |
|--------------------------------------|------------------|
| FL.00 Motor overload protection load | Range: 0、1、2 【0】 |
|--------------------------------------|------------------|

0: Disabled

The overload protection is disabled. Be careful to use this function because the inverter will not protect the motor in case of overload;

1: Common motor (with low speed compensation)

Since cooling conditions of common motor deteriorates at low speed, the motor's thermal protection threshold should also be adjusted. The "Low Speed" here refers to the operating frequency lower than 30Hz.

2: Variable frequency motor (without low speed compensation)

The cooling effect of variable frequency motor is not affected by the motor's speed, so low speed compensation is not necessary.

|                                        |                             |
|----------------------------------------|-----------------------------|
| FL.01 Motor overload protection factor | Range: 20.0~110.0% 【100.0%】 |
|----------------------------------------|-----------------------------|

In order to apply effective overload protection to different kinds of motors, the Max output current of the inverter should be adjusted as shown in Figure 5-75.




Figure 5-75 Motor's overload protection coefficient

The efficient is calculated by the formula below:

$$\text{Motor overload protection coefficient} = \frac{\text{motor rated current}}{\text{inverter's rated output current}} \times 100\%$$

Generally, the Max load current is the motor's rated current.

Note:

If the motor's rated current does not match that of the inverter, adjust FL.00~FL.01 to perform overload protection.

|       |                         |                           |
|-------|-------------------------|---------------------------|
| FL.02 | Stall overvoltage       | Range: 0、1 【1】            |
| FL.03 | Stall overvoltage point | Range: Depending on model |

0: Disabled

1: Enabled

The setting of FL.03 is given in the table below:

| Model | Range         | Default |
|-------|---------------|---------|
| 380V  | 120.0%~150.0% | 140.0%  |
| 220V  | 110.0%~130.0% | 120.0%  |

When the inverter is decelerating, the motor's decreasing rate may be lower than that of the inverter's output frequency due to the inertia of load. At this time, the motor will feed the energy back to the inverter, resulting in voltage rise on the inverter's DC bus, which will cause overvoltage trip.

Function of FL.03: during the deceleration, the inverter detects the bus voltage and compares it with the stall over voltage point defined by FL.03. If the bus voltage exceeds FL.03, the inverter will stop reducing its output frequency. When the detected bus voltage is lower than the point, the deceleration will continue. Please refer to in Figure 5-76.




Figure 5-76 Stall Overvoltage

Note:

1. The inverter will alarm and display “F.ED” if it has been in stall over-voltage status for more than 1 minute.
2. If the stall point is set too low, you should prolong the Acc and Dec time properly.
3. If the stall point is set too high, it is useless for overvoltage protection.

|                                              |                           |
|----------------------------------------------|---------------------------|
| FL.04 Overload pre-alarm detection config    | Range: 000~111 【000】      |
| FL.05 Overload pre-alarm detection threshold | Range: depending on model |
| FL.06 Overload pre-alarm delay               | Range: 0.0~60.0s 【5.0s】   |

SINUS VEGA has overload protection over motor and inverter. See Table 2-1 for inverter overload protection, and FL.00 and FL.01 for motor overload protection. FL.04~FL.06 can monitor the overload condition before overload protection acts.

FL.04 defines the overload detection mode, action mode and reference current.




Figure 5-77 Overload Detection Configuration

One's place of FL.04: overload detection mode:

0: the detection is done as long as the inverter is operating.

1: the detection is done only when the inverter works at constant speed.

Ten's place of FL.04: action mode:

0: The overload is ignored, no alarm.

1: During "Overload Alarm Effective Period", the inverter will alarm and stop operation. The "Overload Alarm Effective Period" means the inverter's operating current has exceeds FL.05 and whose duration has exceed overload alarm delay (FL.06) .

Hundred's place of FL.04: reference current :

0: the overload detection threshold (FL.05) is set based on motor's rated current. Fault code F.oL2.

1: the overload detection threshold (FL.05) is set based on inverter's rated current. Fault code F.oL1.

FL.05 defines the threshold for overload alarm. It is a percentage of either inverter's or motor's rated current. Refer to setting of the hundred's place of FL.04. The setting of FL.05 also relates to the type of the inverter. Please refer the table below:

| Type        | Setting range | Default |
|-------------|---------------|---------|
| Heavy duty  | 20.0%~200.0%  | 130.0%  |
| Normal duty | 20.0%~130.0%  | 120.0%  |

Overload alarm delay FL.06, please refer to Figure 5-78.




Figure 5-78 Overload Detection and Alarm

Note:

1. Overload detection threshold should be lower than the overload protection threshold;
2. During the overload alarm delay period, if the inverter's current becomes lower than overload detection threshold, no alarm will be triggered.



|                                                   |                                   |
|---------------------------------------------------|-----------------------------------|
| FL.07 Auto current limiting threshold             | Range: depending on model         |
| FL.08 Freq. decrease rate during current limiting | Range: 0.00~99.99Hz/s 【10.00Hz/s】 |
| FL.09 Action mode of auto current limiting        | Range: 0~4 【depending on model】   |

Auto current limiting function is used to limit the load current under the preset current in real time to avoid trip due to over-current. This function is especially useful for the applications of larger load inertia or sharp change of load.

FL.07 defines the threshold for current limiting. Its setting is a percentage of inverter's rated current:

Default value for Heavy duty is 150%

Default value for Normal duty 110%

FL.08 defines the decreasing rate of output frequency when the inverter is in auto current limiting status.

If FL.08 is set too small, overload fault may occur. If FL.08 is set too big, the inverter may be in energy generation status for long time that may result in overvoltage protection.

The action mode of auto current limiting function is decided by FL.09.

FL.09=0: disabled;

FL.09=1: auto current limiting is effective during acceleration or deceleration but ineffective at constant speed, no silencing function;

FL.09=2: effective all the time, no silencing function;

FL.09=3: reserved;

FL.09=4: reserved.

Because the output frequency might change during current limiting, the function should be used for applications that require constant speed and stable frequency output.

|                           |                         |
|---------------------------|-------------------------|
| FL.10 Auto reset time     | Range: 0~10 【0】         |
| FL.11 Auto reset interval | Range: 2.0~20.0s 【5.0s】 |

Auto Reset function can reset a fault according to the preset FL.10 and FL.11. If FL.10 is set to 0, auto reset is disabled. Protective action will be taken if a fault occurs.

Note:

1. Overcurrent protection and external fault (F.Ed) cannot be reset automatically.

2. During the reset interval, the inverter's stops operation and restarts on the fly when the reset is finished.
3. Be careful when using auto-reset function, otherwise human injury or material loss may occur.

|       |                          |                         |
|-------|--------------------------|-------------------------|
| FL.12 | Protective action mode 1 | Range: 000~101 【000】    |
| FL.13 | Protective action mode 2 | Range: 0000~1211 【0000】 |

The fault alarm and protective action can be prohibited by setting FL.12 and FL.13, so that the inverter can continue working.

FL.12 defines the protective action in case of communication and E<sup>2</sup>PROM error.




Figure 5-79 Protective action mode setting 1

FL.13 defines the action mode for undervoltage, auto reset interval fault lockup and output phase loss.




Figure 5-80 Protection action mode setting 2



Please be careful when using FL.12 and FL.13, otherwise human injury or material loss may occur.

|       |                                   |                              |
|-------|-----------------------------------|------------------------------|
| FL.14 | Fault type of the first two times | Range: 0~24 【0】              |
| FL.15 | Fault type of the previous time   | Range: 0~24 【0】              |
| FL.16 | Fault type of the last time       | Range: 0~24 【0】              |
| FL.17 | Bus voltage at the last fault     | Range: 0~999V 【0V】           |
| FL.18 | Output current at the last fault  | Range: 0~999.9A 【0.0A】       |
| FL.19 | Freq. at the last fault           | Range: 0.00~650.00Hz【0.00Hz】 |

SINUS VEGA has 24 kinds of alarms. It can memorize the types of 3 latest faults (FL.14~FL.16), and the voltage, current and frequency (FL.17~FL.19) of the most recent fault.

See chapter 8 for the detailed introductions to the alarm.

## 7.16 Operation Time and Temperature of Cooling Fan (FN)

|       |                              |                       |
|-------|------------------------------|-----------------------|
| FN.00 | Preset operation time        | Range: 0~65.535kh 【0】 |
| FN.01 | Total operation time         | Range: 0~65.535kh 【0】 |
| FN.02 | Temperature of cooling fan 1 | Range: 0~100℃ 【0】     |
| FN.03 | Temperature of cooling fan 2 | Range: 0~100℃ 【0】     |

If the accumulated operating time has amount to FN.00, the inverter will give out an indicating signal. Please refer to F6.00~F6.02.

FN.01 is the total accumulated operating time from delivery till now.

FN.02 refers to the temperature of inverter module.

FN.03 refers to the temperature of rectifier module.

Display range: 0~100℃; Accuracy: 5%

## 7.17 Protection of Parameters (FP)

|       |               |                         |
|-------|---------------|-------------------------|
| FP.00 | User password | Range: 0000~9999 【0000】 |
|-------|---------------|-------------------------|

User's password can prevent unauthorized persons from checking and modifying the parameters.

Set FP.00 to 0000 if the user's password is not necessary.

If you want to set the user's password, input a 4-digit number, press **FUNC/DATA** to confirm. If not pressing any key within 5 minutes, the password will become effective.

Changing the password:

Press **PRG**, input the old password, and then select **FP.00** (at this time **FP.00 = 0000**), input new password and press **FUNC/DATA** to confirm. The password will become effective if not pressing any key within 5 minutes.

Note:

Please learn the password by heart.

|                           |                |
|---------------------------|----------------|
| FP.01 Write-in protection | Range: 0~2 【0】 |
|---------------------------|----------------|

FP.01 is to set the mode of write-in protection of parameters.

0: All parameters are allowed to be changed;

1: No parameters can be changed except the **F0.04** and **FP.01**;

2: No parameters can be changed except **FP.01**.

Note:

The factory setting of **FP.01** is 1. If you need modify parameters, **FP.01** must be set to 0; and then set it to 1 or 2 after modification to protect these parameters.

|                                |                |
|--------------------------------|----------------|
| FP.02 Parameter initialization | Range: 0~2 【0】 |
|--------------------------------|----------------|

0: disabled

1: clear fault record

Clear the contents of **FL.14~FL.19**.

2: restore to factory defaults

If **FP.02** is set at 2, the parameters listed before **FL.14** except **F1.00** and **F1.09** will be restored to factory defaults.。

After the initialization, the parameter will change to 0 automatically.

|                |  |
|----------------|--|
| FP.03 Reserved |  |
|----------------|--|

|                |  |
|----------------|--|
| FP.04 Reserved |  |
|----------------|--|

## 7.18 Factory Default (FU)

|                |                    |
|----------------|--------------------|
| FP.00 Password | Set by manufacture |
|----------------|--------------------|

## 8. Troubleshooting

All the possible faults of SINUS VEGA have been given in Table 6-1. Fault code range is F.oC1~F.tU. You can user can check the faults according to the following table and record detailed fault phenomena before seeking service. Please contact the sales distributor when you need technical supports.

Table 6-1 Fault Information and Diagnosis

| Fault code | Display code | Fault description                        | Possible reasons                                                                                   | Actions                                                                                                                                  |
|------------|--------------|------------------------------------------|----------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| F.oC1      |              | Over-current in Acc process              | Too short Acc time                                                                                 | Prolong the Acc time                                                                                                                     |
|            |              |                                          | V/F curve is not suitable                                                                          | Check and adjust V/F curve, adjust torque boost or set the motor parameters correctly to ensure the normal auto torque boost works well. |
|            |              |                                          | The rotating motor re-starts after the inverter stops re-starts after the inverter stops instantly | Start when the motor stops                                                                                                               |
|            |              |                                          | Low AC supply voltage                                                                              | Check the inverter's input AC supply                                                                                                     |
|            |              |                                          | Inverter power is too small                                                                        | Select a higher power inverter                                                                                                           |
| F.oC2      |              | Over-current in Dec process              | Too short Dec time                                                                                 | Prolong the Dec time                                                                                                                     |
|            |              |                                          | Negative-torque load or the load inertia is too high                                               | Connect suitable braking device                                                                                                          |
|            |              |                                          | Too low inverter's power                                                                           | Select the inverter with larger capacity                                                                                                 |
| F.oC3      |              | Over-current in constant speed operation | Sudden change of load                                                                              | Reduce the change of the load                                                                                                            |
|            |              |                                          | Too short Acc/Dec time                                                                             | Prolong Acc/Dec time                                                                                                                     |
|            |              |                                          | Abnormal load                                                                                      | Check the load                                                                                                                           |
|            |              |                                          | Low AC supply voltage                                                                              | Check the AC supply voltage                                                                                                              |
|            |              |                                          | Too low inverter's power                                                                           | Select the inverter with larger capacity                                                                                                 |
| F.oU1      |              | Over voltage in Acc process              | Abnormal AC supply voltage                                                                         | Check the AC supply voltage                                                                                                              |
|            |              |                                          | Too short Acc/Dec time                                                                             | Prolong the Acc time                                                                                                                     |
|            |              |                                          | The inverter is re-started with a rotating motor                                                   | Start when the motor stops                                                                                                               |
| F.oU2      |              | Over voltage in Dec process              | Too short Dec time (with reference to generated energy)                                            | Prolong the Dec time                                                                                                                     |

| Fault code | Display code | Fault description                               | Possible reasons                                                                 | Actions                                                             |
|------------|--------------|-------------------------------------------------|----------------------------------------------------------------------------------|---------------------------------------------------------------------|
|            |              |                                                 | Negative-torque load or the load inertia is too high                             | Use suitable dynamic braking device                                 |
| F.oU3      |              | Over voltage inconstant-speed operating process | Abnormal AC supply voltage                                                       | Check the AC supply voltage                                         |
|            |              |                                                 | Too short Acc/Dec time                                                           | Prolong the Acc/Dec time                                            |
|            |              |                                                 | Abnormal change of input voltage                                                 | Install input reactor                                               |
|            |              |                                                 | Too high load inertia                                                            | Use suitable dynamic braking device                                 |
| F.PoU      |              | Over voltage of inverter's control power supply | Abnormal AC supply voltage                                                       | Check the AC supply voltage or seek service                         |
| F.IPL      |              | input phase loss                                | Input R、S、T phase loss                                                           | Check the wiring and input voltage                                  |
| F.oPL      |              | Output phase loss                               | Output phase failure among Phase U, V and W                                      | Check the inverter's output wiring<br>Check the cable and the motor |
| F.FAL      |              | Module protection                               | Instant overcurrent                                                              | See User's manual                                                   |
|            |              |                                                 | Interphase shorted or ground shorted                                             | Re-wiring                                                           |
|            |              |                                                 | Fan duct blockage or damage                                                      | Clear the fan duct or replace the fan                               |
|            |              |                                                 | Ambient temperature is too high                                                  | Lower the ambient temperature                                       |
|            |              |                                                 | Panel wiring or plug-ins loose                                                   | Check and re-wiring                                                 |
|            |              |                                                 | Output phase loss or some other reasons result in current waveform abnormalities | Check the wiring                                                    |
|            |              |                                                 | Charge voltage damaged, inverter voltage undervoltage                            | Seek service                                                        |
|            |              |                                                 | Straight bridge arm                                                              | Seek service                                                        |
|            |              |                                                 | Panel abnormal                                                                   | Seek service                                                        |
| F.oH1      |              | Rectifier's heatsink overheat                   | Ambient over-temperature                                                         | Lower the ambient temperature                                       |
|            |              |                                                 | Obstruction of ventilation channel                                               | Clear the ventilation channel                                       |
|            |              |                                                 | Fan does not work                                                                | Replace the fan                                                     |
|            |              |                                                 | Inverter fault                                                                   | Seek service                                                        |
| F.oH2      |              | Rectifier cooling fan                           | Ambient temperature is too high                                                  | Lower the ambient temperature                                       |

| Fault code | Display code | Fault description                          | Possible reasons                                                          | Actions                                                  |
|------------|--------------|--------------------------------------------|---------------------------------------------------------------------------|----------------------------------------------------------|
|            |              | overtemperature                            | Fan duct blockage                                                         | Clear the fan duct                                       |
|            |              |                                            | Fan damaged                                                               | Replace the fan                                          |
| F.oL1      |              | Inverter overload                          | Too short Acc time                                                        | Prolong Acc time                                         |
|            |              |                                            | Too large DC braking energy                                               | Reduce DC braking current, prolong braking time          |
|            |              |                                            | Improper V/F curveV/F                                                     | Adjust V/F curve or torque boost value                   |
|            |              |                                            | The inverter is re-started with a rotating motor                          | Start when the motor stops                               |
|            |              |                                            | Low AC supply voltage                                                     | Check the AC supply voltage                              |
|            |              |                                            | Too heavy load                                                            | Select the inverter with larger power                    |
|            |              |                                            |                                                                           |                                                          |
| F.oL2      |              | Motor Overload                             | Improper V/F curveV/F                                                     | Set V/F curve and torque boost value correctly           |
|            |              |                                            | Low AC supply voltage                                                     | Check the AC supply voltage                              |
|            |              |                                            | Common moter operating at low speed, large load for long time             | Select special motor for such operating condition        |
|            |              |                                            | Incorrect setting of motor overload protection factor                     | Correct the setting                                      |
|            |              |                                            | Motor blocked or load sudden change                                       | Check the load                                           |
| F.Ed       |              | Emergency stop or external equipment fails | Press STOP key when operating at non-keypad mode                          | Check the present operating mode                         |
|            |              |                                            | Press STOP when the inverter is in stall status                           | Set the operating parameters correctly                   |
|            |              |                                            | The inverter will report F.Ed fault if it is in stall status for 1 minute | Set the operating parameters correctly                   |
|            |              |                                            | Terminal used for stopping the inverter in an emergency is closed         | Disconnect the terminal if the external fault is cleared |
| F.EEP      |              | E <sup>2</sup> PROM R/W fault              | R/W fault of control parameters                                           | Press STOP/RESET to reset                                |
| F.485      |              | RS485 communication failure                | Wrong baud rate setting                                                   | Set the baud rate correctly                              |
|            |              |                                            | Serial port communication error                                           | Press STOP/RESET to reset, Seek service                  |
|            |              |                                            | Improper setting of alarm conditions                                      | Modify FP.02、FP.03 and FL.12                             |

| Fault code | Display code | Fault description                   | Possible reasons                                                                          | Actions                                                                                       |
|------------|--------------|-------------------------------------|-------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
|            |              |                                     | Host PC does not work                                                                     | Check whether the host PC is working or not;<br>Check the wiring                              |
| F.Con      |              | Contactor fault                     | The voltage of power network is too low                                                   | Check the power network                                                                       |
|            |              |                                     | Contactor damaged                                                                         | Seek service                                                                                  |
|            |              |                                     | Power snubber resistor damaged                                                            | Seek service                                                                                  |
|            |              |                                     | Control circuit damage                                                                    | Seek service                                                                                  |
|            |              |                                     | Input phase loss                                                                          | Check R、S、T wiring                                                                            |
| F.Ct       |              | Current detection circuit is faulty | Wires or connectors of control board are loose                                            | Check and re-wire                                                                             |
|            |              |                                     | Auxiliary power supply is damaged                                                         | Seek service                                                                                  |
|            |              |                                     | Current detection circuit fault                                                           | Seek service                                                                                  |
| F.CPU      |              | System disturbance                  | Severe disturbance from outside                                                           | Press STOP/RESET to reset or install power filter at the input side of the inverter.          |
|            |              |                                     | DSP control board read and write error                                                    | Press STOP/RESET to reset<br>Seek service                                                     |
| F.rE1      |              | Reserved                            | Reserved                                                                                  | Reserved                                                                                      |
| F.rE2      |              | Reserved                            | Reserved                                                                                  | Reserved                                                                                      |
| F.CPy      |              | Copy fault                          | Parameters incomplete<br>Version of the panel is inconsistent with the main control board | Update the data and version, upload parameters first via FP.01=1, then download via FP.03=2/3 |
|            |              |                                     | E <sup>2</sup> PROM damage                                                                | Seek service                                                                                  |
| F.tU       |              | Tuning fault                        | Input motor parameters wrong                                                              | Re-input motor parameter according to the nameplate                                           |
|            |              |                                     | Tuning overtime                                                                           | Check motor cables and limit it within 100m.                                                  |



Table 6-1 Operation Related Faults and Counteractions

| Phenomena                           | Conditions                                                                         | Possible reasons of fault                                                                | Actions                                                                                                                                     |
|-------------------------------------|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
| No response of keys                 | Part of the keys or all the keys are disabled                                      | Keypad locked                                                                            | In stop or operating state, keep pressing FUNC/DATA key, when pressing ▼ key three times.<br>Power off the inverter and then power on again |
|                                     |                                                                                    | Panel's cables are not well connected                                                    | Check the wiring                                                                                                                            |
|                                     |                                                                                    | Panel's keys are damaged                                                                 | Replace operation panel or seek service                                                                                                     |
|                                     |                                                                                    | Not power on.                                                                            | Power on                                                                                                                                    |
| LED no display                      | No LED segment illuminates                                                         | Keypad cable reverse connected                                                           | Immediately remove the keypad and connect it again correctly. If the problem persists, please connect our technical support person.         |
| Parameter setting cannot be changed | Cannot be changed during operating                                                 | Parameter modification property is ×                                                     | Settings of parameters can be changed in stop status                                                                                        |
|                                     | Settings of part of parameters cannot be changed.                                  | Set FP.01 to 1 or 2                                                                      | Set FP.01 to 0                                                                                                                              |
|                                     |                                                                                    | Parameter's modification property is *                                                   | The parameters cannot be changed by user                                                                                                    |
|                                     | No parameter but "0.0.0.0." is displayed when pressing PRG                         | User's password is required                                                              | Input correct user's password<br>Seek service                                                                                               |
| Unexpected stops during running     | The inverter stops automatically without STOP command. The RUN indicator goes out. | Alarm occurs                                                                             | Find out the reason and reset.                                                                                                              |
|                                     |                                                                                    | Single cycle of PLC finishes                                                             | Check PLC configuration                                                                                                                     |
|                                     |                                                                                    | Preset length arrives                                                                    | Clear the actual length value or set FC.08 at 0                                                                                             |
|                                     |                                                                                    | Interruption of the communication between the inverter and host or flush mount faceplate | Check communication cables and FB.02, FB.03, FL.12 settings                                                                                 |
|                                     |                                                                                    | Power failure                                                                            | Check the power supply                                                                                                                      |
|                                     |                                                                                    | Command input method changed                                                             | Check the command input method and corresponding parameter                                                                                  |
|                                     |                                                                                    | Positive/negative logic of control terminal changed                                      | Check F9.15.                                                                                                                                |
|                                     | The inverter stops automatically                                                   | Auto reset of fault                                                                      | Check reason of fault and the auto reset function                                                                                           |

| Phenomena              | Conditions                                                                                         | Possible reasons of fault                                                                                        | Actions                                                                   |
|------------------------|----------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
|                        | without STOP command. The RUN indicator is still on, zero-frequency running                        | Simple PLC pause                                                                                                 | Check PLC pause function (terminal)                                       |
|                        |                                                                                                    | Interrupt signal feedback from external devices                                                                  | Check the configuration of external interrupt and faulty external devices |
|                        |                                                                                                    | Stop at zero-frequency                                                                                           | Check F9.12 and F9.13                                                     |
|                        |                                                                                                    | Reference frequency is 0                                                                                         | Check the reference frequency                                             |
|                        |                                                                                                    | Skip frequency                                                                                                   | Check skip frequency                                                      |
|                        |                                                                                                    | Positive logic, close loop feedback>reference frequency, Negative logic, close loop feedback<reference frequency | Check the close loop setting and feedback                                 |
|                        |                                                                                                    | Frequency adjustment is set at 0                                                                                 | Check F9.05 and F9.06                                                     |
|                        |                                                                                                    | Restart low voltage compensation function enabled, and low supply voltage                                        | Check the configuration of restart and the input voltage                  |
| Inverter does not work | The inverter does not work after pressing “RUN” key, and the operating indicator is distinguished. | Terminal of coast to stop is valid                                                                               | Check the terminal of coast to stop                                       |
|                        |                                                                                                    | Terminal of prohibit running is valid                                                                            | Check this terminal                                                       |
|                        |                                                                                                    | Terminal of external stop is valid                                                                               | Check this terminal                                                       |
|                        |                                                                                                    | Fixed length stop                                                                                                | Check the setting of fixed length or clear the actual length              |
|                        |                                                                                                    | The operation control terminal is not closed under 3-wire control mode                                           | Reset and close this terminal                                             |
|                        |                                                                                                    | Faulty alarm                                                                                                     | Clear the fault                                                           |
|                        |                                                                                                    | Host virtual terminal set incorrectly                                                                            | Cancel this function or reset F9.15                                       |
|                        |                                                                                                    | FWD/REV logic of input terminal is incorrectly                                                                   | Check the set of F9.15                                                    |

| Phenomena                | Conditions                                                                  | Possible reasons of fault                                                                                                                            | Actions                                                                     |
|--------------------------|-----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| Display LU upon power on | Thyristor or contactor is disconnected and the inverter's load is too large | As the thyristor or contactor is closed, the bus voltage will reduce when the inverter's load is large, so that "LU" is displayed instead of "F.Con" | Operate the inverter after the thyristor or contactor are completely closed |

## 9. Maintenance

Many factors such as ambient temperature, humidity, dust, vibration, internal component aging, wear and tear will give rise to the occurrence of potential faults. Therefore, it is necessary to conduct routine maintenance to the inverters.

Note:

As safety precautions, before carrying out check and maintenance of the inverter, please ensure that :

The inverter has been switched off;

The charging LED lamp in the inverter is off, which can be seen after removing the cover.

### 9.1 Routine Maintenance

The inverter must be operated in the environment specified in the Section 2.1. Besides, some unexpected accidents may occur during operation. The user should perform the routine maintenance to ensure a good operation environment according to the table below. A good way to prolong the lifetime of the inverter is to record the routine operation data, find out and clear faults in the early stage.

Table 7-1 Daily Checking Items

| Object      | Check                   |                         | Criterion                             |
|-------------|-------------------------|-------------------------|---------------------------------------|
|             | Items                   | Methods                 |                                       |
| Environment | Temperature 、humidity   | Thermometer, hygrometer | -10°C ~+40°C. Derate if at 40°C ~50°C |
|             | Dust, water and leakage | Observe                 | No sign of leakage                    |
|             | Vibration               | Vibration meter         | Less than 5.9m/s <sup>2</sup> (0.6g)  |
|             | Gas                     | Smell                   | No strange smell                      |
| Inverter    | Heat                    | Touch the casing        | Normal air flow                       |
|             | Sound                   | Listen                  | No strange sound                      |
|             | Output current          | Clamp meter             | Within rated range                    |
|             | Output voltage          | Voltage meter           | Within rated range                    |
| Motor       | Heat                    | Touch                   | No overheat                           |
|             | Sound                   | Listen                  | No strange sound                      |

### 9.2 Periodic Maintenance

You should check the inverter every 3 months or 6 months according to the actual environment.

Note:

1. Only trained personnel can dismantle the inverters for repairing or device replacement;

2. Don't leave metal parts like screws or pads in the inverter, otherwise the equipment may be damaged.

---

### 9.3 General Inspection::

1. Whether screws of control terminals are loose. If so, tighten them with a screwdriver;
  2. Whether the main circuit terminals are properly connected; whether the mains cables are over heated;;
  3. Whether the power cables and control cables are damaged, check especially for any wear on the cable insulation;
  4. Whether the insulating tapes around the cable lugs are stripped;
  5. Clean the dust on PCBs and air ducts with a vacuum cleaner;
  6. For inverters that have been stored for a long time, it must be powered on every 2 years. When supplying AC power to the inverter, use a voltage regulator to raise the input voltage to rated input voltage gradually. The inverter should be powered for 5 hours without driving a motor load.
  7. Before performing insulation tests, all main circuit input/output terminals should be short-circuited with conductors. Then proceed insulation test to the ground. Insulation test of single main circuit terminal to ground is prohibited; The inverter can be damaged by such a test. Please use a 500V Mega-Ohm-Meter.
  8. If performing insulation test to the motor, be sure to disconnect the cables between the inverter and it. Otherwise, the inverter might be damaged.
- 

#### Note:

Dielectric test of the inverter has already been done in the factory. It is not necessary for the user to do dielectric test again in order to avoid potential damage of its internal components.

---

### 9.4 Replacing Easily-worn Parts

The easily-worn parts of the inverter are cooling fan and electrolytic capacitor, whose life has close relation with the environment and maintenance. Refer to the table below.

| Part                   | Life                 |
|------------------------|----------------------|
| Fan                    | 30~40 thousand hours |
| Electrolytic capacitor | 40~50 thousand hours |
| Relay TA/TB/TC         | About 100,000 times  |

You can decide the time when the components should be replaced according to their service time.

1. Cooling fan

Possible cause of damages: wear of the bearing, aging of the fan vanes.

Criteria: After the inverter is switched off, check if abnormal conditions such as crack exists on fan vanes and other parts. When the inverter is switched on, check if inverter running is normal, and check if there is any abnormal vibration.

## 2. Electrolytic capacitors

Possible cause of damages: high ambient temperature, aging of electrolyte and large pulse current induced by rapid changing loads.

Criteria: Check if frequent over-current or over-voltage failures occur during inverter start-up with load. Check if there is any leakage of liquids (electrolytes) . Check if the safety valve protrudes. Measure static capacitance and insulation resistance.

## 3. Relay TA/TB/TC

Possible cause of damages: erosion, frequent operation.º

Criteria: ON/OFF malfunction.

## 9.5 Storing Inverters

The following points must be followed for the temporary and long-term storage of inverter:

1. Store in locations free of high temperature, humidity, dust, metal powder, and with good ventilation.
2. Long-term storage will cause the deterioration of electrolytic capacitors. Therefore, the inverter must be switched on for a test within 2 years, for at least 5 hours. The input 2 voltage must be applied gradually with a voltage regulator to the rated value.

## 9.6 Warranty

SANTERNO will offer warranty service in the case of the following situations:

1. The warranty clause is confined only to the inverter;
2. SANTERNO will take the responsibility of 36 months defects liability period for any faults or damages under the normal operation conditions as of manufacture date. After 36 months, maintenance will be charged;
3. Even within 36 months, maintenance would be charged under the following conditions:
  - ① Damages incurred to the inverter due to mis-operations which are not in compliance with "User Manual";
  - ② Damages incurred to the inverter due to fire, flood, abnormal voltage and so on;

③ Damages incurred to the inverter due to the improper use of inverter functions;

4. Service fee will be charged according to the actual costs. If there are any maintenance contracts, the contract prevails.

## Parameter Set

SINUS VEGA Series inverter's parameters are organized in groups. Each group has several parameters that are identified by "Group No.+ Parameter SN.". Parameter FX.YZ denotes that the parameter belongs to group "X" and its SN is "YZ". For example, "F5.08" belongs to group 5 and its SN is 8. For the convenience of setting the parameters, the group number corresponds to the menu level, 1, parameter number corresponds to menu level 2 and parameters of parameter correspond to the menu level 3. The setting of parameter is presented in decimal (DEC) and hexadecimal (HEX) format. If it is set in hexadecimal format, each digit of the setting is independent to one another.

### Explanation of the columns in Parameter Table:

The "LCD display" in third row refers to the parameter's name displayed by LED; The "setting range" in fourth row is the valid ranges of parameter settings; The "minimum unit" is the min. value of the parameter; The "factory setting" in sixth row is the primary factory settings; The "modification" in seventh row is the properties of modification (that is, whether it is allowed to be modified and conditions for modification) :

"O" denotes the parameters can be revised when the inverter is in operating or stop status;

"×" denotes the parameters can not be revised when the inverter is operating;

"\*" denotes the parameters are actually detected and can not be revised;

"—" denotes the parameters that are set by factory and the user cannot modify it;

(The inverter has already set the "auto-checking" function to the modification property of each parameter, so as to avoid wrong modification by the user)

The inverter provides passwords to protect the parameters against unauthorized modifications. After the user's password is set (that is, the settings of FP.00 are not zero), the inverter will require you to input the password before the user press the **PRG** to edit the parameter settings, otherwise you cannot set the parameters. For the parameters set by factory, you can only set the parameters after inputting factory password (you should not change the settings of the parameters set by factory because the inverter may operate abnormally or may be damaged if the parameters are not set correctly).

After setting the password, please don't press the keys within 5 minutes so as to enable the password. If the password is input correctly and the keys have not been pressed for longer than 5 minutes, the inverter will be locked by the password again. The user's password can be changed any time if the password protection is not locked up. The password that is input last time is valid.



The user's password can be disabled by setting FP.00 to 0. If FP.00 is not set to 0, then the parameters will be protected by the password.



It is defaulted that no parameters except F0.04 are allowed changing. If you need change them, please first set FP.01 (parameter write-in protection) from 1 to 0.

#### Appendix 1: Parameters set

| F0: Basic parameters |                          |                                                                                                                                                                                                                                                                        |           |         |              |
|----------------------|--------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|---------|--------------|
| Code                 | Name                     | Range                                                                                                                                                                                                                                                                  | Min. unit | Default | Modification |
| F0.00                | Command channel          | 0: LED keypad<br>1: Terminal control<br>2: Serial communication port                                                                                                                                                                                                   | 1         | 0       | ○            |
| F0.01                | Control mode             | 0: V/F control<br>1: Vector control                                                                                                                                                                                                                                    | 1         | 0       | ×            |
| F0.02                | Frequency source setting | 0: Digital setting 1(set by ▲ or ▼ key)<br>1: Digital setting 2(set by terminal UP/DN)<br>2: Digital setting 3(set by serial communication port)<br>3: VCI<br>4: CCI<br>5: Terminal pulse setting<br>6: Keypad Potentiometer Setting (for power rate lower than 4.0KW) | 1         | 0       | ○            |

| F0: Basic parameters |                               |                                                                                                                                                                                                                                                                                                                                  |           |                  |              |
|----------------------|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|------------------|--------------|
| Code                 | Name                          | Range                                                                                                                                                                                                                                                                                                                            | Min. unit | Default          | Modification |
| F0.03                | Auxiliary reference frequency | 0: Invalid<br>1: Keypad UP/DOWN (set by F0.05)<br>2: Terminal UP/DOWN(set by F0.05)<br>3:Serial communication port(set by F0.05)<br>4: VCI<br>5: CCI<br>6: PULSE<br>7: -VCI<br>8: -CCI<br>9: -PULSE<br>10: VCI-5<br>11: CCI-5<br>12 : PULSE-1/2*Max input pulse frequency<br>13: Potentiometer (for power rate lower than 4.0KW) | 1         | 0                | ○            |
| F0.04                | Keypad digital setting        | Lower limit of frequency ~<br>Lower limit of frequency                                                                                                                                                                                                                                                                           | 0.01Hz    | 50.00Hz          | ○            |
| F0.05                | Digital auxiliary setting     | 0.00~650.00Hz                                                                                                                                                                                                                                                                                                                    | 0.01Hz    | 0.00Hz           | ○            |
| F0.06                | Base frequency                | 1.00Hz~650.00Hz                                                                                                                                                                                                                                                                                                                  | 0.01Hz    | 50.00Hz          | ×            |
| F0.07                | Upper limit of freq.          | Upper limit~Max output freq.                                                                                                                                                                                                                                                                                                     | 0.01Hz    | 50.00Hz          | ×            |
| F0.08                | Lower limit of freq.          | 0~Upper limit of freq.                                                                                                                                                                                                                                                                                                           | 0.01Hz    | 0.00Hz           | ×            |
| F0.09                | Max output frequency          | Upper limit~650.00Hz                                                                                                                                                                                                                                                                                                             | 0.01Hz    | 50.00Hz          | ×            |
| F0.10                | Max output voltage            | 1~480V                                                                                                                                                                                                                                                                                                                           | 1V        | Inverter's rated | ×            |
| F0.11                | Running directions            | 0: Forward<br>1: Reverse                                                                                                                                                                                                                                                                                                         | 1         | 0                | ○            |

| F0: Basic parameters |                      |                                              |           |         |              |
|----------------------|----------------------|----------------------------------------------|-----------|---------|--------------|
| Code                 | Name                 | Range                                        | Min. unit | Default | Modification |
| F0.12                | Acc time 1           | 0.75KW ~ 22.0KW:0.1 ~ 3600s                  | 0.1       | 6s      | ○            |
|                      |                      | 30.0KW ~ 110.0KW:0.1 ~ 3600s                 | 0.1       | 20s     | ○            |
| F0.13                | Dec time 1           | 0.75KW ~ 22.0KW:0.1 ~ 3600s                  | 0.1       | 6s      | ○            |
|                      |                      | 30.0KW~110.0KW:0.1~3600s                     | 0.1       | 20s     | ○            |
| F0.14                | Anti-reverse setting | 0: Reverse allowed<br>1: Reverse not allowed | 1         | 0       | ×            |

| F1: Motor Parameter |                      |             |          |                    |              |
|---------------------|----------------------|-------------|----------|--------------------|--------------|
| Code                | Name                 | Range       | Min unit | Default            | Modification |
| F1.00               | Reserved             |             |          |                    | ×            |
| F1.01               | Motor's poles        | 2~14        | 2        | 4                  | ×            |
| F1.02               | Rated power          | 0.4~999.9Kw | 0.1KW    | Depending on model | ×            |
| F1.03               | Rated current        | 0.1~999.9A  | 0.1A     | Depending on model | ×            |
| F1.04               | Current without load | 0.1~999.9A  | 0.1A     | Depending on model | ×            |
| F1.05               | Stator resistance    | 0.0~50.00%  | 0.01%    | Depending on model | ○            |
| F1.06               | Leakage inductance   | 0.0~50.00%  | 0.01%    | Depending on model | ○            |
| F1.07               | Rotor resistance     | 0.0~50.00%  | 0.01%    | Depending on model | ○            |

| F1: Motor Parameter |                      |                                                                                    |          |                    |              |
|---------------------|----------------------|------------------------------------------------------------------------------------|----------|--------------------|--------------|
| Code                | Name                 | Range                                                                              | Min unit | Default            | Modification |
| F1.08               | Mutual inductance    | 0.0~2000.00%                                                                       | 0.1%     | Depending on model | ○            |
| F1.09               | Rated slip frequency | 0.00~20.00Hz                                                                       | 0.01Hz   | 2.00Hz             | ○            |
| F1.10               | Auto tuning          | 0: Auto-tuning is disabled<br>1: stationary auto-tuning<br>2: Rotating auto-tuning | 1        | 0                  | ×            |

| F2: Start/Brake Parameter |                           |                                                                                                                                                                                                   |          |         |              |
|---------------------------|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                      | Name                      | Range                                                                                                                                                                                             | Min unit | Default | Modification |
| F2.00                     | Start mode                | 0: Start at start frequency<br>1: Brake first and then start at start frequency<br>2: Rotate speed tracking and then start at start frequency<br>(it is reserved for power rate lower than 4.0KW) | 1        | 0       | ×            |
| F2.01                     | Start frequency           | 0.20~60.00Hz                                                                                                                                                                                      | 0.01Hz   | 0.2Hz   | ○            |
| F2.02                     | Start frequency hold time | 0.0~10.0s                                                                                                                                                                                         | 0.1s     | 0.0s    | ○            |

| F2: Start/Brake Parameter |                                   |                                                                                                                                                                                                                                      |          |         |              |
|---------------------------|-----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                      | Name                              | Range                                                                                                                                                                                                                                | Min unit | Default | Modification |
| F2.03                     | DC brake current at startup       | Heavy duty power rate lower than 4.0KW: 0.0~150.0% inverter rated current<br>Normal duty : 0.0~130.0% rated current<br>Heavy duty power rate larger than 5.5KW<br>0.0~100.0% rated current<br>Normal duty: 0.0 ~ 80.0% rated current | 0.1%     | 0.0%    | ○            |
| F2.04                     | DC brake time at startup          | For power rate lower than 4.0KW: 0.0 disabled 0.1~60.0s<br>For power rate larger than 5.5KW: 0.0 disabled 0.1~30.0s                                                                                                                  | 0.1s     | 0.0s    | ○            |
| F2.05                     | Acc/Dec                           | 0: Linear Acc/Dec<br>1: S curve Acc/Dec                                                                                                                                                                                              | 1        | 0       | ×            |
| F2.06                     | S curve start time                | 10.0~50.0%(Acc/dec time)<br>F2.06+F2.07<90.0%                                                                                                                                                                                        | 0.1%     | 20.0%   | ○            |
| F2.07                     | S curve rising time               | 10.0~80.0%( Acc/dec time)<br>F2.06+F2.07<90.0%                                                                                                                                                                                       | 0.1%     | 60.0%   | ○            |
| F2.08                     | Stop mode                         | 0: Decelerate to stop<br>1: Coast to stop<br>2 : Deceleration + DC braking                                                                                                                                                           | 1        | 0       | ×            |
| F2.09                     | Frequency threshold of DC braking | 0.00~60.00Hz                                                                                                                                                                                                                         | 0.01Hz   | 1.00Hz  | ○            |
| F2.10                     | DC brake delay time               | 0.00~10.00s                                                                                                                                                                                                                          | 0.01s    | 0.00s   | ○            |

| F2: Start/Brake Parameter |                                                |                                                                                                                      |          |         |              |
|---------------------------|------------------------------------------------|----------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                      | Name                                           | Range                                                                                                                | Min unit | Default | Modification |
| F2.11                     | DC brake current                               | Heavy duty power rate lower than 4.0KW: 0.0~150.0% inverter's rated current<br>Normal duty: 0.0~130.0% rated current | 0.1%     | 120.0%  | ○            |
|                           |                                                | Heavy duty power rate higher than 5.5KW: 0.0~100.0% rated current<br>Normal duty: 0.0~80.0% rated current            |          | 100.0%  |              |
| F2.12                     | DC brake time at stop                          | For power rate lower than 4.0KW: 0.0 disabled 0.1~60.0s<br>For power rate high than 5.5KW: 0.0 disabled 0.1~30.0s    | 0.1s     | 0.5s    | ○            |
| F2.13                     | Dynamic braking                                | 0: Disabled<br>1: Enabled                                                                                            | 1        | 0       | ×            |
| F2.14                     | Ration of braking time to total operating time | 0.0~100.0%                                                                                                           | 0.1%     | 100.0%  | ×            |

| F3: Flux vector control parameters |                   |                                                                                                                           |          |         |              |
|------------------------------------|-------------------|---------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                               | Name              | Range                                                                                                                     | Min unit | Default | Modification |
| F3.00                              | V/F curve setting | 0: User defined V/F curve<br>1: curve1, a 2-order curve<br>2: curve 2, a 1.7-order curve<br>3: curve 3, a 1.2-order curve | 1        | 0       | ×            |
| F3.01                              | V/F freq. F3      | F3.03~F0.06                                                                                                               | 0.01Hz   | 0.00Hz  | ×            |

| F3: Flux vector control parameters |                                  |                                                                     |          |                    |              |
|------------------------------------|----------------------------------|---------------------------------------------------------------------|----------|--------------------|--------------|
| Code                               | Name                             | Range                                                               | Min unit | Default            | Modification |
| F3.02                              | V/F voltage V3                   | F3.04~100%                                                          | 0.1%     | 0.0%               | ×            |
| F3.03                              | V/F freq. F2                     | F3.05~F3.01                                                         | 0.01Hz   | 0.00Hz             | ×            |
| F3.04                              | V/F voltageV2                    | F3.06~F3.02                                                         | 0.1%     | 0.0%               | ×            |
| F3.05                              | V/F freq. F1                     | 0.00~F3.03                                                          | 0.01Hz   | 0.00Hz             | ×            |
| F3.06                              | V/F voltageV1                    | 0~F3.04                                                             | 0.1%     | 0.0%               | ×            |
| F3.07                              | Torque boost                     | 0.0%~30.0%                                                          | 0.1%     | 0.0%               | ○            |
| F3.08                              | Manual torque boost cutoff point | 0.0%~50.0%                                                          | 0.1%     | 10%                | ○            |
| F3.09                              | Slip compensation gain           | 0.0~300.0%                                                          | 0.1%     | 100.0%             | ○            |
| F3.10                              | Slip compensation limit          | 0.0~250.0%                                                          | 0.1%     | 200.0%             | ○            |
| F3.11                              | Compensation time                | 0.75 KW~4.0KW:0.1~25.0s                                             | 0.1s     | 0.1s               | ×            |
|                                    |                                  | 5.5KW~110.0KW:0.1~25.0s                                             | 0.1s     | 0.5s               | ×            |
| F3.12                              | AVR function                     | 0: Disabled<br>1: Always enabled<br>2: Disabled during decelerating | 1        | 2                  | ×            |
| F3.13                              | Auto energy saving               | 0: Disabled<br>1: Enabled                                           | 1        | 0                  | ×            |
| F3.14                              | Motor stabilization factor       | 0~255                                                               | 1        | Depending on model | ○            |

| F4: Current vector control parameter (11) |          |       |          |         |              |
|-------------------------------------------|----------|-------|----------|---------|--------------|
| Code                                      | Name     | Range | Min unit | Default | Modification |
| F4.00                                     | Reserved | -     | -        | -       | *            |

| F4: Current vector control parameter (11) |                                       |                        |          |         |                       |
|-------------------------------------------|---------------------------------------|------------------------|----------|---------|-----------------------|
| Code                                      | Name                                  | Range                  | Min unit | Default | Modification          |
| F4.01                                     | Pre-excitation                        | 0: Valid<br>1: Invalid | 1        | 1       | <input type="radio"/> |
| F4.02                                     | Speed loop proportional gain 1        | 0~65535                | 1        | 120     | <input type="radio"/> |
| F4.03                                     | Speed loop integral gain 1            | 0~65535                | 1        | 3       | <input type="radio"/> |
| F4.04                                     | Speed loop proportional gain 2        | 0~65535                | 1        | 120     | <input type="radio"/> |
| F4.05                                     | Speed loop integral gain 2            | 0~65535                | 1        | 3       | <input type="radio"/> |
| F4.06                                     | Speed loop switching frequency        | 0.0%~100.0%            | 0.1%     | 0       | <input type="radio"/> |
| F4.07                                     | D axis current loop proportional gain | 0~65535                | 1        | 10000   | <input type="radio"/> |
| F4.08                                     | D axis current loop integral gain     | 0~65535                | 1        | 2000    | <input type="radio"/> |
| F4.09                                     | Q axis current loop proportional gain | 0~65535                | 1        | 10000   | <input type="radio"/> |
| F4.10                                     | Q axis current loop integral gain     | 0~65535                | 1        | 2000    | <input type="radio"/> |



| F5: Multi-function terminal (22) |                                        |                                                    |          |         |              |
|----------------------------------|----------------------------------------|----------------------------------------------------|----------|---------|--------------|
| Code                             | Name                                   | Range                                              | Min unit | Default | Modification |
| F5.00                            | Function of multi-function terminal X1 | 0: No function                                     | 1        | 0       | ×            |
|                                  |                                        | 1: MS frequency 1                                  |          |         |              |
|                                  |                                        | 2: MS frequency 2                                  |          |         |              |
|                                  |                                        | 3: MS frequency 3                                  |          |         |              |
|                                  |                                        | 4: Acc/Dec time 1                                  |          |         |              |
|                                  |                                        | 5: Acc/Dec time 2                                  |          |         |              |
|                                  |                                        | 6: External fault normally-open input              |          |         |              |
| F5.01                            | Function of multi-function terminal X2 | 7: External fault normally-closed input            | 1        | 0       | ×            |
|                                  |                                        | 8: Reset signal                                    |          |         |              |
|                                  |                                        | 9: Forward jog                                     |          |         |              |
|                                  |                                        | 10: Reverse jog                                    |          |         |              |
|                                  |                                        | 11: Coast-to-stop input                            |          |         |              |
|                                  |                                        | 12: Frequency increase(UP)                         |          |         |              |
|                                  |                                        | 13: Frequency decrease(DN)                         |          |         |              |
| F5.02                            | Function of multi-function terminal X3 | 14: PLC operation pause                            | 1        | 0       | ×            |
|                                  |                                        | 15: Acc/Dec prohibit                               |          |         |              |
|                                  |                                        | 16: 3-wire operation control                       |          |         |              |
|                                  |                                        | 17: External interrupt signal normally-open input  |          |         |              |
|                                  |                                        | 18: External interrupt signal normally-close input |          |         |              |
|                                  |                                        | 19: DC injection braking command                   |          |         |              |
|                                  |                                        | 20: Disable close-loop                             |          |         |              |
|                                  |                                        | 21: Disable PLC                                    | 1        | 0       | ×            |
|                                  |                                        |                                                    |          |         |              |

| F5: Multi-function terminal (22) |                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |          |         |              |
|----------------------------------|----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                             | Name                                   | Range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | Min unit | Default | Modification |
| F5.03                            | Function of multi-function terminal X4 | 22: Frequency setting method 1<br>23: Frequency setting method 2<br>24: Frequency setting method 3<br>25: Reference freq. is input via CCI<br>26: Reserved<br>27 : Terminal control mode is forcibly enabled<br>28: Control mode 1<br>29: Control mode 2<br>30: MS close-loop 1                                                                                                                                                                                                                                                                                               |          |         |              |
| F5.04                            | Function of multi-function terminal X5 | 31: MS close-loop 2<br>32: MS close-loop 3<br>33: Start traverse operation<br>34: Reset the traverse operation status<br>35: External stop command<br>36: Reserved<br>37: Inverter operation prohibiting<br>38: Reserved<br>39: Clear length<br>40: Clear auxiliary reference frequency<br>41: Reset PLC stop status<br>42: Clear counter's record<br>43: Signal of triggering counter<br>44: Input the signal of length<br>45: Pulse input<br>46: Single phase speed measuring<br>47: Speed measuring input SM1 (only for X4)<br>48: Speed measuring input SM2 (only for X5) |          |         |              |
| F5.05                            | Reserved                               | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | -        | -       | *            |
| F5.06                            | Reserved                               | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | -        | -       | *            |

| F5: Multi-function terminal (22) |                                      |                                                                                                                                                                                                                               |          |          |              |
|----------------------------------|--------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|----------|--------------|
| Code                             | Name                                 | Range                                                                                                                                                                                                                         | Min unit | Default  | Modification |
| F5.07                            | Reserved                             | -                                                                                                                                                                                                                             | -        | -        | *            |
| F5.08                            | Terminal control mode                | 0: 2-wire operating mode 1<br>1: 2-wire operating mode 2<br>2: 3-wire operating mode 1<br>3: 3-wire operating mode 2                                                                                                          | 1        | 0        | ×            |
| F5.09                            | UP/DN rate                           | 0.01~99.99Hz/s                                                                                                                                                                                                                | 0.01Hz/s | 1.00Hz/s | ○            |
| F5.10                            | Freq. Curve selection                | One's place of F5.10: VCI curve selection<br>0: curve 1<br>1: curve 2<br>Ten's place of F5.10: CCI curve selection<br>0: curve 1<br>1: curve 2<br>Hundred's place of F5.10: PULSE curve selection<br>0: curve 1<br>1: curve 2 | 1        | 000      | ○            |
| F5.11                            | Gain of reference frequency selector | 0.00~9.99                                                                                                                                                                                                                     | 0.01     | 1.00     | ○            |
| F5.12                            | Filter constant                      | 0.01~50.00                                                                                                                                                                                                                    | 0.01s    | 0.50s    | ○            |
| F5.13                            | Max. input pulse freq.               | 0.1~50.0kHz                                                                                                                                                                                                                   | 0.1k     | 10.0kHz  | ○            |
| F5.14                            | Ratio of Min. input of curve 1       | 0.0%~F5.16                                                                                                                                                                                                                    | 0.1%     | 2.0%     | ○            |

| F5: Multi-function terminal (22) |                                                |              |          |         |              |
|----------------------------------|------------------------------------------------|--------------|----------|---------|--------------|
| Code                             | Name                                           | Range        | Min unit | Default | Modification |
| F5.15                            | Frequency corresponds to min. input if curve   | 0.00~F0.09   | 1        | 0.00Hz  | ○            |
| F5.16                            | Ratio of Max. input of curve1                  | F5.14~100.0% | 0.1%     | 100.0%  | ○            |
| F5.17                            | Frequency corresponds to max. input of curve 1 | 0.00%~F0.09  | 1        | 50.00Hz | ○            |
| F5.18                            | Ratio of Min. input of curve2                  | 0.0%~F5.20 ( | 0.1%     | 0.0%    | ○            |
| F5.19                            | Frequency corresponds to min. input            | 0.00~F0.09   | 1        | 0.00Hz  | ×            |
| F5.20                            | Ratio of Max. input of curve 2                 | F5.18~100.0% | 0.1%     | 100.0%  | ○            |
| F5.21                            | Frequency corresponds to max. input            | 0.00~F0.09   | 1        | 50.00Hz | ○            |

| F6: Output terminal control parameters (18) |                                   |                                                                                                                                                                                                                              |          |         |              |
|---------------------------------------------|-----------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                                        | Name                              | Range                                                                                                                                                                                                                        | Min unit | default | Modification |
| F6.00                                       | Open collector output terminal Y1 | 0: Inverter running signal (RUN)<br>1: Frequency arrival signal (FAR)<br>2: Frequency detection threshold (FDT1)<br>3: Frequency detection threshold (FDT2)<br>4: Overload signal (OL)<br>5: Low voltage lock-up signal (LU) | 1        | 0       | ×            |
| F6.01                                       | Open collector output terminal Y2 | 6: External stop command (EXT)<br>7: Higher limit of frequency (FHL)<br>8: Lower limit of frequency (FLL)<br>9: Zero-speed running<br>10: Completion of simple PLC operation                                                 | 1        | 1       | ×            |
| F6.02                                       | Relay 1 output function           | 11: PLC cycle completion indication<br>12: Preset counting value arrival<br>13: Specified counting value arrival<br>14: Preset length arrival                                                                                | 1        | 16      | ×            |

| F6: Output terminal control parameters (18) |                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |          |         |              |
|---------------------------------------------|-----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                                        | Name                              | Range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | Min unit | default | Modification |
| F6.03                                       | Relay power (for rate lower than) | 15: Inverter is ready (RDY)<br>16: Inverter fails<br>17: Extended function 1 of host<br>18: Upper and lower limits of traverse frequency<br>19: Preset operation time out<br>20: Freq. before slip compensation<br>21: Freq. after slip compensation<br>22: Preset freq.<br>23: Output current (0~2 times of inverter's rated current)<br>24: Output current (0~2 times of motor's rated current)<br>25: Output torque (0~2 times of motor's rated torque)<br>26: Output voltage (0~1.2 times of inverter's rated voltage)<br>27: Bus voltage (0~800V)<br>28: VCI (0~10V)<br>29: CCI (0~10V/0~20mA)<br>30: Output power (0~2times rated power)<br>31: Extended function 2 of host (0~65535)<br>32: Potentiometer setting<br>Note : 20 ~ 32 for the Y2 proprietary<br>0: Output frequency before slip compemsation (0 ~ Max. output frequency) |          |         |              |

| F6: Output terminal control parameters (18) |                     |                                                             |          |         |              |
|---------------------------------------------|---------------------|-------------------------------------------------------------|----------|---------|--------------|
| Code                                        | Name                | Range                                                       | Min unit | default | Modification |
| F6.04                                       | AO1 output function | 0 : Output freq. before compensation                        | 1        | 0       | ○            |
|                                             |                     | 1 : Output freq. after compensation                         |          |         |              |
|                                             |                     | 2: Preset freq. (0~Max. output freq.)                       |          |         |              |
|                                             |                     | 3: Output current (0~2 times of inverter's rated current)   |          |         |              |
| F6.05                                       | AO2 output function | 4: Output current (0~2 times of motor's rated current)      | 1        | 3       | ○            |
|                                             |                     | 5: Output torque (0~2 times of motor's torque)              |          |         |              |
|                                             |                     | 6: Output voltage (0~1.2 times of inverter's rated voltage) |          |         |              |
|                                             |                     | 7: Bus voltage (0~800V)                                     |          |         |              |
|                                             |                     | 8: VCI (0~10V)                                              |          |         |              |
|                                             |                     | 9: CCI (0~10V/0~20mA)                                       |          |         |              |
|                                             |                     | 10: Output power (0~2 times of rated power)                 |          |         |              |
|                                             |                     | 11: Extended function 2 of host (0~65535)                   |          |         |              |
|                                             |                     | 12 : Setting of potentiometer (0~10V)                       |          |         |              |
|                                             |                     |                                                             |          |         |              |
| F6.06                                       | Reserved            | -                                                           | -        | -       | *            |

| F6: Output terminal control parameters (18) |                                     |                                                                                                                                                                |          |         |              |
|---------------------------------------------|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                                        | Name                                | Range                                                                                                                                                          | Min unit | default | Modification |
| F6.07                                       | Analog output range                 | LED one's place: AO1 output range<br>0: 0~10V or 0~20mA<br>1: 2~10V or 4~20mA<br>LED ten's place: AO2 output range<br>0: 0~10V or 0~20mA<br>1: 2~10V or 4~20mA | 1        | 00      | ○            |
| F6.08                                       | AO1 output gain                     | 0.0~200.0%                                                                                                                                                     | 0.1%     | 100.0%  | ○            |
| F6.09                                       | AO2 output gain                     | 0.0~200.0%                                                                                                                                                     | 0.1%     | 100.0%  | ○            |
| F6.10                                       | Max output pulse freq. of Y2        | 0.1~50.0kHz                                                                                                                                                    | 0.1      | 10.0kHz | ○            |
| F6.11                                       | Preset counting value               | F6.12~9999                                                                                                                                                     | 1        | 0       | ○            |
| F6.12                                       | Specified counting value            | 0~F6.11                                                                                                                                                        | 1        | 0       | ○            |
| F6.13                                       | Freq. arrival detection range (FAR) | 0.00~650.0Hz                                                                                                                                                   | 0.01Hz   | 2.50Hz  | ○            |
| F6.14                                       | FDT1 level                          | 0.00~650.0Hz                                                                                                                                                   | 0.01Hz   | 50.00Hz | ○            |
| F6.15                                       | FDT1 lag                            | 0.00~650.0Hz                                                                                                                                                   | 0.01Hz   | 1.00Hz  | ○            |



| F6: Output terminal control parameters (18) |            |              |          |         |              |
|---------------------------------------------|------------|--------------|----------|---------|--------------|
| Code                                        | Name       | Range        | Min unit | default | Modification |
| F6.16                                       | FDT2 level | 0.00~650.0Hz | 0.01Hz   | 25.00Hz | ○            |
| F6.17                                       | FDT2 lag   | 0.00~650.0Hz | 0.01Hz   | 1.00Hz  | ○            |

| F7: Close-loop control |                        |                                                                                                                                                                                                     |          |         |              |
|------------------------|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                   | Name                   | Range                                                                                                                                                                                               | Min unit | Default | Modification |
| F7.00                  | Close-loop control     | 0: Disabled<br>1: Enabled                                                                                                                                                                           | 1        | 0       | ×            |
| F7.01                  | reference input method | 0: digital setting (when F7.02=6, it refers to F7.06, the rest refer to F7.05)<br>1: VCI<br>2: CCI<br>3: LED keypad (for power rate lower than 4.0KW)<br>4: PULSE (for power rate lower than 4.0KW) | 1        | 1       | ○            |
| F7.02                  | Feedback method        | 0: VCI<br>1: CCI<br>2: VCI+CCI<br>3: VCI-CCI<br>4: MIN(VCI,CCI)<br>5: MAX(VCI,CCI)<br>6: Pulse                                                                                                      | 1        | 1       | ○            |
| F7.03                  | Input filter           | 0.01~50.00s                                                                                                                                                                                         | 0.01s    | 0.5s    | ○            |

| F7: Close-loop control |                                        |                                        |          |         |              |
|------------------------|----------------------------------------|----------------------------------------|----------|---------|--------------|
| Code                   | Name                                   | Range                                  | Min unit | Default | Modifacation |
| F7.04                  | Feedback filter                        | 0.01~50.00s                            | 0.01s    | 0.5s    | ○            |
| F7.05                  | Digital reference input                | 0.00~10.00V                            | 0.01     | 0.00    | ○            |
| F7.06                  | Speed close-loop setting               | 0~39000RPM                             | 1        | 0       | ○            |
| F7.07                  | Pulse number per revolution of encoder | 1~9999                                 | 1        | 1024    | ○            |
| F7.08                  | Min. input                             | 0.0%~F7.10                             | 0.1%     | 0.0     | ○            |
| F7.09                  | Feedback of min. input                 | 0.0~100.0%                             | 0.1%     | 20.0%   | ○            |
| F7.10                  | Max. input                             | F7.08~100.0%                           | 0.1%     | 100.0%  | ○            |
| F7.11                  | Feedback of max. input                 | 0.0~100.0%                             | 0.1%     | 100.0%  | ○            |
| F7.12                  | Proportional gain                      | 0.75 KW~4.0KW:0.000~9.999              | 0.001    | 2.000   | ○            |
|                        |                                        | 5.5KW~110.0KW:0.000~9.999              | 0.001    | 0.050   | ○            |
| F7.13                  | Integral gain                          | 0.75 KW~4.0KW:0.000~9.999              | 0.001    | 0.100   | ○            |
|                        |                                        | 5.5KW~110.0KW:0.000~9.999              | 0.001    | 0.050   | ○            |
| F7.14                  | Sampling cycle                         | 0.75 KW~4.0KW:0.01~50.00s              | 0.01s    | 0.10s   | ○            |
|                        |                                        | 5.5KW~110.0KW:0.01~50.00s              | 0.01s    | 0.50s   | ○            |
| F7.15                  | Error limit                            | 0.0~20.0%                              | 0.1%     | 2.0%    | ○            |
| F7.16                  | Close-loop regulation characteristics  | 0: Positive logic<br>1: Negative logic | 1        | 0       | ×            |

| F7: Close-loop control |                            |                                                                                                                                                                              |          |         |              |
|------------------------|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                   | Name                       | Range                                                                                                                                                                        | Min unit | Default | Modification |
| F7.17                  | Integral regulation        | 0: Stop integral regulation when the frequency reaches the upper or lower limits<br>1: Continue the integral regulation when the frequency reaches the upper or lower limits | 1        | 0       | ×            |
| F7.18                  | Preset frequency           | 0.00~650.0Hz                                                                                                                                                                 | 0.01Hz   | 0.00Hz  | ○            |
| F7.19                  | Preset frequency hold time | 0.0~3600s                                                                                                                                                                    | 0.1s     | 0.0s    | ×            |

| F8: MS parameters (20) |                         |                         |          |         |              |
|------------------------|-------------------------|-------------------------|----------|---------|--------------|
| Code                   | Name                    | Range                   | Min unit | Default | Modification |
| F8.00                  | MS freq. 1              | lower limit~upper limit | 0.01Hz   | 5.00Hz  | ○            |
| F8.01                  | MS freq. 2              |                         |          | 10.00Hz | ○            |
| F8.02                  | MS freq. 3              |                         |          | 20.00Hz | ○            |
| F8.03                  | MS freq. 4              |                         |          | 30.00Hz | ○            |
| F8.04                  | MS freq. 5              |                         |          | 40.00Hz | ○            |
| F8.05                  | MS freq. 6              |                         |          | 45.00Hz | ○            |
| F8.06                  | MS freq. 7              |                         |          | 50.00Hz | ○            |
| F8.07                  | MS close-loop setting 1 | 0.00~10.00V             | 0.01 V   | 0.00V   | ○            |
| F8.08                  | MS close-loop setting 2 |                         |          |         |              |
| F8.09                  | MS close-loop setting 3 |                         |          |         |              |
| F8.10                  | MS close-loop setting 4 |                         |          |         |              |
| F8.11                  | MS close-loop setting 5 |                         |          |         |              |
| F8.12                  | MS close-loop setting 6 |                         |          |         |              |

| F8: MS parameters (20) |                         |           |          |                                |              |
|------------------------|-------------------------|-----------|----------|--------------------------------|--------------|
| Code                   | Name                    | Range     | Min unit | Default                        | Modification |
| F8.13                  | MS close-loop setting 7 |           |          |                                |              |
| F8.14                  | Acc time 2              | 0.1~3600s | 0.1      | <<br>55G:6.0s<br>><br>3G:20.0s | ○            |
| F8.15                  | Dec time 2              |           |          |                                |              |
| F8.16                  | Acc time 3              |           |          |                                |              |
| F8.17                  | Dec time 3              |           |          |                                |              |
| F8.18                  | Acc time 4              |           |          |                                |              |
| F8.19                  | Dec time 4              |           |          |                                |              |

| F9: Enhanced function |                           |                                                                                                                                                                     |          |                           |              |
|-----------------------|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------------------------|--------------|
| Code                  | Name                      | Range                                                                                                                                                               | Min unit | Default                   | Modification |
| F9.00                 | Digital frequency control | LED one's place:<br>0: save after power off<br>1: Not save after power off<br>LED tem's place:<br>0: hold freq. after stop<br>1: restore to F0.04 after stop        | 1        | 00                        | ○            |
| F9.01                 | FWD/REV transition time   | 0~3600s                                                                                                                                                             | 0.1s     | 0.0s                      | ○            |
| F9.02                 | Carrier wave frequency    | 0.7kW ~ 4.0KW : 0.7 kHz ~ 15.0kHz<br>5.5kW ~ 15kW : 0.7kHz ~ 15.0kHz<br>18.5kW ~ 45kW : 0.7kHz ~ 10.0kHz<br>55kW~75kW: 0.7kHz~6.0kHz<br>90kW and above: 0.7kHz~3kHz | 0.1kHz   | Dependi<br>ng on<br>model | ×            |

| F9: Enhanced function |                     |                           |          |         |              |
|-----------------------|---------------------|---------------------------|----------|---------|--------------|
| Code                  | Name                | Range                     | Min unit | Default | Modification |
| F9.03                 | CWF auto adjustment | 0: Disabled<br>1: Enabled | 1        | 1       | ○            |
| F9.04                 | Motor tone          | 0~10                      | 1        | 0       | ○            |
| F9.05                 | Jog frequency       | 0.10 Hz~F0.07             | 0.01Hz   | 5.00Hz  | ○            |
| F9.06                 | Jog interval        | 0.1~100.0s                | 0.1s     | 0.0s    | ○            |
| F9.07                 | Jog Acc time        | 0.7kW~22.0KW: 0.1~60.0s   | 0.1      | 6s      | ○            |
|                       |                     | 30.0kW~110.0kW: 0.1~60.0s | 0.1      | 20s     | ○            |
| F9.08                 | Jog Dec time        | 0.7kW~22.0KW: 0.1~60.0s   | 0.1      | 6s      | ○            |
|                       |                     | 30.0kW~110.0kW: 0.1~60.0s | 0.1      | 20s     | ○            |
| F9.09                 | Skip freq. 1        | 0.00~650.0Hz              | 0.01Hz   | 0.00Hz  | ×            |
| F9.10                 | Skip freq. 1 range  | 0.00~30.00Hz              | 0.01Hz   | 0.00Hz  | ×            |
| F9.11                 | Skip freq. 2        | 0.00~650.0Hz              | 0.01Hz   | 0.00Hz  | ×            |
| F9.12                 | Skip freq. 2 range  | 0.00~30.00Hz              | 0.01Hz   | 0.00Hz  | ×            |
| F9.13                 | Skip freq. 3        | 0.00~650.0Hz              | 0.01Hz   | 0.00Hz  | ×            |
| F9.14                 | Skip freq.3 range   | 0.00~30.00Hz              | 0.01Hz   | 0.00Hz  | ×            |

| F9: Enhanced function |                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |          |         |              |
|-----------------------|-----------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                  | Name                                                | Range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Min unit | Default | Modification |
| F9.15                 | Positive or negative logic of terminal              | Binary setting:<br>0: breakover enabled<br>1: disconnect enabled<br>LED one's place:<br>Bit0~Bit3: X1~X4<br>LED ten's place:<br>Bit0: X5<br>Bit1~Bit3: reserved<br>LED hundred place:<br>Bit0 ~ Bit3:<br>FWD,REV,Y1,Y2                                                                                                                                                                                                                                                                                                                      | 1        | 000     | ○            |
| F9.16                 | operating command bundled with freq. method setting | LED one's place: keypad control<br>0: No bunding<br>1: digital setting 1(▲ and ▼)<br>2: digital setting 2(terminal UP/DN)<br>3: digital setting 3(serial port)<br>4: VCI analog input<br>5: CCI analog input<br>6: Pulse terminal input<br>7: Potentionmeter (for power rate lower than 4.0KW)<br>LED ten's place: terminal control<br>0: No bunding<br>1: digital setting 1(▲ and ▼)<br>2: digital setting 2(terminal UP/DN)<br>3: digital setting 3(serial port)<br>4: VCI analog input<br>5: CCI analog input<br>6: Pulse terminal input | 1        | 000     | ○            |

| F9: Enhanced function |                                                     |                                                                                                                                                                                                                                                                                                                                                            |          |         |              |
|-----------------------|-----------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                  | Name                                                | Range                                                                                                                                                                                                                                                                                                                                                      | Min unit | Default | Modification |
| F9.16                 | operating command bundled with freq. setting method | 7: potentiometer (for power rate lower than 4.0KW)<br>LED hundred place: serial port control<br>0: No bunding<br>1: digital setting 1(▲ and ▼)<br>2: digital setting 2(terminal UP/DN)<br>3: digital setting 3(serial port)<br>4: VCI analog input<br>5: CCI analog input<br>6: Pulse terminal input<br>7: potentiometer (for power rate lower than 4.0KW) | 1        | 000     | ○            |
| F9.17                 | Auxiliary reference factor                          | 0.00~9.99                                                                                                                                                                                                                                                                                                                                                  | 0.01     | 1.00    | ○            |
| F9.18                 | Digital auxiliary reference control                 | LED one's place: save control<br>0: save after power off<br>1: not save after power off<br>LED ten's place<br>0: hold reference frequency at stop<br>1: clear reference frequency at stop<br>LED hundred place: sign of auxiliary freq.<br>0: (+) positive sign<br>1: (−) negative sign                                                                    | 1        | 000     | ○            |
| F9.19                 | Preset freq. adjust mode                            | 0: disabled<br>1: regulate based on max. output freq. (F0.09)<br>2: regulate based on current output freq.                                                                                                                                                                                                                                                 | 1        | 0       | ○            |

| F9: Enhanced function |                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |          |         |              |
|-----------------------|-------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                  | Name                                | Range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Min unit | Default | Modification |
| F9.20                 | Factor for calculating preset freq. | 0.0~200.0%                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 0.1%     | 100.0%  | ○            |
| F9.21                 | Keypad functions                    | <p>LED one's place: STOP/RESET key's function</p> <p>0 : effective when keypad control is selected</p> <p>1 : effective for keypad, terminal and serial port control</p> <p>2 : it will display "F.Ed" alarm and the inverter will coast to stop when the inverter is not in panel control mode</p> <p>LED ten's place : LOCAL functions (for 4.0KW and below)</p> <p>0: disabled</p> <p>1: Enabled in STOP state</p> <p>2: Enabled in STOP &amp; RUN state</p> <p>LED hundred place : lock up keypad selection</p> <p>0: not lock the keypad</p> <p>1: lock all keys on the keypad</p> <p>2 : lock all keys on the keypad except STOP/RESET key</p> <p>3: lock all keys on the keypad except ►► key</p> <p>4: lock all keys on the keypad except RUN and STOP key</p> | 1        | 000     | ×            |



| F9: Enhanced function |                                                 |                                                                 |          |           |              |
|-----------------------|-------------------------------------------------|-----------------------------------------------------------------|----------|-----------|--------------|
| Code                  | Name                                            | Range                                                           | Min unit | Default   | Modification |
| F9.22                 | Cooling fan                                     | 0: Auto-stop mode<br>1: cooling fan keeps running upon power on | 1        | 0         | ×            |
| F9.23                 | Acc/Dec time unit                               | 0: second<br>1: minute                                          | 0        | 0         | ×            |
| F9.24                 | Droop control                                   | 0.00~10.00Hz                                                    | 0.01Hz   | 0.00Hz    | ○            |
| F9.25                 | High usage of bus voltage                       | 0: disabled<br>1: enabled                                       | 1        | 1         | ×            |
| F9.26                 | Zero freq. threshold                            | 0.00~650.0Hz                                                    | 0.01Hz   | 0.00Hz    | ○            |
| F9.27                 | Zero freq. hysteresis                           | 0.00~650.0Hz                                                    | 0.01Hz   | 0.00Hz    | ○            |
| F9.28                 | Low voltage compensation (trip free)            | 0: disabled<br>1: enabled                                       | 1        | 0         | ×            |
| F9.29                 | Freq. decrease rate during voltage compensation | 0.00~99.99Hz/s                                                  | 0.01Hz/s | 10.00Hz/s | ○            |
| F9.30                 | Conditions of restart after power failure       | 0: disabled<br>1: enabled                                       | 1        | 0         | ×            |
| F9.31                 | Restart delay after power failure               | 0.0~10.0s                                                       | 0.1s     | 0.5s      | ○            |
| F9.32                 | Reserved                                        | -                                                               | -        | -         | *            |
| F9.33                 | Braking unit operating voltage                  | 0.7kW~4.0KW: 650~780V                                           | 1        | 710V      | ○            |
|                       |                                                 | 5.5kW~160.0KW: 650~780V                                         | 1        | 750V      | ○            |
| F9.34                 | Terminal filter time                            | 0.5~100.0ms                                                     | 0.1ms    | 7.5ms     | ○            |

| F9: Enhanced function |                                 |              |          |         |              |
|-----------------------|---------------------------------|--------------|----------|---------|--------------|
| Code                  | Name                            | Range        | Min unit | Default | Modification |
| F9.35                 | Reserved                        |              |          |         |              |
| F9.36                 | undervoltage setting            | 75.0%~135.0% | 0.1%     | 90.0%   | ×            |
| F9.37                 | Load loss protection            | 0~1          | 1        | 0       | ○            |
| F9.38                 | Load loss fault level           | 0.0~100.0%   | 0.1%     | 30.0%   | ○            |
| F9.39                 | Load loss fault time            | 0~600.0s     | 0.1s     | 120.0   | ○            |
| F9.40                 | Torque enable in zero speed     | 0~1          | 1        | 0       | ○            |
| F9.41                 | Torque percentage in zero speed | 0.0~100%     | 0.1%     | 1.0%    | ○            |

| FA: Display Control Parameters |                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                             |          |         |              |
|--------------------------------|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                           | Name                                | Range                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Min unit | Default | Modification |
| FA.00                          | LED displayed parameter selection 1 | Binary setting:<br>0: not be displayed 1: displayed<br>LED one's place:<br>Bit0: output freq.(before compensation, Hz)<br>Bit1: output freq.(after compensation, Hz)<br>Bit2: reference frequency(Hz flicker)<br>Bit3: output current(A)<br>LED ten's place:<br>Bit0: actual speed(RPM)<br>Bit1: preset speed(RPM)<br>Bit2: actual line speed(m/s)<br>Bit3: preset line speed(m/s)<br>LED hundred's speed:<br>Bit0: output power<br>Bit1: output torque (%) | 1        | 00D     | ○            |

| FA: Display Control Parameters |                                     |                                                                                                                                                                                                                                                                                                                                                                                              |          |         |              |
|--------------------------------|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                           | Name                                | Range                                                                                                                                                                                                                                                                                                                                                                                        | Min unit | Default | Modification |
| FA.01                          | LED displayed parameter selection 2 | Binary setting:<br>0 : not be displayed 1 : displayed<br>LED one's place:<br>Bit0: output voltage(V)<br>Bit1: bus voltage<br>Bit2: VCI(V)<br>Bit3: CCI(V)<br>LED ten's place:<br>Bit0 : analog close-loop feedback(%)<br>Bit1 : analog close-loop setting(%)<br>Bit2: external counting value<br>Bit3: terminal status<br>LED hundred's place:<br>Bit0: actual length<br>Bit1: preset length | 1        | 000     | ○            |

| FA: Display Control Parameters |                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |          |         |              |
|--------------------------------|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                           | Name                                | Range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Min unit | Default | Modification |
| FA.02                          | Displayed parameter at stop state   | Binary setting:<br>0: not be displayed 1: displayed<br>LED one's place:<br>Bit0: reference freq.(Hz)<br>Bit1: external counting value<br>Bit2: actual speed (RPM)<br>Bit3: preset speed(RPM)<br>LED ten's place:<br>Bit0: actual line speed(m/s)<br>Bit1: preset line speed(m/s)<br>Bit2: VCI(V)<br>Bit3: CCI(V)<br>LED hundred's place:<br>Bit0 : analog close-loop feedback(%)<br>Bit1 : analog close-loop setting(%)<br>Bit2: actual length<br>Bit3: preset length<br>LED thousand's place:<br>Bit0: terminal status<br>Bit1: bus voltage | 1        | 2001    | ○            |
| FA.03                          | Rotating speed display factor       | 0.1~999.9%                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 0.1%     | 100.0%  | ○            |
| FA.04                          | Line speed factor                   | 0.1~999.9%                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 0.1%     | 1.0%    | ○            |
| FA.05                          | Close-loop parameter display factor | 0.1~999.9%                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 0.1%     | 100.0%  | ○            |

| FA: Display Control Parameters |                             |                                                                                                                                                                                                                                                                                                               |          |         |              |
|--------------------------------|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                           | Name                        | Range                                                                                                                                                                                                                                                                                                         | Min unit | Default | Modification |
| FA.06                          | Language                    | 0: Chinese<br>1: English                                                                                                                                                                                                                                                                                      | 1        | 0       | *            |
| FB: Communication              |                             |                                                                                                                                                                                                                                                                                                               |          |         |              |
| Code                           | Name                        | Range                                                                                                                                                                                                                                                                                                         | Min unit | Default | Modification |
| FB.00                          | Communication configuration | LED one's place: Baud rate<br>0: 1200bps<br>1: 2400bps<br>2: 4800bps<br>3: 9600bps<br>4: 19200bps<br>5: 38400bps<br>LED ten's place: data format<br>0: 1-8-2-N format, RTU<br>1: 1-8-1-E format, RTU<br>2: 1-8-1-O format, RTU<br>LED hundred's place: fictitious input terminal<br>0: disabled<br>1: enabled | 1        | 4       | ×            |
| FB.01                          | Local address               | 0~247, 0 is the broadcast address                                                                                                                                                                                                                                                                             | 1        | 1       | ×            |
| FB.02                          | Communicate timeout detect  | 0.0~1000s<br>When it is set at 0, the inverter will not detect the signals at the serial port                                                                                                                                                                                                                 | 0.1      | 0.0s    | ×            |
| FB.03                          | Response delay              | 0~1000ms                                                                                                                                                                                                                                                                                                      | 1        | 5ms     | ×            |

| FC: Traverse Parameters 1 (15) |                                     |                                                                                                                                                                                                                                                                                                                                                               |          |         |              |
|--------------------------------|-------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                           | Name                                | Range                                                                                                                                                                                                                                                                                                                                                         | Min unit | Default | Modification |
| FC.00                          | Traverse function selection         | 0: disabled<br>1: enabled                                                                                                                                                                                                                                                                                                                                     | 1        | 0       | ×            |
| FC.01                          | Taverse mode                        | LED one's place: transfer mode<br>0: auto<br>1: manually<br>LED ten's place : amplitude control<br>0: varied amplitude<br>1: fixed amplitude<br>LED hundred's place: start/stop mode<br>0: start to the state before stop<br>1 : just restart, no other requirement<br>LED thousand's place : save traverse state upon powerfailure<br>0: save<br>1: not save | 1        | 0000    | ×            |
| FC.02                          | Preset traverse frequency           | 0.00~650.0Hz                                                                                                                                                                                                                                                                                                                                                  | 0.01Hz   | 0.00Hz  | ○            |
| FC.03                          | Preset traverse frequency hold time | 0.0~3600.0s                                                                                                                                                                                                                                                                                                                                                   | 0.1s     | 0.0s    | ○            |
| FC.04                          | Traverse amplitude                  | 0.0~50.0%                                                                                                                                                                                                                                                                                                                                                     | 0.1%     | 0.0%    | ○            |
| FC.05                          | Step freq.                          | 0.0~50.0%                                                                                                                                                                                                                                                                                                                                                     | 0.1%     | 0.0%    | ○            |

| FC: Traverse Parameters 1 (15) |                              |                |           |           |              |
|--------------------------------|------------------------------|----------------|-----------|-----------|--------------|
| Code                           | Name                         | Range          | Min unit  | Default   | Modification |
| FC.06                          | Traverse cycle               | 0.1~999.9s     | 0.1s      | 10.0s     | ○            |
| FC.07                          | Rise time of triangular wave | 0.0~100.0%     | 0.1%      | 50.0%     | ○            |
| FC.08                          | Preset length                | 0.000~65.535km | 0.001(km) | 0.000(km) | ○            |
| FC.09                          | Actual length                | 0.000~65.535km | 0.001(km) | 0.000(km) | ○            |
| FC.10                          | Length factor                | 0.001~30.00    | 0.001     | 1.000     | ○            |
| FC.11                          | Length calibrate             | 0.001~1.000    | 0.001     | 1.000     | ○            |
| FC.12                          | Shaft circumference          | 0.01~100.0cm   | 0.01cm    | 10.00cm   | ○            |
| FC.13                          | Pulse per revolution         | 1~9999         | 1         | 1         | ○            |
| FC.14                          | Reserved                     | -              | -         | -         | *            |

| FD: PLC parameters |                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |          |         |              |
|--------------------|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code               | Name            | Range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Min unit | Default | Modification |
| FD.00              | Simple PLC mode | <p>LED one's place: PLC running mode selection</p> <p>0: Disabled</p> <p>1: stop after a single cycle</p> <p>2: Maintain value of the last stage after 1 cycle</p> <p>3: Continuous cycle</p> <p>LED ten's place: Restart mode after PLC interruption</p> <p>0: start from the first stage</p> <p>1: continue from the stage frequency where the inverter stops</p> <p>2: Start from the frequency where it stops</p> <p>LED hundred's place: Save PLC state after poweroff</p> <p>0: not save</p> <p>1: save</p> <p>LED thousand's place: Selection of time unit</p> <p>0: Second</p> <p>1: Minute</p> | 1        | 0000    | ×            |



| FD: PLC parameters |                  |                                                                                                                                                                                                                                                                                                                               |          |         |              |
|--------------------|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code               | Name             | Range                                                                                                                                                                                                                                                                                                                         | Min unit | Default | Modification |
| FD.01              | Stage 1 setting  | LED one's place:<br>0: MS frequency 1(F8.00)<br>1: determined by F0.02<br>2: MS close loop setting 1(F8.07)<br>3: Determined by P7.01<br>LED ten's place:<br>0: FWD<br>1: REV<br>2: Determined by running command<br>LED hundred's place:<br>0: Acc/Dec time 1<br>1: Acc/Dec time 2<br>2: Acc/Dec time 3<br>3: Acc/Dec time 4 | 1        | 000     | ○            |
| FD.02              | Stage 1 run time | 0.0~6500 s(min)                                                                                                                                                                                                                                                                                                               | 0.1      | 20.0s   | ○            |

| FD: PLC parameters |                  |                                                                                                                                                                                                                                                                                                                               |          |         |              |
|--------------------|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code               | Name             | Range                                                                                                                                                                                                                                                                                                                         | Min unit | Default | Modification |
| FD.03              | Stage 2 setting  | LED one's place:<br>0: MS frequency 2(F8.01)<br>1: determined by F0.02<br>2: MS close loop setting 2(F8.08)<br>3: Determined by F7.01<br>LED ten's place:<br>0: FWD<br>1: REV<br>2: Determined by running command<br>LED hundred's place:<br>0: Acc/Dec time 1<br>1: Acc/Dec time 2<br>2: Acc/Dec time 3<br>3: Acc/Dec time 4 | 1        | 000     | ○            |
| FD.04              | Stage 2 run time | 0.0~6500 s(min)                                                                                                                                                                                                                                                                                                               | 0.1      | 20.0s   | ○            |

| FD: PLC parameters |                  |                                                                                                                                                                                                                                                                                                                               |          |         |              |
|--------------------|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code               | Name             | Range                                                                                                                                                                                                                                                                                                                         | Min unit | Default | Modification |
| FD.05              | Stage 3 setting  | LED one's place:<br>0: MS frequency 3(F8.02)<br>1: determined by F0.02<br>2: MS close loop setting 3(F8.09)<br>3: Determined by F7.01<br>LED ten's place:<br>0: FWD<br>1: REV<br>2: Determined by running command<br>LED hundred's place:<br>0: Acc/Dec time 1<br>1: Acc/Dec time 2<br>2: Acc/Dec time 3<br>3: Acc/Dec time 4 | 1        | 000     | ○            |
| FD.06              | Stage 3 run time | 0.0~6500 s(min)                                                                                                                                                                                                                                                                                                               | 0.1      | 20.0s   | ○            |

| FD: PLC parameters |                  |                                                                                                                                                                                                                                                                                                                               |          |         |              |
|--------------------|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code               | Name             | Range                                                                                                                                                                                                                                                                                                                         | Min unit | Default | Modification |
| FD.07              | Stage 4 setting  | LED one's place:<br>0: MS frequency 4(F8.03)<br>1: determined by F0.02<br>2: MS close loop setting 4(F8.10)<br>3: Determined by F7.01<br>LED ten's place:<br>0: FWD<br>1: REV<br>2: Determined by running command<br>LED hundred's place:<br>0: Acc/Dec time 1<br>1: Acc/Dec time 2<br>2: Acc/Dec time 3<br>3: Acc/Dec time 4 | 1        | 000     | ○            |
| FD.08              | Stage 4 run time | 0.0~6500 s(min)                                                                                                                                                                                                                                                                                                               | 0.1      | 20.0s   | ○            |

| FD: PLC parameters |                  |                                                                                                                                                                                                                                                                                                                               |          |         |              |
|--------------------|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code               | Name             | Range                                                                                                                                                                                                                                                                                                                         | Min unit | Default | Modification |
| FD.09              | Stage 5 setting  | LED one's place:<br>0: MS frequency 5(F8.04)<br>1: determined by F0.02<br>2: MS close loop setting 5(F8.11)<br>3: Determined by F7.01<br>LED ten's place:<br>0: FWD<br>1: REV<br>2: Determined by running command<br>LED hundred's place:<br>0: Acc/Dec time 1<br>1: Acc/Dec time 2<br>2: Acc/Dec time 3<br>3: Acc/Dec time 4 | 1        | 000     | ○            |
| FD.10              | Stage 5 run time | 0.0~6500 s(min)                                                                                                                                                                                                                                                                                                               | 0.1      | 20.0s   | ○            |

| FD: PLC parameters |                  |                                                                                                                                                                                                                                                                                                                              |          |         |              |
|--------------------|------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code               | Name             | Range                                                                                                                                                                                                                                                                                                                        | Min unit | Default | Modification |
| FD.11              | Stage6 setting   | LED one's place:<br>0: MS frequency 6(F8.05)<br>1: determined by F0.02<br>2: MS close loop setting 6(F8.12)<br>3: Determined by F7.01<br>LED ten's place:<br>0: FWD<br>1: REV<br>2: Determined by running command<br>LED hundred's place<br>0: Acc/Dec time 1<br>1: Acc/Dec time 2<br>2: Acc/Dec time 3<br>3: Acc/Dec time 4 | 1        | 000     | ○            |
| FD.12              | Stage 6 run time | 0.0~6500 s(min)                                                                                                                                                                                                                                                                                                              | 0.1      | 20.0s   | ○            |

| FD: PLC parameters |               |                                                                                                                                                                                                                                                                                                                               |          |         |              |
|--------------------|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code               | Name          | Range                                                                                                                                                                                                                                                                                                                         | Min unit | Default | Modification |
| FD.13              | Stage setting | LED one's place:<br>0: MS frequency 7(F8.06)<br>1: determined by F0.02<br>2: MS close loop setting 7(F8.13)<br>3: Determined by F7.01<br>LED ten's place:<br>0: FWD<br>1: REV<br>2: Determined by running command<br>LED hundred's place:<br>0: Acc/Dec time 1<br>1: Acc/Dec time 2<br>2: Acc/Dec time 3<br>3: Acc/Dec time 4 | 1        | 000     | ○            |
| FD.14              | Stage runtime | 0.0~6500 s(min)                                                                                                                                                                                                                                                                                                               | 0.1      | 20.0s   | ○            |

### 11 parameters have reserved for FE

| FL: Protection |                                |                                                                                                                              |          |         |              |
|----------------|--------------------------------|------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code           | Name                           | Range                                                                                                                        | Min unit | Default | Modification |
| FL.00          | Motor overload protection load | 0: disabled<br>1: Common motor (with low speed compensation)<br>2: Variable frequency motor (without low speed compensation) | 1        | 0       | ×            |

| FL : Protection |                                        |                                                                                                                                                                                                                                                                                           |          |         |              |
|-----------------|----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code            | Name                                   | Range                                                                                                                                                                                                                                                                                     | Min unit | Default | Modification |
| FL.01           | Motor overload protection factor       | 20.0~110%                                                                                                                                                                                                                                                                                 | 0.1%     | 100.0%  | ×            |
| FL.02           | Stall overvoltage                      | 0: disabled<br>1: enabled                                                                                                                                                                                                                                                                 | 1        | 1       | ×            |
| FL.03           | Stall overvoltage point                | 120.0~150.0%                                                                                                                                                                                                                                                                              | 0.1%     | 140.0%  | ×            |
| FL.04           | Overload pre-alarm detection config    | LED one's place : overload detection mode<br>0: detect all the time<br>1 : detect in the case of constand speed<br>LED ten's place: overload action mode<br>0: No alarm<br>1: Alarm<br>LED hundred's place : reference current<br>0: motor's rated current<br>1: inverter's rated current | 1        | 000     | ×            |
| FL.05           | Overload pre-alarm detection threshold | 20.0~200.0%                                                                                                                                                                                                                                                                               | 0.1%     | 130.0%  | ×            |
| FL.06           | Overload pre-alarm alarm delay         | 0.0~60.0s                                                                                                                                                                                                                                                                                 | 0.1s     | 5.0s    | ×            |



| FL: Protection |                                             |                                                                                                             |          |                                   |              |
|----------------|---------------------------------------------|-------------------------------------------------------------------------------------------------------------|----------|-----------------------------------|--------------|
| Code           | Name                                        | Range                                                                                                       | Min unit | Default                           | Modification |
| FL.07          | Auto current limiting threshold             | 20.0~200.0%                                                                                                 | 0.1%     | G:150.0%<br>P:110.0%              | ×            |
| FL.08          | Freq. decrease rate during current limiting | 0.00~99.99Hz/s                                                                                              | 0.01Hz/s | 10.00Hz/s                         | ○            |
| FL.09          | Action mode of auto current limiting        | 0: disabled<br>1: enabled<br>2: effective all the time, no silencing function<br>3: Reserved<br>4: Reserved | 1        | Less than or equal to 4.0kw : 2   | ×            |
|                |                                             |                                                                                                             |          | Greater than or equal to 5.5kw: 1 |              |
| FL.10          | Auto reset time                             | 0~10                                                                                                        | 1        | 0                                 | ×            |
| FL.11          | Auto reset interval                         | 2.0~20.0s                                                                                                   | 0.1s     | 5.0s                              | ×            |

| FL : Protection |                          |                                                                                                                                                                                                                                                   |          |         |              |
|-----------------|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code            | Name                     | Range                                                                                                                                                                                                                                             | Min unit | Default | Modification |
| FL.12           | Protective action mode 1 | LED one's place : action for communication fault<br><br>0: alarm and coast to stop<br><br>1 : no alarm, continue operation<br><br>2: no alarm, stop<br><br>(only in serial port control mode)<br><br>3: no alarm, stop<br><br>(all control modes) | 1        | 001     | ×            |
|                 |                          | LED ten's place : action for contactor fault<br><br>( it is reserved for power rate lower than 4.0KW)<br><br>0: alarm and coast to stop<br><br>1 : No alarm, continue operation                                                                   |          |         |              |
|                 |                          | LED hundred's place: action for EEPROM fault<br><br>0: alarm and coast to stop<br><br>1 : No alarm, continue operation                                                                                                                            |          |         |              |

| FL: Protection |                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |          |         |              |
|----------------|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code           | Name                     | Range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | Min unit | Default | Modification |
| FL.13          | Protective action mode 2 | <p>LED one's place: indication for under voltage fault</p> <p>0: no indication</p> <p>1: indicate the fault</p> <p>LED ten's place: indication for auto reset fault</p> <p>0: no indication</p> <p>1: indication the fault</p> <p>LED hundred's place: fault lock-up</p> <p>0: disabled</p> <p>1: enabled (no fault indication)</p> <p>2: enabled (indicate the fault)</p> <p>(for power rate higher than 5.5KW Heavy duty)LED thousand's place: phase-loss protection</p> <p>0 : input/output phase-loss protection</p> <p>1: no input phase-loss protection</p> <p>2: no output phase-loss protection</p> <p>3: no phase-loss protection</p> <p>(for power rate lower than 4.0KW)</p> <p>LED thousand's place: phase-loss protection</p> <p>0: enabled</p> <p>1: disabled</p> | 1        | 0000    | ×            |

| FL : Protection |                                   |                                         |          |         |              |
|-----------------|-----------------------------------|-----------------------------------------|----------|---------|--------------|
| Code            | Name                              | Range                                   | Min unit | Default | Modification |
| FL.14           | Fault type of the first two times | 0: no fault record                      | 1        | 0       | *            |
|                 |                                   | 1: Over-current in Acc process(F.oC1)   |          |         |              |
| FL.15           | Fault type of the previous time   | 2 : Over-current in Dec process (F.oC2) | 1        | 0       | *            |
|                 |                                   | 3 : Over-current in constant speed      |          |         |              |

| FL : Protection |                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |          |         |              |
|-----------------|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code            | Name                        | Range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Min unit | Default | Modification |
| PL.16           | Fault type of the last time | operation (F.oC3)<br>4 : Over voltage in Acc process (F.oU1)<br>5 : Over voltage in Dec process (F.oU2)<br>6 : Over voltage inconstant-speed operating process(F.oU3)<br>7: Over voltage of inverter's control power supply (F.PoU)<br>8: input phase loss (F.IPL)<br>9: Output phase loss (F.oPL)<br>10: Module protection (F.FAL)<br>11 : Rectifier's heatsink overheat (F.oH1)<br>12 : Rectifier cooling fan overtemperature (F.oH2)<br>13: Inverter overload (F.oL1)<br>14: Motor overload (F.oL2)<br>15 : Emergency stop or external equipment fails (F.Ed)<br>16: E2PROM R/W fault (F.EEP)<br>17: RS485 communication failure (F.485)<br>18: Contactor fault (F.Con)<br>19: Current detection circuit is faulty<br>20: System disturbance (F.CPU)<br>21: Reserved<br>22: Reserved<br>23: Copy fault (F.CPy)<br>24: Tuning fault (F.tU) | 1        | 0       | *            |

| FL: Protection |                                  |                |          |         |              |
|----------------|----------------------------------|----------------|----------|---------|--------------|
| Code           | Name                             | Range          | Min unit | Default | Modification |
| FL.17          | Bus voltage at the last fault    | 0~999V         | 1V       | 0V      | *            |
| FL.18          | Output current at the last fault | 0.0~999.9A     | 0.1A     | 0.0A    | *            |
| FL.19          | Freq. at the last fault          | 0.00Hz~650.0Hz | 0.01Hz   | 0.00Hz  | *            |

| FN: Operation Time and Temperature of Cooling Fan |                              |             |          |         |              |
|---------------------------------------------------|------------------------------|-------------|----------|---------|--------------|
| Code                                              | Name                         | Range       | Min unit | Default | Modification |
| FN.00                                             | Preset operation time        | 0~65.535 kh | 0.001kh  | 0       | ○            |
| FN.01                                             | Total operation time         | 0~65.535 kh | 0.001kh  | 0       | *            |
| FN.02                                             | Temperature of cooling fan 1 | 0.0~100.0℃  | 0.1      | 0℃      | *            |
| FN.03                                             | Temperature of cooling fan 2 | 0.0~100.0℃  | 0.1      | 0℃      | *            |

| FP: Protection of Parameters |                     |                                                                                                                                                           |          |         |              |
|------------------------------|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|--------------|
| Code                         | Name                | Range                                                                                                                                                     | Min unit | Default | Modification |
| FP.00                        | User password       | 0000~9999                                                                                                                                                 | 0        | 0000    | ○            |
| FP.01                        | Write-in protection | 0: All parameters are allowed to be changed<br>1: No parameters can be changed except the F0.04 and FP.01<br>2: No parameters can be changed except FP.01 | 1        | 0       | ○            |

| FP: Protection of Parameters |                          |                                                                        |          |         |              |
|------------------------------|--------------------------|------------------------------------------------------------------------|----------|---------|--------------|
| Code                         | Name                     | Range                                                                  | Min unit | Default | Modification |
| FP.02                        | Parameter initialization | 0: disabled<br>1: clear fault record<br>2: restore to factory defaults | 1        | 0       | ×            |
| FP.03                        | Reserved                 |                                                                        |          |         | ×            |
| FP.04                        | Reserved                 |                                                                        |          |         | *            |

| FU: Factory Default |          |       |          |                    |              |
|---------------------|----------|-------|----------|--------------------|--------------|
| Code                | Name     | Range | Min unit | Default            | Modification |
| FU.00               | Password | ***** | 1        | Set by manufacture | -            |


## 10. Communication Protocol

### 10.1 Communication Mode

1. The protocol is Modbus protocol. Besides the common register Read/Write operation, it is supplemented with commands of parameters management.
2. The inverter is a slave in the network. It communicates in 'point to point' master-slave mode. It will not respond to the command sent by the master via broadcast address.
3. In the case of multi-inverter communication or long-distance transmission, connecting "GND" in parallel with the master signal line will help to enhance the immunity to interference.

### 10.2 Protocol Format

Modbus protocol supports both RTU mode. The frame format is illustrated as follows:



Modbus adopts "Big Endian" Representation for data frame.

This means that when a numerical quantity larger than a byte is transmitted, the most significant byte is sent first. Under RTU mode, the idle time between frames is decided by the bigger value between parameter setting by FF.03 and the Modbus minimum idle time. The minimum Modbus idle time between frames should be no less than 3.5 bytes. The checksum adopts CRC-16 method. All data except checksum itself sent will be counted into the calculation. Please refer to section: CRC Check for more information. Note that at least 3.5 bytes of modbus idle time should be kept, and the start and end idle time need not be summed up to it.

The table below shows the data frame of reading parameter 002 from Inverter No. 1.

| Address | Code | Register address |      | Quantity of inputs |      | Checksum |      |
|---------|------|------------------|------|--------------------|------|----------|------|
| 0x01    | 0x03 | 0x00             | 0x04 | 0x00               | 0x01 | 0xC5     | 0xCB |

The table below shows the reply frame from Inverter No. 1:

| Address | Code | Reply bytes | Register content |      | Checksum |      |
|---------|------|-------------|------------------|------|----------|------|
| 0x01    | 0x03 | 0x02        | 0x13             | 0x88 | 0xB5     | 0x12 |

Different response delay time can be set through inverter's parameters to adapt to different needs. For RTU mode, the response delay time should be no less than 3.5 bytes interval.



### 10.3 Protocol function

The main functions of Modbus is to read and write parameters. The Modbus protocol supports the following function code:

| Function code | Function                                                                                 |
|---------------|------------------------------------------------------------------------------------------|
| 0x03          | Read inverter's parameter and operation status parameters                                |
| 0x06          | Modify single inverter's parameter or control parameters. Not save them upon power-off.  |
| 0x08          | Serial line diagnosis                                                                    |
| 0x10          | Modify several inverters' parameter or control parameters. Not save them upon power-off. |
| 0x41          | Modify single inverter's parameter or control parameters. Saving them upon power-off.    |
| 0x42          | Parameter management                                                                     |

All inverter's parameters, control and status parameters are mapped to Modbus R/W Register. The R/W properties of the parameters and their setting ranges are specified in the user manual. The group number of the inverter's parameter maps to the most significant byte of the register address, and the index number of the parameter in the group maps to the least significant byte. The control and status parameters of the inverter are virtually taken as parameter group. The relationship of group number of the parameters and the most significant byte of register address is listed below:

F0 group: 0x00; F1 group: 0x01; F2 group: 0x02; F3 group: 0x03; F4 group: 0x04; F5 group: 0x05; F6group: 0x06; F7 group: 0x07; F8 group: 0x08; F9 group: 0x09; FA group: 0x0A; FB group: 0x0B; FC group: 0x0C; FD group: 0x0D; FE group: 0x0E; FL group: 0x11; Fn group: 0x12; FP group: 0x13; FU group: 0x14; Inverter control parameter group: 0x32; Inverter status parameter group: 0x33.

E.g. the register address of F3.02: 0x302, register address of FB.01: 0xB01.

The above shows the format of the frame. Now we will introduce the Modbus function code and data unit for different function in details, which is called protocol data unit for simplicity. Also MSB stands for the most significant byte and LSB stands for the least significant byte for the same reason. The description below is data format in RTU mode. The length of data unit in ASCII mode should be doubled.

Protocol data unit format of reading parameters:

Request format::

| Protocol data unit       | Data length (bytes) | Range         |
|--------------------------|---------------------|---------------|
| Function code            | 1                   | 0x03          |
| Initial register address | 2                   | 0x0000~0xFFFF |
| Register number          | 2                   | 0x0001~0x0004 |

Response format :

| Protocol data unit       | Data length (bytes) | Range           |
|--------------------------|---------------------|-----------------|
| Function code            | 1                   | 0x03            |
| Number of bytes read out | 1                   | 2*Register Qty. |
| Contents                 | 2*Register Qty.     |                 |

If the operation fails, error code and exception code forming the protocol data unit will be replied. The error code is (Parameter+0x80) . The exception code denotes reason of the error; see the table below.

Table 1 Exception Code Meaning:

| Exception code | Meaning                                                                                    |
|----------------|--------------------------------------------------------------------------------------------|
| 0x1            | Invalid parameter.                                                                         |
| 0x2            | Invalid register address.                                                                  |
| 0x3            | Data error, exceeding upper or lower limit                                                 |
| 0x4            | Inverter operation failure, including invalid data, although within upper and lower limit. |
| 0x5            | Valid command, processing, mainly used in storing data into involatile memory              |
| 0x6            | Inverter busy, please try later. Mainly used in storing data into involatile memory.       |
| 0x18           | Information frame error, including data length or checksum error.                          |
| 0x20           | Parameter cannot be modified                                                               |
| 0x22           | Parameter protected by password.                                                           |

Protocol data unit format of modifying single Inverter's parameter:

Request format:

| Protocol data unit | Data length (bytes) | Range         |
|--------------------|---------------------|---------------|
| Parameter          | 1                   | 0x06          |
| Register Address   | 2                   | 0x0000~0xFFFF |
| Register content   | 2                   | 0x0000~0xFFFF |

Request format:

| Protocol data unit | Data length (bytes) | Range         |
|--------------------|---------------------|---------------|
| Parameter          | 1                   | 0x06          |
| Register Address   | 2                   | 0x0000~0xFFFF |
| Register content   | 2                   | 0x0000~0xFFFF |

If the operation fails, error code and exception code will be replied. The error code is (Parameter+0x80) . The exception code denotes reason of the error; see Table below. Protocol data unit format of serial line diagnosis:

Request format:

| Protocol data unit | Data length (bytes) | Range         |
|--------------------|---------------------|---------------|
| Parameter          | 1                   | 0x08          |
| Sub-function code  | 2                   | 0x0000~0x0030 |
| Data               | 2                   | 0x0000~0xFFFF |

Response format:

| Protocol data unit | Data length (bytes) | Range         |
|--------------------|---------------------|---------------|
| Parameter          | 1                   | 0x08          |
| Sub-function code  | 2                   | 0x0000~0x0030 |
| Data               | 2                   | 0x0000~0xFFFF |

If the operation fails, error code and message code will be replied. The error code is 88H. The exception code denotes reason of the error; see Table below.

Sub-function of line diagnosis:

| Sub-function code | Data (request)                                  | Data (respond)                                   | Meaning                                                                                                                                      |
|-------------------|-------------------------------------------------|--------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| 0x0001            | 0x0000                                          | 0x0000                                           | Initialize the communication, disable no-reply mode                                                                                          |
|                   | 0xFF00                                          | 0xFF00                                           | Initialize the communication, disable no-reply mode                                                                                          |
| 0x0003            | “newframe tail” and “00” occupy the MSB and LSB | “new frame tail” and “00” occupy the MSB and LSB | It will replace the old line feed character. It will not be saved upon power-off. Note: it must not be greater than 0x7F, nor equal to 0x3A. |
| 0x0004            | 0x0000                                          | No response                                      | To set no-response mode, so the Inverter respond only to “initialize communication” request. It is to isolate the faulty Inverter.           |
| 0x0030            | 0x0000                                          | 0x0000                                           | Inverter not respond to error or invalid command                                                                                             |
|                   | 0x0001                                          | 0x0001                                           | Inverter responds to error or invalid command                                                                                                |

Protocol data unit format of modifying several inverter’s parameter and status parameters:

Response format:

| Protocol data unit       | Data length (bytes) | Range         |
|--------------------------|---------------------|---------------|
| Function code            | 1                   | 0x10          |
| Initial register address | 2                   | 0x0000~0xFFFF |

|                       |                  |                  |
|-----------------------|------------------|------------------|
| Register Qty.         | 2                | 0x0001~0x0004    |
| Register bytes number | 1                | 2* Register Qty. |
| Register contents     | 2* Register Qty. |                  |

Response format:

| Protocol data unit       | Data length (bytes) | Range         |
|--------------------------|---------------------|---------------|
| Function code            | 1                   | 0x10          |
| Initial Register Address | 2                   | 0x0000~0xFFFF |
| Register Qty.            | 2                   | 0x0001~0x0004 |

Parameter 0x41 is to modify single inverter's parameter or control parameter and save it in an involatile memory. The format is similar with that of 0x06. The only difference is that 0x41 parameter is saved upon power failure, while 0x06 not. Since some of the control parameters cannot be saved in the involatile memory, the two commands in this case have the same effect. Those parameters will be introduced later. The management of parameters includes reading out the upper and lower limit of the parameters, parameters properties, max. index number of a parameter group, next or previous parameter group number, currently displayed status parameter index, or display the next status parameter. Parameter property includes R/W property, parameter unit, scaling, etc. These commands are helpful to provide information about parameter's range and properties etc., which are necessary for modifying parameters remotely. The protocol data unit of parameter management is as follows:

Request format:

| Protocol data unit | Data length (bytes) | Range                         |
|--------------------|---------------------|-------------------------------|
| Function code      | 1                   | 0x42                          |
| Sub-function code  | 2                   | 0x0000~0x0007                 |
| Data               | 2                   | It depends on inverter's type |

Response format:

| Protocol data unit | Data length (bytes) | Range         |
|--------------------|---------------------|---------------|
| Function code      | 1                   | 0x42          |
| Sub-function code  | 2                   | 0x0000~0x0007 |
| Data               | 2                   | 0x0000~0xFFFF |

If the operation fails, error codes and exception code will be replied. The exception code is shown in Table below. Sub-function of parameter management.

| Sub-function code | Data (request)                                                          | Data (respond)                                                            | Meaning                                         |
|-------------------|-------------------------------------------------------------------------|---------------------------------------------------------------------------|-------------------------------------------------|
| 0x0000            | Parameter group number and index within a group occupy the MSB and LSB. | Upper limit of a parameter.                                               | Read the upper limit of a parameter             |
| 0x0001            | Parameter group number and index within a group occupy the MSB and LSB. | Lower limit of a parameter                                                | Read the lower limit of a parameter             |
| 0x0002            | Parameter group number and index within a group occupy the MSB and LSB. | Parameter property, see description below                                 | Read out Parameter property                     |
| 0x0003            | Parameter group number occupies the MSB and the LSB is "00".            | Max. index within a parameter group                                       | Read max. index within a parameter group        |
| 0x0004            | Parameter group number occupies the MSB and the LSB is "00".            | Next parameter group number takes the higher byte and lower byte is "00". | Read next parameter group number                |
| 0x0005            | Parameter group number occupies the MSB and the LSB is "00".            | Last Parameter group number occupies the MSB and the LSB is "00".         | Read previous parameter group number            |
| 0x0006            | 0x3300                                                                  | Currently displayed status parameter index                                | Read currently Displayed status parameter index |
| 0x0007            | 0x3300                                                                  | Next status parameter index                                               | Display next status parameter                   |

The status parameter group cannot be modified nor support upper or lower limit read-out operation.

Parameter property is 2 bytes in length. The definitions of its bits are as follows:

| Parameter property (Bit) | Value    | Meaning                               |
|--------------------------|----------|---------------------------------------|
| Bit2~Bit0                | 000B     | No decimal part                       |
|                          | 010B     | One digit of decimal                  |
|                          | 011B     | Two digits of decimal                 |
|                          | 100      | Three digits of decimal               |
|                          | Others   | Reserved                              |
| Bit3                     | Reserved |                                       |
| Bit5~Bit4                | 00B      | Modification step is “1”              |
|                          | Others   | Reserved                              |
| Bit7~Bit6                | 01B      | Modifiable                            |
|                          | 10B      | Cannot be modified during running     |
|                          | 11B      | Set by factory, cannot be modified    |
|                          | 00B      | Actual parameters, cannot be modified |
| Bit11~Bit8               | 0000B    | No unit                               |
|                          | 0001B    | Unit: HZ                              |
|                          | 0010B    | Unit: A                               |
|                          | 0011B    | Unit: V                               |
|                          | 0100B    | Unit: r/min                           |
|                          | 0101B    | Unit: (m/s)                           |
|                          | 0110B    | Unit: (%)                             |
|                          | Others   | Reserved                              |
| Bit12                    | 1        | Upper limit is active every nibble    |
|                          | 0        | Upper limit is active as a whole word |
| Bit15~Bit13              | Reserved |                                       |

Inverter control parameters cover the inverter start/stop, frequency setting, etc. Through the status parameters, present frequency, output current, output torque, etc. can be retrieved. The control and status parameters are listed below:

#### Inverter's Control Parameters Index

| Register Address | Parameter name       | Save upon power-off |
|------------------|----------------------|---------------------|
| 0x3200           | Control command word | N                   |
| 0x3201           | Main reference freq. | Y                   |

|        |                                  |   |
|--------|----------------------------------|---|
| 0x3202 | Reference Frequency              | Y |
| 0x3203 | Digital close loop setting       | Y |
| 0x3204 | Pulse close loop setting         | Y |
| 0x3205 | Analog output AO1 setting        | N |
| 0x3206 | Analog output AO2 setting        | N |
| 0x3207 | Digital output DO setting        | N |
| 0x3208 | Freq. proportion setting         | N |
| 0x3209 | Virtual terminal control setting | N |
| 0x320A | Acc time 1                       | Y |
| 0x320B | Dec time 1                       | Y |

#### SINUS VEGA Inverter Status Parameters Index

| Register Address | Parameter Name                                                                                                                                              |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0x3300           | Operation status word 1                                                                                                                                     |
| 0x3301           | Actual value of the current main setting                                                                                                                    |
| 0x3302           | Inverter model                                                                                                                                              |
| 0x3303           | Inverter type                                                                                                                                               |
| 0x3304           | Software version                                                                                                                                            |
| 0x3305           | Present actual frequency                                                                                                                                    |
| 0x3306           | Output current                                                                                                                                              |
| 0x3307           | Output voltage                                                                                                                                              |
| 0x3308           | Output power                                                                                                                                                |
| 0x3309           | Actual rotating speed                                                                                                                                       |
| 0x330A           | Actual line speed                                                                                                                                           |
| 0x330B           | Analog close loop feedback                                                                                                                                  |
| 0x330C           | Bus voltage                                                                                                                                                 |
| 0x330D           | External counter                                                                                                                                            |
| 0x330E           | Output torque                                                                                                                                               |
| 0x330F           | Digital value I/O terminal status:: (for power rate lower than 4.0KW, TC2 is for NC)<br>BIT0~15=X1~X5, NC, NC, NC, Y1, Y2, TC1, (TC2), FAN, BRAKE, FWD, REV |
| 0x3310           | Actual length                                                                                                                                               |
| 0x3311           | Frequency after compensation                                                                                                                                |
| 0x3312           | First fault in operation                                                                                                                                    |
| 0x3313           | Second fault in operation                                                                                                                                   |
| 0x3314           | Third fault (latest) in operation                                                                                                                           |

|        |                                                                                                                                                                                                                               |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0x3315 | Frequency setting                                                                                                                                                                                                             |
| 0x3316 | Rotation speed setting                                                                                                                                                                                                        |
| 0x3317 | Analog close loop setting                                                                                                                                                                                                     |
| 0x3318 | Line speed setting                                                                                                                                                                                                            |
| 0x3319 | VCI                                                                                                                                                                                                                           |
| 0x331A | CCI                                                                                                                                                                                                                           |
| 0x331B | Preset length                                                                                                                                                                                                                 |
| 0x331C | Preset Acc time 1                                                                                                                                                                                                             |
| 0x331D | Preset Dec time 1                                                                                                                                                                                                             |
| 0x331E | Command sending method:<br>0: Keypad<br>1: Terminal<br>2: Serial port                                                                                                                                                         |
| 0x331F | Inverter status word 2                                                                                                                                                                                                        |
| 0x3320 | Frequency setting method:<br>0: digital setting 1, by ▲, ▼ key<br>1: digital setting 2, by UP/DN terminal<br>2: digital setting 3, serial port<br>3: VCI analog setting<br>4: CCI analog setting<br>5: terminal PULSE setting |

#### Bit Definition of Inverter Control Word:

| Control word (bit) | Value  | Meaning             | Function                                                                  |
|--------------------|--------|---------------------|---------------------------------------------------------------------------|
| Bit2、1、0           | 111B   | Operation command   | Start the inverter                                                        |
|                    | 110B   | Mode 0 stop         | Stop as preset Dec time                                                   |
|                    | 101B   | Mode 1 stop         | Coast to stop                                                             |
|                    | 011B   | Mode 2 stop         | Reserved                                                                  |
|                    | 100B   | External fault stop | Coast to stop.<br>External fault message will be displayed                |
|                    | Others | No command          |                                                                           |
| Bit3               | 1      | Reverse             | Running direction when operation command valid, invalid for jog operation |
|                    | 0      | Forward             |                                                                           |
| Bit4               | 1      | Jog forward         |                                                                           |
|                    | 0      | Jog forward stop    |                                                                           |



| Control word (bit) | Value   | Meaning                     | Function                                      |
|--------------------|---------|-----------------------------|-----------------------------------------------|
| Bit5               | 1       | Jog reverse                 |                                               |
|                    | 0       | Jog reverse stop            |                                               |
| Bit6               | 1       | Acc/Dec allowed             | Reserved                                      |
|                    | 0       | Acc/Dec prohibited          |                                               |
| Bit7               | 1       | Serial port control valid   | Current control word from serial port valid   |
|                    | 0       | Serial port control invalid | Current control word from serial port invalid |
| Bit8               | 1       | Main setting valid          | Enable main setting                           |
|                    | 0       | Main setting invalid        | Disable main setting                          |
| Bit9               | 1       | Fault reset valid           |                                               |
|                    | 0       | Fault reset invalid         |                                               |
| Bit15~Bit10        | 000000B | Reserved                    |                                               |

Note: The jog operation setting (Bit4, Bit5) and Bit0~Bit2 must not be valid at the same time.

#### Bit Definition of Inverter Status Word 1:

| Status word | Value | Meaning                          | Note |
|-------------|-------|----------------------------------|------|
| Bit0        | 1     | Inverter running                 |      |
|             | 0     | Inverter stops                   |      |
| Bit1        | 1     | Inverter reverse running         |      |
|             | 0     | Inverter forward running         |      |
| Bit2        | 1     | Main setting arrived             |      |
|             | 0     | Main setting not arrived         |      |
| Bit3        | 1     | Communication control allowed    |      |
|             | 0     | Communication control prohibited |      |

|         |         |            |                                                                                                                                               |
|---------|---------|------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| Bit7~4  | 0000B   | Reserved   |                                                                                                                                               |
| Bit15~8 | 00~0xFF | Fault code | 0 0: inverter normal<br>others: inverter is faulty,<br>see fault code in user<br>manual. E.g., the fault<br>code of motor<br>overload is 0x0E |

Bit Definition of Inverter Status Word 2:

### Note

- 1、The communication will be interrupted during restoring to default parameters or auto-tuning, and resume to normal after them.
- 2、The parameter F1.10、FP.03 cannot be modified through communication
- 3、FP.00 (password) can be verified through WRITE command.
- 4、If several multi-function terminals are set to the same function, error will occur. Please avoid it when modifying them using MODBUS protocol.

## 10.4 Application

The command of starting 1# inverter, running forward, 50.00Hz (write as 5000 in the command):

|          | Address | Function code | Initial register address | Quantity of registers | Bytes of registers content | Content of register | Checksum |
|----------|---------|---------------|--------------------------|-----------------------|----------------------------|---------------------|----------|
| Request  | 0x01    | 0x10          | 0x3200                   | 0x0002                | 0x04                       | 0x01C7, 0x1388      | 0x0399   |
| Response | 0x01    | 0x10          | 0x3200                   | 0x0002                | none                       | none                | 0x4F70   |

Read the operation frequency of 1# inverter, the respond operation frequency is 50.00HZ:

|          | Address | Function code | Initial register address | Bytes of registers content | Content of register | Checksum |
|----------|---------|---------------|--------------------------|----------------------------|---------------------|----------|
| Request  | 0x01    | 0x03          | 0x3301                   | 0x0001                     | None                | 0xDA8E   |
| Response | 0x01    | 0x03          | None                     | 0x02                       | 0x1388              | 0xB512   |

Modify 1# inverter Acc time 1 (Parameter F0.12) to 10.0s, not save upon power-off.

|          | Address | Function code | Initial register address | Content of register | Checksum |
|----------|---------|---------------|--------------------------|---------------------|----------|
| Request  | 0x01    | 0x06          | 0x000C                   | 0x0064              | 0x4822   |
| Response | 0x01    | 0x06          | 0x000C                   | 0x0064              | 0x4822   |

Read 1# inverter output current, the replay is 30.0A.

|          | Address | Function code | Initial register address | Bytes of registers content | Content of register | Checksum |
|----------|---------|---------------|--------------------------|----------------------------|---------------------|----------|
| Request  | 0x01    | 0x03          | 0x3306                   | 0x0001                     | None                | 0x6B4F   |
| Response | 0x01    | 0x03          | None                     | 0x02                       | 0x012C              | 0xB809   |

Modify 1# inverter operating frequency to 35.00HZ:

|          | Address | Function code | Register address | Register content | Check sum |
|----------|---------|---------------|------------------|------------------|-----------|
| Request  | 0x01    | 0x06          | 0x3202           | 0x0DAC           | 0x225F    |
| Response | 0x01    | 0x06          | 0x3202           | 0x0DAC           | 0x225F    |

Read 1# inverter DC bus voltage inverter response DC Bus voltage is 541V:

|          | Address | Function code | Register address | Bytes of registers content | Register content | Check sum |
|----------|---------|---------------|------------------|----------------------------|------------------|-----------|
| Request  | 0x01    | 0x03          | 0x330C           | 0x0001                     | Null             | 0x4B4D    |
| Response | 0x01    | 0x03          | Null             | 0x02                       | 0x021D           | 0x792D    |

Modify 1# inverter deceleration time (function code F0.13) change to 14.0s, no parameter save after power off

|          | Address | Function code | Register address | Register content | Check sum |
|----------|---------|---------------|------------------|------------------|-----------|
| Request  | 0x01    | 0x06          | 0x000D           | 0x008C           | 0x19AC    |
| Response | 0x01    | 0x06          | 0x000D           | 0x008C           | 0x19AC    |

Read the operating status of 1#inverter:

|          | Address | Function code | Register address | Bytes of registers Content | Register content | Check sum |
|----------|---------|---------------|------------------|----------------------------|------------------|-----------|
| Request  | 0x01    | 0x03          | 0x3300           | 0x0001                     | Null             | 0x8B4E    |
| Response | 0x01    | 0x03          | Null             | 0x02                       | 0x0001           | 0x7984    |

Modify the multi-stage frequency of 1# inverter(function code isF8.00) to 10.00HZ:

|          | Address | Function code | Register address | Register content | Check sum |
|----------|---------|---------------|------------------|------------------|-----------|
| Request  | 0x01    | 0x06          | 0x0800           | 0x03E8           | 0x8B14    |
| Response | 0x01    | 0x06          | 0x0800           | 0x03E8           | 0x8B14    |

## 10.5 Scaling

A) Frequency scaling: 1:100

If the inverter is expected to run at 50Hz, the main setting should be 0x1388 (5000) .

B) Time scaling: 1:10

If the inverter acceleration time is expected to be 30S, the parameter should be set at 0x012c (300) .

C) Current scaling: 1:10


If the feedback current is 0x012c, the present current is 30A.

D) The output power is an absolute value

E) Others, such as terminal input or output, please refer to user manual.

## Appendix I

### Closed-loop tension speed control



Drive works at speed mode, set process PID regulator to control the speed in order to control tension, PID set point is the tension set point, PID feedback is tension sensor voltage.

### Closed-loop tension speed control with feed-forward

Under the speed control mode of the inverter, it controls the motor speed to keep the cable (belt) constant tension. Motor speed contains 2 parts:

1) Convert the cable (belt) line speed to motor speed

$$n_1 = \frac{v \cdot i}{\pi \cdot D}$$

$v$  : current belt line speed;


$i$  : Mechanical transmission ratio;

$D$  : Current volume diameter

2)  $\Delta n$  : Speed micro regulation from result PID closed control (tension set point and tension feedback)

Under speed control mode, can achieve constant line-speed via detected line speed and current rolling diameter (no need tension feedback), can also achieve simple process PID control via tension set point and tension feedback (no need detect

speed). Also can get the speed command  $n_1 + \Delta n$  via line speed detection and tension feedback.



Speed Mode



Via Della Concia, 7  
40023 Castel Guelfo (BO)-ITALY  
t. +39 0542 489711 - f. +390542 489722  
info@santerno.com - santerno.com

